

# ALTIVAR<sup>®</sup> 66

PCMCIA communication card  
UNI-TELWAY, MODBUS/JBUS  
protocols

VW3-A66301

Serial link via graphic keypad port

User's manual



GRUPE SCHNEIDER



Although every care has been taken in the preparation of this document, Schneider Electric SA cannot guarantee the contents and cannot be held responsible for any errors it may contain or for any damage which may result from its use or application.

The hardware, software and services described in this document may be changed or modified at any time, either from a technical point of view or in the way they are operated. Their description can in no way be considered contractual.

# Contents

---

## Hardware setup

---

Introduction	2
Installing the card	3 and 4
Connection to multidrop bus	5 to 7

---

## Software setup

---

Configuration of the communication functions	8 to 10
Communication state	11
Diagnostics	12

---

## Description of protocols

---

UNI-TELWAY requests	13 to 16
MODBUS / JBUS protocol	17 to 28
Graphic keypad serial link	29 to 33

---

## Communication principle

---

34 to 43

---

## Altivar 66 variables

---

<a href="#">Command and adjustment variables</a>	<a href="#">44 to 47</a>
--	--------------------------

---

<a href="#">Signalling variables</a>	<a href="#">48 to 60</a>
--------------------------------------	--------------------------

---

<a href="#">Configuration variables</a>	<a href="#">61 to 93</a>
---	--------------------------

---

Address zone common to Altivar 66 and Altivar 45.2	94 to 98
--	----------

---

Index	99 to 111
-------	-----------

---

# Hardware setup

---

## Introduction

The communication card reference **VW3-A66301** is designed for use with Altivar 66 speed controllers fitted with VW3-A66205, VW3-A66201Q or VW3-A66202Q communication interfaces.

It is designed to integrate these power switching components into modern control system architectures by enabling them to be connected to a multidrop industrial bus.

Data exchanges enable all functions of the Altivar 66 to be used :

- function configuration,
- remote downloading of settings,
- control and supervision,
- monitoring,
- diagnostics.

The **VW3-A66301** communication card, in extended type 3 PCMCIA format, has a 3 m connection cable fitted with a 15-pin SUB-D connector.

This card manages the following communication protocols :

- UNI-TELWAY,
- MODBUS, RTU / JBUS,
- MODBUS ASCII.

Note : PCMCIA : Personal Computer Memory Card International Association

**For optimum use of this manual, we recommend that you read the section entitled "Communication principle". In addition, use the index at the end of this manual to help you find Altivar 66 parameters.**

# Hardware setup

## Installing the card


- **Receipt :**

Ensure that the card reference printed on the label is the same as that on the delivery note corresponding to the delivery advice.

Remove the packaging and check that the communication option card has not been damaged in transit.

- **Installing the card in the speed controller :**

Before starting work on the controller, disconnect the power supply and wait for the capacitors to discharge (around 1 minute after switching off).



- **Mounting precautions :**

To access the slot for mounting the extension card, unlock the protective cover and pivot it from right to left.

Check that there is no voltage on the DC bus : red LED off.

Remove the IP20 protective cover from the J10 connector on the control card.

Mount the option card on the control card by plugging it into the J10 terminal block, press on both sides of the J10 connector with your fingers to plug it in securely, and fix it using the two captive screws.


# Hardware setup

---

## Installing the card

Once the communication interface (**VW3-A66205**, **VW3-A66201Q** or **VW3-A66202Q**) has been mounted in the speed controller :

- Insert the **VW3-A66301** communication card into its slot so that the 3-meter connection cable is pointing to the left outside the speed controller.




Note : For ratings of ATV66-U41N4 to D12N4 / ATV66-U41M2 to U90M2 break off the precut (1) tab.

# Hardware setup

## Connection to multidrop bus


### SUB-D connector pin configuration

The transmission interface is electrically isolated from the speed controller in accordance with the RS 485 and RS 422 (RS 232 C compatible) standards. It is available on a 15-pin SUB-D connector.




## Connection to standard RS 485 bus

### Pins to be used



### Recommendations

- use a shielded cable with 2 pairs of twisted conductors,
- connect the reference potentials to each other,
- maximum length of line : 1000 meters,
- maximum length of drop cable : 20 meters,
- do not connect more than 28 stations to one bus,
- cable routing : keep the bus away from the power cables (at least 30 cm) with any crossovers at right angles, and connect the cable shielding to the ground of each device,
- fit a line terminator at both ends of the line.



Zt line terminator recommended at both ends of the line

# Hardware setup

## Connection to multidrop bus

Various accessories are available to facilitate connection of equipment.


- Cables for **TSX-CSA...** bus sold in lengths of 100, 200 or 500 m.
- **TSX-SCA62** subscriber connector

This passive unit consists of a printed circuit fitted with screw terminal blocks and enables two devices to be connected to the bus. It includes an end of line terminator when the connector is at the end. The switches in the socket must be positioned in the following manner :

switch number	switch position
2	OFF
3	OFF
5	OFF

the position of the other switches has no effect.

## Example of connection to UNI-TELWAY bus



Note : it is imperative that the earths are connected between the TSX-SCA unit and the Altivar 66 to ensure the system operates correctly.  
In addition, these connections must be as short as possible.


# Hardware setup

---

Connection to multidrop bus


## Connection to standard RS 422 bus

**Pins to be used**



## RS 232 C connection

**Pins to be used**



# Software setup

## Configuration of the communication functions

### Initial power-up

To gain a good understanding of accessing the various menus we recommend that you consult the speed controller programming manual.

A message appears on the screen on initial power-up which enables identification of the option.

```
OPT. : UW3A66205
-----
          INSTALLED
REMEMBER YOU NEED TO
CONFIGURE THE OPTION
ENT to continue
```

The reference number of the chosen card and its version appear after OPT.

Confirm acknowledgment of the option by pressing ENT. This reconfigures the speed controller to its factory settings.

```
          ENT ↓
          ↑ ESC
DRIVE IDENTIFICATION
ATV66U41N4 , DC ,U3.2
Power   : 2.2kW/3HP
In= 5.8A, Imax= 8.0A
SUPPLY  : 400-415 V
▼, ▲
OPT.1 UW3A66205
```

In the drive identification menu, it is possible to check the reference number, the drive number and option 3 selected using the directional ▼ ▲ keys.

```
          FAULT
OPT. : UW3A66205
IS NOT RECOGNIZED
OR
HAS BEEN REMOVED
ENT to continue
```


This screen appears on power-up if an option has been removed which was configured during a previous power-up.

```
          ENT ↓
          ↑ ESC
TO RESET THE FAULT
YOU NEED TO REINSTALL
OPT.: UW3A66205
or initialize drive
to factory settings
ENT to initialize
```

Cut the general power supply to the speed controller before reinstalling the extension card ([see page 3](#)).


# Software setup

## Configuration of the communication functions



### Configuration


After installing the option, select menu 11 "Communication" to access the card configuration.  
 (To move around use the ▼ ▲ keys)  
 To access menu 11, remember to unlock the access to menus.



This menu includes 5 parameters for configuring the address, protocol, transmission speed, frame format and parity.

When a factory setting is made with the PCMCIA card present : menu 11 remains configured.

### Protocol



(Modbus RTU = Jbus)

### Address


The default address setting is to 0 (not configured) and the maximum is 31.

# Software setup

---

## Configuration of the communication functions


### Transfer speed



- Transmission speed setting from 300 bits/s to 19,200 bits/s.


Default setting of 9,600 bits/s.

### Frame format



- Frame format. There are 4 formats  
7 bits with 1 or 2 stop bits  
8 bits with 1 or 2 stop bits.

### Parity



Parity assignment.

The format is fixed for UNITELWAY (8 bits 1 stop ODD)  
For Modbus RTU : only the 8-bit format is available.

Only the following formats are permitted :

- 8 bits 1 stop all selections are possible.
- 8 bits 2 stop only NO.
- 7 bits NO cannot be selected.

# Software setup

---

## Communication state

Menu 12 on the graphic keypad displays the communication state.

### "Card missing" display

12 COMM. STATE
Card Missing
See Menu 11

In this case, the communication card is missing or not yet configured.

### "Communication card present" display

12 COMM. STATE
VW3A66301 V1.0
UTW/Modbus ADR. 0
Not configured
See Menu 11

Note : the "UTW / Modbus" indication is unique and corresponds to the name of the option card. It is irrelevant whether the protocol is UNI-TELWAY or Modbus .

"Not configured" indicates that the card has been identified but the protocol has not been configured.

"Configuration error" indicates that the identified card does not correspond to the protocol configured.

### Card display during operation

12 COMM. STATE
VW3A66301 V1.0
UTW/Modbus ADR. 0
Bus active ←
CPT Message 00000

Different network states are possible with the communication card :  
initializing, bus active, bus inactive

# Software setup

---


## Diagnostics

### Fault

For the communication fault codes refer to the user's manual for the PCMCIA communication card interface.

### Additional diagnostics

Check the state of the 2 indicator lamps on the front panel of the VW3-A66301 communication card.



Lamp status : 0 = off

1/2 = flashing

1 = on

COM lamp green	ERR lamp red	Probable cause	Corrective action
1	0	Normal operation	
1/2	0	Incorrect communication configuration, or communication fault with the Altivar 66	Check configuration. Ensure software is compatible.
0	1	Bus communication fault	Check position of the switches of the TSX-SCA 62 subscriber connector of the Altivar 66 (when off). Check connections, presence configuration and operation of link master.
0	0	PCMCIA card or speed controller fault	Remove the PCMCIA card and check the Altivar 66. Replace the Altivar 66 or the card as necessary.

# Description of protocols

---

## UNI-TELWAY requests

### List of requests

The following table describes the requests accepted by the Altivar 66 and their limits. Details of the coding of the requests are given in the UNI-TELWAY reference manual.

Request	Code (hex)	Altivar 66
Identification	H'0F'	Yes
Protocol version	H'30'	Yes
Status	H'31'	Yes
Mirror	H'FA'	Yes
Read error counters	H'A2'	Yes
Reset counters	H'A4'	Yes
Read a bit	H'00'	Yes
Write a bit	H'10'	Yes
Read a word	H'04'	Yes
Write a word	H'14'	Yes
Read objects	H'36'	63 words max.
Write objects	H'37'	60 words max.
Event data	–	Yes 2 words
Specific	H'F2'	See later

### Identification request

Response code = H'3F'  
Product type = H'14' for Altivar  
Sub-type = H'66' Altivar 66  
Product version = H'XX' software version (e.g. : H'21' for V2.1)  
ASCII string\* = product reference (e.g. : VAR-66U29N4)

\* The first byte of an ASCII string always corresponds to the length of the string.

### Status request

Response code = H'61'  
Current status = H'XX'  
(present at high state)  
bit 0 : internal fault  
bit 1 : correctable fault  
bit 2 : uncorrectable fault  
bit 3 : not significant  
bit 4 : not significant  
bit 5 : not significant  
bit 6 : speed controller stopped (RDY or SLC or fault)  
bit 7 : speed controller in LOCAL control  
Status mask = H'C7' indicates the significant bits for the current status

# Description of protocols

## UNI-TELWAY requests

### Requests to read and write objects

These requests are used to access several words within the limits described on the previous page. These requests can be coded by specifying :

Question code (TxTi,C) = H'36' (read) or H'37' (write)  
Category = 0...7  
Segment = H'68' (internal word)  
Object type = H'06' for a byte (8 bits) in read-only or H'07' for a word (16 bits) in read and write  
Object address = H'xxxx'

Etc.

Reserved or unused words are read as 0 and if written they have no meaning.

The response to the "write objects" request is accepted if at least one word is written.

**Example** : programming on a TSX7 PLC using a text block.

READ words W2020 to W3023 of the Altivar 66.

#### – Using word type object = H'07'

Transmission text block

TxTi,C = H'0736' (category + request)

TxTi,L = 6


+ transmission table

Reception text block

TxTi,V = H'66' (confirm)

TxTi,S = 9 (9 bytes received)

+ reception table



W2020 (Lo)	H'07'
W2021 (Lo)	W2020 (Hi)
W2022 (Lo)	W2021 (Hi)
W2023 (Lo)	W2022 (Hi)
	W2023 (Hi)

The data received in the reception table is offset by one byte. It is the application program which must correct the data (for example by successive offsets) before using it.

# Description of protocols

## UNI-TELWAY requests

– **Using byte type object = H'06'**

Transmission text block

TxTi,C = H'0736' (category + request)

TxTi,L = 6


+ Transmission table

Reception text block

TxTi,V = H'66' (confirm)

TxTi,S = 10 (10 bytes received)

+ Reception table



This programming enables words to be correctly positioned in the reception table.

## Event data

The Altivar 66 transmits data on its own initiative to the UNI-TELWAY link master without having first received a question.

This data is sent via the "unsolicited data" request and does not require a response from the receiver.

Data is transmitted in the following two cases :

- When a fault appears or disappears (rising or falling edge at status register bit W2040,2).
- When the speed controller is controlled locally via one of its logic inputs, if the input is assigned to this function (rising or falling edge at this input), or via the local key on the interface for the PCMCIA communication card.

Size of event data : 2 words of 16 bits sent in the following order :

- STR status register (word W2040).
- FLT fault register (word W2051).

# Description of protocols

---

## UNI-TELWAY requests

### Summary :

the use of event data with a TSX PLC requires :

- Correct configuration of the UNI-TELWAY link master module.
- Regular monitoring of the indicators which display changes in the value of the data.
- Acquisition of this data via the request to read event data.

### Specific control request

This request is used to control the Altivar 66 and to obtain in return the data essential for controlling the speed controller.

#### Request format

Request code	: byte	= H'F2'
Category	: byte	= 0...7
Specific request code	: byte	= 0
Reserved	: byte	= 0
Command	: word	= COM
Set point	: word	= FRH
Acceleration	: word	= ACC
Deceleration	: word	= DEC

#### Confirm format

Request code	: byte	= H'F2'
Specific response code	: byte	= H'30'
Reserved	: byte	= 0
Set point	: word	= FRH
Status register	: word	= STR
Fault register	: word	= FLT
Motor current	: word	= LCR

#### Negative response

Response code	: byte	= H'FD'
---------------	--------	---------

Cause : incorrect number of parameters

# Description of protocols

---

## MODBUS / JBUS protocol

### General

The exchange of data between computer systems, PLCs and other intelligent systems must be performed using a common language.

This language should be as simple as possible and understood by everyone involved. Nevertheless it must be possible to check every exchange to ensure the integrity of the transfers. The variables exchanged are therefore inserted in a frame which generally comprises the following :



Each protocol defines the presence, the format and the contents of the various groups of variables which surround the data zone.

This structuring makes it possible to define the start and the size of messages, if necessary the system to which the data is addressed, the type of function required, the variables themselves, a control parameter and an end code which validates the whole message.

The form and content of this frame are different for each type of protocol.


In the remainder of this document the MODBUS and JBUS functions will be referred to under the term MODBUS.

### MODBUS frames

Two transmission modes can be used, only one of them being used in a system.

#### RTU mode

The frame defined for the MODBUS protocol has neither message heading bytes nor end of message bytes. It is defined as follows :



The data is transmitted in binary code.

CRC16 : cyclical redundancy check.

The end of the frame is detected on a silence of 3 characters or more.

#### ASCII mode

The frame is complete and defined in the following way :



- heading = ":" (H'3A),
- data is coded in ASCII : each byte is divided into 2 four-bit bytes, each of which is coded by an ASCII character (0 to F),
- LRC : longitudinal redundancy check,
- end : "CR" "LF" (H'0D and H'0A).

# Description of protocols

---

## MODBUS / JBUS protocol

### Principle


The MODBUS protocol is a dialogue protocol which creates a hierarchical structure (a master and several slaves).

The MODBUS protocol enables the master to interrogate one or more intelligent slaves. A multidrop link connects the master and slaves.

Two types of dialogue are possible between master and slaves :

- the master talks to a slave and waits for its response,
- the master talks to all slaves without waiting for a response (broadcasting principle).

The slaves are numbered from 1 to 31 and number 0 is reserved for broadcasting.



### Note

No lateral communication (i.e. slave to slave) can be performed directly.

The application software of the master must therefore be designed to interrogate a slave and send back data received to another slave.

# Description of protocols

## MODBUS / JBUS protocol


### Accessible data

The MODBUS protocol enables data (bits and words) to be exchanged between a master and several slaves, and checks these exchanges.

Consequently, bit areas are defined in each slave unit which will be read or written by the master.

An input object can only be read.

An output object can be read or written.



### Exchanges

The master, or supervision device, takes the initiative in exchanges. This master addresses a slave by supplying it with four types of data :

- the address of the slave,
- the function required of the slave,
- the data area (variable depending on the request),
- the exchange check.

The link master waits for the response of the slave before transmitting the next message, thus avoiding any conflict on the line. Operation in half duplex is therefore authorized.


# Description of protocols

---

## MODBUS / JBUS protocol

### Control and monitoring

All control of exchanges between two units which are communicating via asynchronous serial link naturally includes exception messages when exchange faults occur. Various incorrect messages may be sent to a slave. In this event, the slave will tell the master that it does not understand, and the master will decide whether or not to repeat the exchange.



The master has access to a certain amount of data which is stored and managed by the slave. The master can access this data using special function codes (diagnostic mode, read event counter, etc).

# Description of protocols

---

## MODBUS / JBUS protocol

### MODBUS functions

MODBUS functions include :

- main functions for exchanging data,
- additional functions for exchange diagnostics.

The following table shows the functions which are managed by the ALTIVAR 66 communication option, and specifies its limits.

Definitions of "read" and "write" functions are understood from the point of view of the master.

Code	Type of functions	B	ALTIVAR 66
01	Read N output bits		1 max
02	Read N input bits		1 max
03	Read N output words		63 max
04	Read N input words		63 max
05	Write one output bit	B	Yes
06	Write one output word	B	Yes
08	Diagnostics (see details below)		Yes
11	Read event counter		Yes
16	Write N output words	B	60 max

**Functions marked "B" can be broadcast.**

**The message transmitted by the master must specify slave number = 0.**

**A response message is never returned.**

### Detailed information on functions

- Code 01 : read N output bits.  
This function is used to read output bits (bits which can be written and read in the slave by the master).
- Code 02 : read N input bits.  
As above, but applies to input bits (bits which the master can only read).
- Code 03 : read N output words.  
This function is used to read output words (words which can be written and read in the slave by the master).
- Code 04 : read N input words.  
As above, but applies to input words (words which the master can only read).
- Code 05 : write an output bit.  
Used to set an output bit to 0 or 1 (can only be accessed in write).
- Code 06 : write an output word.  
Used to write a 16-bit output word (can only be accessed in write).

# Description of protocols

---

## MODBUS / JBUS protocol

Diagnostic function code 08 is always accompanied by a sub-code.

- Code 08/00 : echo.  
This function requests the interrogated slave to send back the whole message sent by the master.
- Code 08/01 : channel reinitialization.  
This function is used to reinitialize communication of a slave and in particular to make it leave listen only mode (LOM) by sending data item H'0000 or H'FF00.
- Code 08/03 : change of ASCII delimiter.  
In ASCII mode, messages are delimited by the line feed character (LF = H'0A). This function is used to change this character.
- Code 08/04 : change to LOM mode.  
This function is used to command a slave to change to listen only mode (LOM). In this mode the slave does not process messages which are addressed to it, and only transmits a response when the channel is reinitialized.
- Code 08/0A : counter reset.  
This function resets to zero all the counters monitoring the exchanges of a slave.
- Code 08/0B : number of correct messages seen on the line without CRC or checksum error.  
This function reads a 16-bit counter (incremented from 0 to H'FFFF) which totals the messages seen on the line and processed by the slave.
- Code 08/0C : number of messages received with checksum error (reads a 16-bit counter).
- Code 08/0D : number of exception responses.  
Reads a 16-bit counter which totals the number of exception messages transmitted to the master by a slave (following an incorrect frame).
- Code 08/0E : number of messages addressed to the slave except for broadcasts.  
Reads a 16-bit counter which totals the number of all types of messages addressed to the slave.
- Code 08/0F : number of broadcast messages received.  
Reads a 16-bit counter which totals the number of all types of messages addressed to the slave.
- Code 08/10 : reads number of NAQ responses. The value read is always 0.
- Code 08/11 : reads the number of non-ready responses from the slave. The value read is always 0.
- Code 08/12 : reads the number of characters which are not processed (incorrect).

# Description of protocols

---

## MODBUS / JBUS protocol

- Code 11 :      read event counter.  
                  – a status (always zero),  
                  – a counter which is incremented each time a correct message sent to the slave  
                  is received (form and content) except for exception messages.
- Code 16 :      write N output words.  
                  This function enables the master to write output words to the slave  
                  (words which can be written or read).

# Description of protocols

## MODBUS / JBUS protocol

### Details of frames (RTU mode)

**Read N bits** : function 1 or 2

Question

Slave no.	01 or 02	No. of 1st bit		Number of bits		CRC16
		Hi	Lo	Hi	Lo	
1 byte	1 byte	2 bytes		2 bytes		2 bytes

Response

Slave no.	01 or 02	Number of bytes read	Value	Value	CRC16
1 byte	1 byte	1 byte			2 bytes

Example : read bit B4 of slave 2

Question	02	01	0004	0001	BC38
----------	----	----	------	------	------

Response	02	01	01	00	51CC	if B4 = 0
----------	----	----	----	----	------	-----------

	02	01	01	01	900C	if B4 = 1
--	----	----	----	----	------	-----------

Bit B4 can always be used and can be read at 1 or at 0.

**Read N words** : function 3 or 4

Question

Slave no.	03 or 04	No. of first word		Number of words		CRC16
		Hi	Lo	Hi	Lo	
1 byte	1 byte	2 bytes		2 bytes		2 bytes

Response

Slave no.	03 or 04	Number of bytes read	Value of 1st word		Value of last word		CRC16
			Hi	Lo	Hi	Lo	
1 byte	1 byte	1 byte	2 bytes		2 bytes		2 byte

Example : read words W3020 to W3023 of slave 2

Question	02	04	0BCC	0004	33E1
----------	----	----	------	------	------

Response	02	04	08	xxxx	xxxx	CRC16
----------	----	----	----	------	------	-------

Value  
of W3020

Value  
of W3023

# Description of protocols

---

## MODBUS / JBUS protocol

### Write an output bit : function 5

#### Question

Slave no.	05	Bit no. Hi   Lo	Bit value	CRC16
1 byte	1 byte	2 bytes	2 bytes	2 bytes

The "bit value" field has two possible values only, and can take no other value :

- bit at 0 = 0000
- bit at 1 = FF00

#### Response

Slave no.	05	Bit no. Hi   Lo	Bit value	CRC16
1 byte	1 byte	2 bytes	2 bytes	2 bytes

Example : write value 1 in bit B3 of slave 2

Question  
and response

02	05	0003	FF00	7C09
----	----	------	------	------

### Write an output word : function 6

#### Question

Slave no.	06	Word number Hi   Lo	Word value Hi   Lo	CRC16
1 byte	1 byte	2 bytes	2 bytes	2 bytes

#### Response

Slave no.	06	Word number Hi   Lo	Word value Hi   Lo	CRC16
1 byte	1 byte	2 bytes	2 bytes	2 bytes

Example : write value H'0315' = 789 in word W3022  
of slave 2 (ACC = 78.9 s)

Question  
and response

02	06	0BCE	0315	2B1D
----	----	------	------	------

# Description of protocols

## MODBUS / JBUS protocol

### Diagnostic : function 8

Question and response

Slave no.	08	Sub-code	Data	CRC16
1 byte	1 byte	2 bytes	2 bytes	2 bytes

Sub-code	Question data	Response data	Function executed
00	XX YY	XX YY	Echo
01	00 00	00 00	Reinitialization
03	XX 00	XX 00	XX = new delimiter
04	00 00	No response	Change to LOM mode
0A	00 00	00 00	Reset counters to 0
0B	00 00	XX YY	XXYY = counter value
0C	00 00	XX YY	XXYY = counter value
0D	00 00	XX YY	XXYY = counter value
0E	00 00	XX YY	XXYY = counter value

### Read event counter : function 11 (H'0B')

Question

Slave no.	0B	CRC16
1 byte	1 byte	2 bytes

Response

Slave no.	0B	00   00	Counter value Hi   Lo	CRC16
1 byte	1 byte	2 bytes	2 bytes	2 bytes

### Write N output words : function 16 (H'10')

Question

Slave no.	10	No. of 1st word Hi   Lo	Number of words	Number of bytes	Value of 1st word Hi   Lo	.....	CRC16
1 byte	1 byte	2 bytes	2 bytes	1 byte	2 bytes		2 bytes

Response

Slave no.	10	No. of 1st word Hi   Lo	Number of words Hi   Lo	CRC16
1 byte	1 byte	2 bytes	2 bytes	2 bytes

Example : write values 2 and 3 in words W3022 and W3023 of slave 2

Question	02	10	0BCE	0002	04	0002	0003	E3C6
----------	----	----	------	------	----	------	------	------

Response	02	10	0BCE	0002	2220
----------	----	----	------	------	------

# Description of protocols

---

## MODBUS / JBUS protocol

### Exception responses

An exception response is given by a slave when it is unable to perform the request which is addressed to it.

Format of an exception response :

Slave no.	Response code	Error code	CRC16
1 byte	1 byte	1 byte	2 bytes

**Response code** : function code of the request + H'80 (the most significant bit is set to 1).

**Error code** :

- 1 = the function requested is not recognized by the slave.
- 2 = the bit and word numbers (addresses) indicated in the request do not exist in the slave.
- 3 = the bit and word values indicated in the request are not permissible in the slave.
- 4 = the slave has started to execute the request but cannot continue to execute it completely.

### CRC16 calculation

The CRC16 is calculated on all the bytes of the message by applying the following method.

Initialize the CRC (16-bit register) to H'FFFF.

Enter the first to the last byte of the message :

CRC XOR <byte> → CRC

Enter 8 times

Move the CRC one bit to the right

If the output bit = 1, enter CRC XOR H'A001 → CRC

End enter

End enter

The low order byte of the CRC obtained will be transmitted first, followed by the high order ones.

XOR = exclusive OR.


# Description of protocols

---

## MODBUS / JBUS protocol

### ASCII mode

In this mode, the MODBUS frame has the following structure :



**Delimiters** : ":" = H'3A', CR = H'0D', LF = H'0A'.

**Data** : the data field is analogous to the RTU frames, but coded in ASCII characters. Each byte is divided into 2 four-bit bytes, each of which is coded by its ASCII equivalent.

Example : the byte containing the slave number 06 will be coded by 2 ASCII characters "0" and "6", i.e. by H'30' and H'36'.

**LRC** : modulo 256 hexadecimal sum of the contents of the frame (without the delimiters) before ASCII coding, 2's complement.

The byte obtained is then coded in the form of 2 ASCII characters as above.

Example : write value 1 in bit B3 of slave 2

Question and response

Hexadecimal

3A	30 32	30 35	30303033	46463030	4637	0D	0A
----	-------	-------	----------	----------	------	----	----

ASCII

:	02	05	0003	FF00	F7	CR	LF
---	----	----	------	------	----	----	----

LRC calculation

Sum of the bytes in the frame :

$$H'02' + H'05' + H'00' + H'03' + H'FF' + H'00' = H'109' = 265$$

Modulo sum 256 : H'09' = 9

Modulo sum 256 2's complement :

$$H'100' - H'09' = 256 - 9 = 247 = H'F7'$$

# Description of protocols

## Graphic keypad serial link

### General


Communication via serial link from the ALTIVAR 66 keypad port enables all data generated by the microprocessor controlling the speed controller to be accessed. Data is always available in read only form. The speed controller can be controlled (change frequency set point, start, etc) either via the serial link in LINE mode, or by local commands in LOCAL mode.

NOTE : In the description of the keypad port serial link, all characters are in ASCII code ([see ASCII code table on page 88](#)).

### Connection


#### SUB-D connector pin configuration

The transmission interface is electrically isolated from the speed controller in accordance with the RS 485 and RS 422 (RS 232 C compatible) standards. It is available on a 9-pin SUB-D connector .



#### Connection to standard RS 485 bus

##### Pins to be used




##### Recommendations

- use a shielded cable with 2 pairs of twisted conductors,
- connect the reference potentials between them,
- cable routing : keep the bus away from the power cables (at least 30 cm), with any crossovers at right angles, and connect the cable shielding to the ground of each device,
- fit a line terminator at both ends of the line.


# Description of protocols

---


## Graphic keypad serial link



## Connection to standard RS 422



## Connection to standard RS 232 C



# Description of protocols

---

## Graphic keypad serial link

### Definition of the link

9600 Baud asynchronous link

Format1 start bit

8 data bits

1 odd parity bit

1 stop bit

All these parameters are fixed. The link is of the master-slave type, with the speed controller as slave. Only one of the two stations can transmit at any given moment (half duplex link).

### Definition of the protocol

Dialogue is in question / response form :

The master asks a question and waits for the response within a given time (50 to 350 ms). If there is any uncertainty (parity or frame error, etc) the speed controller will not respond. If this occurs check that all of the link parameters are correct.

The messages are delimited by the start characters "?" for a question and ">" for a response, and the end characters LF or CR.

#### Question

Start	Question code	Data 1	Separator (*)	Data 2 (*)	End
?	See table <a href="#">on page 28</a>	Number of word or bit	1 or 2 characters <SP> or @	Value	either <LF> or <CR>

(\*) write only

Data 1 : Number of word or bit :

integer between 0 and + 32767.

The = sign is optional as are zeroes to the left of the number.

Example : 55 or +00055

Data 2 : Value of word or bit :

- Word : integer between -32768 and +32767.

The = sign is optional as are zeroes to the left of the number.

Example : 55 or +00055

-2345 or -02345

- Bit : 0 or 1.

#### Response

Start	Response code	Data 3(**)	End
>	See table <a href="#">on page 28</a>	Value	<LF> <CR>

(\*\*) read only

Data 1 : - Word: 6 characters, fixed format

Examples : +00034, -21254

- Bit : 0 or 1.

# Description of protocols

---

## Graphic keypad serial link

### Table of requests

	Question code	Response code	
		Positive	Negative
Read bit	A	A	N
Write bit	B	Y	N
Read word	C	C	N
Write word	D	Y	N
Mirror	M	M	N
Read 10 words	E	E	N

If response is negative :

- Number of bit or word does not exist.
- Question code does not exist.
- Incorrect question format (but with first character = ?).
- Write while the speed controller is not in LINE mode.
- Change of operating mode while the motor is not stopped.
- Change of operating mode which does not correspond to chart.

Request E enables 10 words to be read or written consecutively.

### Communication test : mirror

The mirror request returns the character string sent and can be used for the communication test.

Question : ?M12345<LF><CR>

Response : >M12345<LF><CR>

### Read bit

Bit to inhibit communication check : Read bit B4

Question : ?A4<LF><CR> or ?A+00004<LF><CR>

Response : >A0<LF><CR> if bit = 0 (check active)

Response : >A1<LF><CR> if bit = 1 (check inactive)

### Write bit

Change to LINE mode : write value 1 in bit B3.

Question : ?B3<SP>1<LF><CR>

Response : >Y<LF><CR>

### Read word

Value of analog input AI1 : read word W2044.

Question : ?C2044<LF><CR>

Response : >C+00100<LF><CR> (AI1 value = 100%)

### Write word

Frequency set point at 50 Hz : write word W2021.

Question : ?D2021<SP>3310<LF><CR>

Response : >Y<LF><CR>

# Description of protocols

---

## Graphic keypad serial link

**Table of ASCII codes used**

Dec.	Hex.	Character
10	0A	LF line feed
13	0D	
32	20	SP space
43	2B	+
45	2D	-
48	30	0
49	31	1
50	32	2
51	33	3
52	34	4
53	35	5
54	36	6
55	37	7
56	38	8
57	39	9
62	3E	>
63	3F	?
64	40	@
65	41	A
66	42	B
67	43	C
68	44	D
77	4D	M
78	4E	N
89	59	Y

---

# Communication principle

---

## Data structure

The adjustment, control, supervision and monitoring of the Altivar 66 are performed using data (or objects) which are specific to this product.

This data essentially consists of :

- BITS : named Bi (i = bit number) which are used to execute logic commands.

Example : B5 = start/stop command.

- WORDS (of 16 bits) : named Wi (i = word number) to be used for storing either integer values (from - 32768 to + 32767), or 16 independent logic states (these words are then called registers).

Examples :

W2021 = frequency set point (digital value),  
W2040 = register (16 status bits).

Notation : W2040.2 designates the bit in row 2 of register W2040.

## Accessing data

The tables in the section on ATV 66 variables list the parameters which can be accessed via the communication link. The exact function of each parameter and its effect on the behavior of the speed controller are described in the speed controller programming manual and catalogue.

Certain data can be accessed in both read and write : these are the bits and words corresponding to adjustments, commands or the configuration. This data is used by the speed controller.

However, data generated by the speed controller can only be accessed in read : signalling or fault data, for example. If written, they have no meaning and are rejected.

## Order in which data is processed

Where several types of parameter are written by the same request, the order in which parameters are processed is important in order to determine their validity. This order is as follows :

- 1) configuration parameters,
- 2) writing to 1 of bits W2020.1 and W2020.2 (DLI and FLI)
- 3) adjustment parameters,
- 4) command parameters (except W2020.1 and W2020.2)

# Communication principle

---

## Protection of access to configuration and settings

The configuration semaphore write protects the access to the configuration, adjustment and locking parameters (W199). The processor which writes word W198 = 1 reserves the semaphore and prohibits all write access to the parameters write-protected by other processors (graphic keypad, PC software and devices connected to buses). The configuration semaphore (W198 = 0) must be freed by the processor which reserved it.

The speed controller can operate normally when the configuration semaphore is reserved. Only the locking (W199 = 1) prevents starting.

The semaphore will return to its free state :

- in the event of a communication fault, or
- if after 60 seconds no request has been transmitted to the Altivar 66 by the processor which reserved it.

The configuration semaphore is reserved :

- by the keypad in a configuration menu.
- by the forced local function (in this case the reserving processor "loses" the semaphore).
- by the OEM locking function.

**Using configuration semaphore is optional as it is automatically reserved on locking when a controller stops (W199 = 1).**

## Protection of access to commands

The command semaphore write protects the access to the command objects (bits or words). The processor which writes word W2235 to 1 reserves the semaphore and prohibits all write access to commands by other processors (PC software). The command semaphore (W2235 = 0) must be freed by the processor which reserved it.

Note : It is possible to control the speed controller without having reserved the command semaphore.

The command semaphore is freed :

- in the event of a communication fault,
- if after 60 seconds no request has been transmitted to the Altivar by the processor which reserved the semaphore.

The command semaphore is reserved by the forced local function (in this case the reserving processor "loses" the semaphore).

## Protection of access in forced local mode

No writing is permitted during local forcing (when using the graphic keypad or logic input). The forced local function automatically reserves the command and configuration semaphores even if they have already been reserved.

**Protection of access in OEM locked mode** (function accessed by PC software)

Access locking signaled by W2049,2 = 1 prohibits reading of the configuration and adjustments. It also prohibits writing by reserving the configuration semaphore.

## Loading a configuration

This section deals with the complete loading of a configuration or a modification which requires several write messages. To ensure consistency of the configuration, carry out the following sequence :

- Lock the Altivar 66 in **stop mode** (W199 = 1).
- First write message,
- Second write message,
- etc.
- Unlock the Altivar 66 (W199 = 0).

Locking is refused if the motor is operating or if the configuration semaphore is reserved ([see the section entitled "Modifying the configuration" on the next page](#)).

When the speed controller is locked in stop mode :

- it is not possible to start the motor
- the configuration consistency check is inhibited.

Unlocking starts the configuration consistency test and enables the motor to be restarted.

Unlocking is refused when the configuration is invalid (W2049.1 = 1). If this occurs load a new configuration.

**Note :** if the configuration semaphore is free before locking, it is automatically reserved by the processor which locks it and is freed on unlocking.

During locking : only the locked processor can write the configuration.

it is not possible to enter a graphic keypad configuration menu.

To load a valid configuration, we recommend that you first read the value of the parameters, having first established a suitable configuration using the graphic keypad or the PC software.

Nonsignificant words are read at 8000H. Writing of nonsignificant words has no effect. If you have to write nonsignificant words to limit the number of messages when loading the configuration, they must be written at 8000H. This ensures that the configuration you have loaded will be compatible with future versions of ALTIVAR 66 software.

**Example :** the speed controller I/O are always assigned by default to functions (LI4 is assigned to JOG). If you wish to assign the preset speed function to LI4 you must :

- 1 - lock the controller
- 2 - disable the JOG function (W890 = 0)
- 3 - disable input LI4 (W891 = 0)
- 4 - enable the preset speed function (W830 = 1 ; W831 = 1)
- 5 - assign this function to LI4 (W832 = 4)

**Make sure that the resource (input / output) used for the new function is free. Otherwise, completely disable the function using this resource.**

## Invalid configuration

There are 4 main causes of invalid configurations :

- An incorrect parameter value,
- Two inputs or two outputs assigned to the same "application function" (brake control, etc.),
- Not all of the compulsory parameters forming a function have been configured,
- Several incompatible functions have been enabled.

In each case the speed controller adapts the configuration and changes to "invalid configuration" state.

# Communication principle

---

## Modifying the configuration

To make a simple modification to the configuration send a request to the Altivar 66 to :

- Write words,
- Write an object or a table.

Writing is refused :

- If the motor is operating (W2040.8 = 1),  
or
- If the configuration semaphore is reserved (W2049.3 = 1),
  - By another processor (W198 = 1 or W199 = 1 or W2049.1 = 1),
  - By the keypad in a configuration menu,
  - By OEM locking (W2049.2 = 1),
  - By local forcing (W2040.5 = 1).

The response is negative or exceptional if the configuration obtained is invalid.

[\(See section on "invalid configuration"\)](#)

## Configuration examples

1) Programming of the loss follower fault with skip to a frequency of 20 Hz.

Lock the configuration (W199 = 1).

Send the following 3 write requests :

W755,12 = 1 (function enabled)  
W767 = 200 (skip frequency)  
W768 = 1 (skip to frequency enabled)

Unlock the configuration.

2) Fast controlled stop via logic input :

Send a request to write an object to the following 4 words :

W920,0 = 1 enabling of controlled stop,  
W921 = 1 activation by logic input,  
W922 = 3 for LI3.  
W923 = 1 fast stop.

**Note** : remember to disable LI3 before assigning it.

3) Alternate ramps by frequency threshold :

Lock the configuration.

Send the following write requests :

W270 = 1 ramp switched,  
W271 = 0 linear ramp (acceleration),  
W274 = 0 linear ramp (deceleration),  
W277 = 1 switching by frequency threshold,  
W279 = 400 activation frequency threshold (400 x 0.1 or 40 Hz)  
W282 = 100 duration of second acceleration ramp (100 x 0.1 or 10 Hz)  
W283 = 100 duration of second deceleration ramp (100 x 0.1 or 10 Hz)

Unlock the configuration.

**Note** :

The configuration must be locked if the addresses are not consecutive.

# Communication principle

Before transmitting the PLC configuration to the speed controller, use the table below to check that the functions selected are compatible.

Table showing application functions which are not compatible

The ● indicates incompatibility

	RUN REVERSE	JOG	+ / - SPEED	SET POINT MEMORY	PRESET SPEEDS	SPEED REFERENCE	AUTO / MANUAL	CONTROLLED STOP	SHUTDOWN	TERMINAL / KEYPAD	BYPASS	BRAKE SEQUENCE	PI	SWITCH MOT. SEL/PAR.	TACH FEEDBACK	ORIENT	CYCLE	DOUBLE RAMP	
RUN REVERSE	■												●						
JOG		■							●				●						
+ / - SPEED			■	●	●								●					●	
SET POINT MEMORY			●	■	●		●						●	●		●			
PRESET SPEEDS			●	●	■								●					●	
SPEED REFERENCE						■							●						
AUTO / MANUAL				●			■						●						
CONTROLLED STOP								■				●	●	●		●			
SHUTDOWN		●							■			●	●	●		●	●		
TERMINAL / KEYPAD										■			●						
BYPASS											■						●	●	
BRAKE SEQUENCE								●	●			■	●						
PI	●	●	●	●	●	●	●		●	●		●	■		●	●	●	●	●
SWITCH MOT. SEL/PAR.				●				●	●					■		●			
TACH FEEDBACK													●		■				
ORIENT				●				●	●		●		●	●		■		●	
CYCLE			●		●				●		●		●				●	■	●
DOUBLE RAMP													●					●	■

# Communication principle

Table showing parameters which are not compatible

	Constant torque			Variable torque	
	NORMAL control	HIGH TORQUE control	SPECIAL control	NORMAL control	NOLD control
Nominal current					
Nominal frequency					
Nominal voltage					
IR compensation				•	•
Damping					
Rotation normalization : ABC					
Current limit					
Slip compensation				•	•
Brake sequence				•	•
Voltage boost	•			•	•
Motor torque limit	•		•	•	•
Generator torque limit	•		•	•	•
Bandwidth	•		•	•	•
Profile	•	•	•		•
Voltage reduction				•	•
Current limit adaptation	•	•	•		
Multimotor/PAR M1					
M2		•			
M3		•			

# Communication principle

---

## Controlling the speed controller

### Control mode

The Altivar 66 speed controller can be controlled in local mode via the terminal block or the graphic keypad, or remotely via the communication bus.

However, it is possible to control set points and logic commands of the controller separately.

The possible sources of commands are thus :

- Terminal block => local mode,
- Graphic keypad => local mode,
- Communication bus => total or partial line mode.

Menu 5 Keypad Config. is used to select the command source for local mode (see the product programming guide).

The communication bus can at any moment request that the control mode is changed by setting bits DLI and FLI of the command register :

DLI = 1 : partial line mode on the logic run commands, set points are enabled via the terminal block,

FLI = 1 : partial line mode on the set points, logic commands are enabled via the terminal block.

The control mode thus depends on both the state of bits DLI and FLI and the configuration of the keypad supplied with menu 5.


**Caution** : the STOP key on the graphic keypad and Run Permitted (LI1) are always active, irrespective of the current control mode. After a stop ordered by the keypad the bus is restarted on the rising edge of the Run bit of the command register (which changes from state 0 to state 1).

### Local forcing

It is possible to force operation to terminal block or keypad local mode (depending on the state of the T/K function).

Any write request or command received by the bus is thus prohibited. Only requests to read the configuration or monitoring parameters are permitted.

To do this, the Forced Local function in menu 7.2 must be configured or the F1 key of the keypad must be assigned to this function in menu 5.1.



NO : forced local not enabled

YES : selection of the associated logic input

**Local forcing via the terminal block** : activating the LI assigned to local forcing causes a switch to terminal block forced local mode. Logic commands and set points are taken via the terminal block. On exiting local forcing (deactivation of LI), the controller returns to the previous control mode, maintaining the operating direction.

**Local forcing via the graphic keypad** : pressing the F1 key assigned to local forcing causes a switch to keypad forced local mode. Logic commands and set points are taken at the keypad, the operating direction is maintained. On exiting local forcing (F1 pressed again), the controller returns to the previous control mode, maintaining the operating direction.

# Communication principle

## Switching between control modes

DLI	FLI	T/K	Current control mode depending on the state of the bits
0	0	0	Terminal block local
0	0	1	Graphic keypad local
0	1	0 or 1	Analog set point in line mode and terminal block logic command
1	0	0 or 1	Analog set point in term. block local mode and logic command in line mode
1	1	0 or 1	Total line

T/K : state of the terminal block/keypad configuration in local mode

DLI : state of the "on-line logic command" bit in word W2020,1

FLI : state of the "on-line set point" bit in word W2020,2

Switching between terminal block and keypad modes always causes the motor to stop.

Switching between local mode and line mode (total or partial) takes account of logic commands and set points of the new command source.

**Note** : whatever the current mode, if the logic input assigned to the Forced Local function is in a high state, or if the F1 key on the keypad is selected, the controller switches to Forced Local mode.

## Controlling the application functions via the bus, depending on the various control modes

Function which can be activated by the bus	DLI partial mode	FLI partial mode	Total line mode
Reverse operation	yes (W2031,1)	yes (sign of set point W2021)	yes
Jog	no	no	no
+ / - speed	no	no	no
Set point memory	no	no	no
Preset speeds	yes (W2031,4,5,6)	yes	no
Speed reference	no (value at terminal block)	yes (W2021)	yes (W2021)
Auto / Man	yes (W2031,2)	no	no
Controlled stop on threshold (always active if enabled)	no	no	no
Controlled stop by LI	yes	no	yes
Shutdown	yes	yes	yes
Bypass (always activated locally)	no	no	no
PI regulator	no	no	no
Switch motor / parameters	yes (W2020,11,12)	no	yes (W2020,11,12)
Stop command for orient (sensor input always on term. block)	yes (W2020,7 + ,5)	no	yes (W2020,7 + ,5)
Cycles	no	no	no
Double ramp switching	yes (W2020,3)	no	yes (W2020,3)
Default current limit (always active)	yes (config. word)	yes (W2024)	yes (W2024)
Current limit on freq. threshold	yes (config. word)	yes (W2024)	yes (W2024)
Current limit on LI	yes (config. word W265 + W2031,0)	yes (W2024)	yes (W2024 + W2031,0)

# Communication principle

---

## Controlling the application functions via the bus, depending on the various control modes (continued)

Function which can be activated by the bus	DLI partial mode	FLI partial mode	Total line mode
Current limit on AI	yes (value at terminal block)	yes (W2024)	yes (W2024)
Default voltage reduction	yes (config. word)	yes (W2028)	yes (W2028)
Voltage reduction on threshold	yes (config. word)	yes (W2028)	yes (W2028)
Voltage reduction on LI	yes (config. word : W2020,10)	yes (W2028)	yes (W2028 + W2020,10)
Voltage reduction on AI	yes (value at terminal block)	yes (W2028)	yes (W2028)
Default torque limit	yes (default value)	yes (W2025 + W2026)	yes (W2025 + W2026)
Torque limit on freq. threshold	yes (config. word)	yes (W2025 + W2026)	yes (W2025 + W2026)
Torque limit on LI	yes (config. word + W2031,3)	yes (W2025 + W2026)	yes (W2025 + W2026 + W2031,3)
Torque limit on AI	yes (value at terminal block)	yes (W2025 + W2026)	yes (W2025 + W2026)
Customer fault	yes (W2020,14)	no	yes (W2020,14)

## Checking the communication bus

Bit NTO of the command register (W2020,4) is used to inhibit the communication check.

If bit NTO = 1, the controller no longer takes account of communication errors from the communication bus or the serial link.

For safety reasons, this should only be used in the debug phase.

# Altivar 66 variables

---

## Altivar 66 variables

Certain Altivar 66 variables can be accessed at two different addresses :

- in the 200 to 3000 address zone reserved for the Altivar 66,
- in the 0 to 127 address zone already used by the Altivar 45.2.

1– Address zone reserved for the Altivar 66 (200 to 3000)

This address zone contains all the speed controller parameters for optimum use of the facilities of the Altivar 66.

2– Address zone (0 to 127) common to the Altivar 66 and the Altivar 45.2

This address zone should only be used when integrating an Altivar 66 into a control system which until now has only included Altivar 45.2 controllers. Not all of the Altivar 66 parameters appear here, in particular those functions available using the Altivar 66 but not the Altivar 45.2. In certain cases, using these addresses avoids the necessity of modifying the program.

Any small differences in comparison with the Altivar 45.2 are indicated in the comments.

## Range

The range permitted by the speed controller is specified for each parameter.

Writing of an incorrect value is always accepted, but will be automatically adjusted by the speed controller.

## Unit

Words are always expressed as integer values, either signed (-32768 to +32767) or unsigned (0 to 65535). The unit is defined for each of them.

Example : W2000 : high speed, unit = 0.1 Hz,

W2000 : 455 corresponds to high speed = + 45.5 Hz.

## Values on switching on

Each time it is switched on the Altivar 66 is initialized with the configuration and adjustments stored in its EEPROM memory.

# Altivar 66 variables

## ADJUSTMENT WORDS (read and write)

These parameters may be adjusted with the motor **stopped or running**.

WORD	RANGE	UNIT	DESCRIPTION	PRESET
W1993	0...9999		Proportional gain	100
W1994	0...9999		Integral gain	0
W1995	-9999...9999		Gain	9999
W1996	-4096...4096		Offset	0
W1997	0...9999		Fault ratio	100
W1998	0...9999		Keypad PI set point value	0
W1999	0...600	0.1Hz	Keypad speed reference value	0
W2000	W2001...W301	0.1Hz	High speed	
W2001	W*...W2000	0.1Hz	Low speed	
W2002	1...9999	0.1s	1st acceleration ramp time	3 s
W2003	1...9999	0.1s	1st deceleration ramp time	3 s
W2004	1...9999	0.1s	2nd acceleration ramp time	5 s
W2005	1...9999	0.1s	2nd deceleration ramp time	5 s
W2006	1...100	0.1Hz	Slip compensation : motor value	3 Hz
W2007	0...800 **	1 %	IR compensation	100 %
W2008	0...100	1 %	Profile	20 %
W2009	0...100	1 %	BOOST voltage	20 %
W2010	0...800 **	1 %	Damping	20 %
W2011	0...100	0.1%	Bandwidth	20 %
W2012	45%Invar...115%Invar	0.1 A	Thermal protection	Nominal motor current 1 (W214)

W\* = Max. between W247 and W250

\*\* Depends on torque type :

- High torque ..... 150
- Special ..... 800
- Other ..... 100

In Var : W2205.

# Altivar 66 variables

## COMMAND WORDS (read and write)

### Command register

WORD	DESCRIPTION	POSSIBLE VALUES
W2020	Speed controller reset	W2020,0 = 0 no request W2020,0 = 1 reset request
	Assignment of logic commands in line mode (DLI)	W2020,1 = 0 logic commands in local mode W2020,1 = 1 logic commands in line mode
	Assignment of set points in line mode (FLI)	W2020,2 = 0 set point in local mode W2020,2 = 1 set point in line mode
	Ramp 2 command	W2020,3 = 0 ramp 1 command W2020,3 = 1 ramp 2 command
	Communication check inhibited (NTO)	W2020,4 = 0 communication check activated W2020,4 = 1 communication check deactivated
	Start/Stop command (RUN)	W2020,5 = 0 stop request W2020,5 = 1 start request
	DC injection braking command (DCB)	W2020,6 = 0 no DC injection W2020,6 = 1 DC injection command
	Select orient stop	W2020,7 = 0 select orient stop W2020,7 = 1 select normal stop (warning : operation reversed compared to freewheel and fast stops)
	Select freewheel stop	W2020,8 see table below
	Select fast stop	W2020,9 see table below
	Voltage reduction command	W2020,10 = 0 no voltage reduction W2020,10 = 1 voltage reduction according to the commanded or configured value
	Select motor a	W2020,11 see table below
	Select motor b	W2020,12 see table below
	Reserved	W2020,13
	External fault command (EFL)	W2020,14 = 0 no external fault W2020,14 = 1 external fault present
Reserved	W2020,15	



**Important :** it is imperative to set the bits (1 and 2) of word W2020 to 1 to access the logic commands and the ATV set point via serial link.

It is necessary to activate L1 to start the motor.

The DLI and FLI bits are accepted first when writing.

Freewheel stop (W2020.8)	Fast stop (W2020.9)	Stop on stop request (W2020.5 = 0 → 1)
0	0	Normal stop
1	1	Freewheel stop
1	0	Freewheel stop
0	1	Fast stop

Select motor a (W2020.11)	Select motor b (W2020.12)	*	*
0	0	motor 1	1 parameter
1	0	motor 2	2 parameters
0	1	motor 3	3 parameters
1	1	No switching	No switching

\* Depending on the configuration selected (multiparameter or multimotor)

# Altivar 66 variables

## COMMAND WORDS (read and write)

### Additional command register

WORD	DESCRIPTION	POSSIBLE VALUES
W2031	Current limit command	W2031,0 = 0 default limit W2031,0 = 1 current limit depending on the configured or commanded value
	Operating direction	W2031,1 = 0 run forward W2031,1 = 1 run reverse
	Auto / man command	W2031,2 = 0 auto set point W2031,2 = 1 man set point
	Motor and generator torque limit command	W2031,3 = 0 default limit W2031,3 = 1 torque limit depending on the configured or commanded values
	Preset speeds selection a	W2031,4 see table below
	Preset speeds selection b	W2031,5 see table below
	Preset speeds selection c	W2031,6 see table below
	Reserved	W2031,7 -> W2031,15

Selection a	Selection b	Selection c	Number of preset speeds
0	0	0	no preset speed
1	0	0	1 preset speed
0	1	0	2 preset speeds
1	1	0	3 preset speeds
0	0	1	4 preset speeds
1	0	1	5 preset speeds
0	1	1	6 preset speeds
1	1	1	7 preset speeds

### Frequency set point in line mode

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W2021	-32767 .. 32767	-	frequency set point in line mode	26478 represents 400 Hz -26478 represents -400 Hz

### Current and torque limit and voltage reduction

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W2024	400...1500	0.1 %	Current limit value	value expressed as a % of the nominal motor current
W2025	0...200%	1 %	Motor torque limit value	
W2026	0...200%	1 %	Generator torque limit value	
W2027			Reserved	
W2028	20...100 %	1 %	Motor voltage reduction value	value expressed as a % of the nominal motor voltage

# Altivar 66 variables

## COMMAND WORDS (read and write)

### Analog and logic output command

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W2022			Reserved	W2022,0
			State of logic output LO1	W2022,1=0 low state W2022,1=1 high state
			State of logic output LO2	W2022,2=0 low state W2022,2=1 high state
			Reserved	W2022,3 and W2022,4
			State of output relay RO2	W2022,5=0 low state W2022,5=1 high state
			State of output relay RO3	W2022,6=0 low state W2022,1=1 high state
			State of output relay RO4	W2022,7=0 low state W2022,1=1 high state
W2023	0...4095		Value of output AO1	Depends on type of signal configured : 0 corresponds to 0 mA or 4 mA 4095 corresponds to 20 mA
W2029	0...4095		Value of output AO2	
W2030	0...4095		Value of output AO3	



Important : outputs LO, RO, and AO must be deactivated before use.

# Altivar 66 variables

## SIGNALLING WORDS (read-only)

### Status register

WORD	DESCRIPTION	POSSIBLE VALUES
W2040	All commands assigned in LOCAL mode	W2040,0 = 0 Commands assigned in line mode W2040,0 = 1 All commands assigned in local mode (terminal block or keypad)
	Speed controller ready (RDY or SLC)	W2040,1 = 0 Speed controller not ready W2040,1 = 1 Speed controller ready
	Faulty (FLT)	W2040,2 = 0 No speed controller fault W2040,2 = 1 Speed controller faulty
	Reset authorized	W2040,3 = 0 Reset not authorized W2040,3 = 1 Reset authorized
	Brake release relay energized	W2040,4 = 0 Brake release relay not energized W2040,4 = 1 Brake release relay energized
	Speed controller forced in LOCAL mode	W2040,5 = 0 Speed controller not forced W2040,5 = 1 Speed controller forced in LOCAL mode
	Communication check inhibited (NTO)	W2040,6 = 0 Communication fault monitoring W2040,6 = 1 No communication fault monitoring
	Resettable fault	W2040,7 = 0 Speed controller has no resettable fault W2040,7 = 1 Speed controller has resettable fault
	Motor running	W2040,8 = 0 Motor stopped W2040,8 = 1 Motor running
	Actual direction of rotation	W2040,9 = 0 Forward operation W2040,9 = 1 Reverse operation
	DC injection braking	W2040,10 = 0 No current injection W2040,10 = 1 Current injection in progress
	Steady state	W2040,11 = 0 Speed controller not in steady state W2040,11 = 1 Speed controller in steady state
	Motor thermal overload alarm	W2040,12 = 0 Speed controller has no motor overload fault W2040,12 = 1 Speed controller has motor overload fault
	Overbraking alarm	W2040,13 = 0 Speed controller has no DC bus overvoltage fault W2040,13 = 1 Speed controller has DC bus overvoltage fault
	Current limit	W2040,14 = 0 Speed controller not in current limit W2040,14 = 1 Speed controller in current limit
No power present (NLP)	W2040,15 = 0 Speed controller has no AC phase failure W2040,15 = 1 Speed controller has AC phase failure	

# Altivar 66 variables

## SIGNALLING WORDS (read-only)

### Complimentary status register

WORD	DESCRIPTION	POSSIBLE VALUES
W2047	Local control mode terminal block/keypad	W2047,0 = 0 Local control via terminal block W2047,0 = 1 Local control via keypad
	On line logic commands	W2047,1 = 0 On line logic commands not activated W2047,1 = 1 On line logic commands activated
	On line set point commands	W2047,2 = 0 On line set point commands not activated W2047,2 = 1 On line set point commands activated
	Dynamic braking (BRK)	W2047,3 = 0 Braking not active W2047,3 = 1 Braking active
	Fast stop in progress	W2047,4 = 0 Fast stop not in progress W2047,4 = 1 Fast stop in progress
	Controlled stop on loss of AC supply	W2047,5 = 0 Stop not in progress W2047,5 = 1 Stop in progress
	Output voltage deactivated freewheel stop	W2047,6 = 0 Power bridge controlled W2047,6 = 1 Power bridge not controlled
	Orient complete	W2047,7 = 0 Oriented stop is incomplete or not in progress W2047,7 = 1 Oriented stop is complete (function operates for 1 sec)
	Decelerating (DEC)	W2047,8 = 0 Speed controller not in deceleration phase W2047,8 = 1 Speed controller in deceleration phase
	Accelerating (ACC)	W2047,9 = 0 Speed controller not in acceleration phase W2047,9 = 1 Speed controller in acceleration phase
	Motor selection	W2047,10 State of motor selection or parameter set (a)
	Motor selection	W2047,11 State of motor selection or parameter set (b)
	Reserved	W2047,12
	Speed controller thermal alarm	W2047,13 = 0 Speed controller has no thermal overload fault W2047,13 = 1 Speed controller has thermal overload fault
	Reserved	W2047,14
Stopped via the keypad	W2047,15 = 0 Speed controller has not been stopped by keypad W2047,15 = 1 Speed controller has been stopped by keypad (valid from the deceleration phase)	

# Altivar 66 variables

## SIGNALLING WORDS (read-only)

### Complimentary status register

WORD	DESCRIPTION	POSSIBLE VALUES
W2048	JOG in progress	W2048,0 = 0 JOG function not in progress W2048,0 = 1 JOG function in progress
	Shutdown completed	W2048,1 = 0 Shutdown not completed W2048,1 = 1 Shutdown completed
	Cycle completed	W2048,2 = 0 Cycle function not completed W2048,2 = 1 Cycle function completed
	Ramp 2 in progress	W2048,3 = 0 Ramp 1 W2048,3 = 1 Ramp 2
	Auto/Man state	W2048,4 = 0 Manual activated W2048,4 = 1 Automatic activated
	Frequency threshold 1 reached	W2048,5 = 0 Frequency threshold 1 not reached W2048,5 = 1 Frequency threshold 1 reached
	Frequency threshold 2 reached	W2048,6 = 0 Frequency threshold 2 not reached W2048,6 = 1 Frequency threshold 2 reached
	Current threshold 1 reached	W2048,7 = 0 Current threshold 1 not reached W2048,7 = 1 Current threshold 1 reached
	Current threshold 2 reached	W2048,8 = 0 Current threshold 2 not reached W2048,8 = 1 Current threshold 2 reached
	Thermal threshold 1 reached	W2048,9 = 0 Thermal threshold 1 not reached W2048,9 = 1 Thermal threshold 1 reached
	Thermal threshold 2 reached	W2048,10 = 0 Thermal threshold 2 reached W2048,10 = 1 Thermal threshold 2 reached
	No ramp follow	W2048,11 = 0 Ramp follow W2048,11 = 1 No ramp follow
	External contactor in active state	W2048,12 = 0 Contactor not activated (Bypass mode) W2048,12 = 1 Contactor activated (Bypass mode)
	Direction of rotation requested	W2048,13 = 0 Forward operation W2048,13 = 1 Reverse operation

WORD	DESCRIPTION	POSSIBLE VALUES
W2049	Speed controller locked when stopped	W2049,0 = 0 Speed controller not locked when stopped W2049,0 = 1 Speed controller locked when stopped
	Invalid configuration	W2049,1 = 0 Valid configuration W2049,1 = 1 Invalid configuration
	OEM access protection indicator	W2049,2 = 0 not protected W2049,2 = 1 protected
	State of configuration semaphore	W2049,4 = 0 Semaphore free W2049,4 = 1 Semaphore reserved
	State of command semaphore	W2049,5 = 0 Semaphore free W2049,5 = 1 Semaphore reserved

# Altivar 66 variables

## SIGNALLING WORDS (read-only)

### Register of faults

WORD	POSSIBLE VALUES
W2050	<ul style="list-style-type: none"> <li>= 0 No fault</li> <li>= 1 AC line overvoltage</li> <li>= 2 DC bus overvoltage</li> <li>= 3 DC bus undervoltage</li> <li>= 4 Ground fault</li> <li>= 5 Phase short-circuit</li> <li>= 6 ± 15 V supply</li> <li>= 7 Rating not recognized</li> <li>= 8 AC supply phase failure</li> <li>= 9 Motor overload</li> <li>= 10 Customer fault</li> <li>= 11 Speed controller thermal overload</li> <li>= 12 Overspeed</li> <li>= 13 Tachogenerator feedback loss</li> <li>= 14 Serial link loss</li> <li>= 15 Loss follower</li> <li>= 16 Memory failure</li> <li>= 17 DC bus load</li> <li>= 18 Isolation timeout (Bypass)</li> <li>= 19 Process timeout (Bypass)</li> <li>= 20 DB resistor absent</li> <li>= 21 DB resistor thermal protection</li> <li>= 22 Transistor short-circuit</li> <li>= 23 Open transistor</li> <li>= 24 Output phase loss</li> <li>= 25 Control card supply</li> <li>= 26 Peak current limit</li> <li>= 27 Reserved</li> <li>= 28 Disconnection of an I/O card</li> <li>= 29 Backdriving fault</li> </ul>

### Register of faults present (bit at 1 : fault present)

WORD	POSSIBLE VALUES
W2051	<ul style="list-style-type: none"> <li>W2051,0 Unlisted internal + other ATV66 fault</li> <li>W2051,1 Serial link break</li> <li>W2051,2 Reserved</li> <li>W2051,3 Reserved</li> <li>W2051,4 DC bus undervoltage</li> <li>W2051,5 AC supply overvoltage</li> <li>W2051,6 In-phase loss</li> <li>W2051,7 Speed controller overtemperature</li> <li>W2051,8 Speed feedback not present, overspeed</li> <li>W2051,9 Phase short-circuit or ground short-circuit</li> <li>W2051,10 DC bus overvoltage</li> <li>W2051,11 Reserved</li> <li>W2051,12 Motor overload</li> <li>W2051,13 Output phase loss</li> <li>W2051,14 Reserved</li> <li>W2051,15 Precharge failure</li> </ul>

# Altivar 66 variables

## SIGNALLING WORDS (read-only)

WORD	DESCRIPTION	POSSIBLE VALUES
W2140	Indicates position of marker on 1 of the 8 past faults	from 0 to 9
W2141	Past fault 1 : speed controller status	= 0 No fault
W2143	Past fault 2 : speed controller status	= 1 Acceleration
W2145	Past fault 3 : speed controller status	= 2 Deceleration
W2147	Past fault 4 : speed controller status	= 3 Steady state
W2149	Past fault 5 : speed controller status	= 4 Dynamic braking
W2151	Past fault 6 : speed controller status	= 5 Ready
W2153	Past fault 7 : speed controller status	= 6 DC injection
W2155	Past fault 8 : speed controller status	= 7 Current limit
		= 8 Reserved
		= 9 Reserved
		=10 Locking on run permitted
		=11 Faulty
		=12 Jog
W2142	Past fault 1 : fault name	= 0 No fault
W2144	Past fault 2 : fault name	= 1 AC supply overvoltage
W2146	Past fault 3 : fault name	= 2 DC bus overvoltage
W2148	Past fault 4 : fault name	= 3 DC bus undervoltage
W2150	Past fault 5 : fault name	= 4 Earth fault
W2152	Past fault 6 : fault name	= 5 Phase short-circuit
W2154	Past fault 7 : fault name	= 6 Power supply $\pm 15$ V
W2156	Past fault 8 : fault name	= 7 Rating not recognized
		= 8 One phase missing
		= 9 Motor overload
		= 10 User fault
		= 11 Speed controller thermal overload
		= 12 Overspeed
		= 13 Tachogenerator feedback loss
		= 14 Serial link loss
		= 15 Loss of 4-20 mA current input
		= 16 Memory fault
		= 17 DC bus load
		= 18 Isolation timeout (Bypass)
		= 19 Process timeout (Bypass)
		= 20 Braking resistor missing
		= 21 Thermal protection of braking resistor
		= 22 Transistor short-circuit
		= 23 Transistor open
		= 24 Motor phase fault
		= 25 Control card supply
		= 26 Peak current limit
		= 27 Reserved
		= 28 Disconnection of an I/O card
		= 29 Back driving fault

# Altivar 66 variables

## SIGNALLING WORDS (read-only)

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W2041	-32768...32767		Output frequency	400 Hz = 26478
W2042		0.1 A	Output current	
W2052		0.1 kW	Output power	
W2053		1 V	Output voltage	
W2054		1 V	Supply voltage	
W2055		1 V	Bus voltage	
W2056		1 %	Motor thermal state value	
W2057		1 %	Speed controller thermal state value	For rating > 7.5 kW
W2058		H	Motor running time elapsed (hours)	Total time = W2058, W2059
W2059		min	Motor running time elapsed (minutes)	
W2060		rpm	Output speed	
W2061			Machine speed reference (customer unit)	Frequency set point x scale factor (W734)
W2062			Machine frequency (customer unit)	Output frequency x scale factor (W734)

# Altivar 66 variables

## SIGNALLING WORDS (read-only)

WORD	RANGE	UNIT	DESCRIPTION	COMMENTS
W2074	0...2		No. of motor running or set parameter number	= 0 Motor 1 = 1 Motor 2 = 2 Motor 3
W2075	1...8		Current cycle step	= 1 step 1 = 2 step 2 = 3 step 3 = 4 step 4 = 5 step 5 = 6 step 6 = 7 step 7 = 8 step 8
W2076	0...7		Current preset speed number	= 0 set point = 1 preset speed 1 = 2 preset speed 2 = 3 preset speed 3 = 4 preset speed 4 = 5 preset speed 5 = 6 preset speed 6 = 7 preset speed 7

\* Depending on the configuration selected (either multimotor, or multiparameter).

WORD	RANGE	DESCRIPTION	POSSIBLE VALUES
W2200	0...22	Commercial rating for speed controller in constant torque	= 0 Not significant = 1 Reserved = 2 Reserved = 3 Speed controller 2.2 kW - 3 HP = 4 Speed controller 3 kW - 4 HP = 5 Speed controller 4 kW - 5 HP = 6 Speed controller 5.5 kW - 7.5 HP = 7 Speed controller 7.5 kW - 10 HP = 8 Speed controller 11 kW - 15 HP = 9 Speed controller 15 kW - 20 HP = 10 Reserved = 11 Speed controller 22 kW - 30 HP = 12 Speed controller 30 kW - 40 HP = 13 Speed controller 37 kW - 50 HP = 14 Speed controller 45 kW - 60 HP = 15 Speed controller 55 kW - 75 HP = 16 Speed controller 75 kW - 100 HP = 17 Speed controller 90 kW - 125 HP = 18 Speed controller 110 kW - 150 HP = 19 Speed controller 132 kW - 200 HP = 20 Speed controller 160 kW - 250 HP = 21 Speed controller 200 kW - 300 HP = 22 Speed controller 220 kW - 350 HP = 23 Reserved

# Altivar 66 variables

## SIGNALLING WORDS (read-only)

WORD	RANGE	UNIT	DESCRIPTION	COMMENTS
W2201	0...23		Configured speed controller rating	Same as previous rating with = 1 Speed controller 0.75 kW - 1HP = 2 Speed controller 1.5 kW - 2 HP = 10 Speed controller 18.5 kW - 20 HP = 23 Speed controller 250 kW - 400 HP
W2202			Speed controller voltage range	= 0 Not significant = 1 Voltage 208 - 240 V = 2 Voltage 380 - 460 V
W2203			AC frequency recognized or not	= 0 Not known = 1 50 Hz = 2 60 Hz
W2205		0.1A	Altivar nominal current	Depending on the rating, AC voltage and torque type
W2206		0.1A	Speed controller maximum current	Depending on the rating, AC voltage and torque type
W2071			Motor nominal voltage	= 0 Voltage 208 - 240 V = 1 Voltage 380 - 415 V = 2 Voltage 440 - 460 V

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W2211	0...1		Memory card present	= 0 Absent = 1 Present
W2212	0...1		Communication Interface Option	= 0 Non connected = 1 Connected
W2213	0...1		Graphic keypad present	= 0 Non connected = 1 Connected
W2214	0...3		I/O option present	= 0 No option = 1 24 V DC option card = 2 115 V AC option card
W2216	-1...5		PCMCIA communication card type	= 0 No option = 1 UNI-TELWAY / Modbus/Jbus = 2 Reserved = 3 FIP I/O = 4 Modbus + = 5 INTERBUS S = -1 Unknown option

# Altivar 66 variables

## SIGNALLING WORDS (read-only)

WORD	DESCRIPTION	POSSIBLE VALUES
W2043	Display of activation of LI1	W2043,1 = 0 Input inactive W2043,1 = 1 Input active
	Display of activation of LI2	W2043,2 = 0 Input inactive W2043,2 = 1 Input active
	Display of activation of LI3	W2043,3 = 0 Input inactive W2043,3 = 1 Input active
	Display of activation of LI4	W2043,4 = 0 Input inactive W2043,4 = 1 Input active
	Display of activation of LI5	W2043,5 = 0 Input inactive W2043,5 = 1 Input active
	Display of activation of LI6	W2043,6 = 0 Input inactive W2043,6 = 1 Input active
	Display of activation of LI7	W2043,7 = 0 Input inactive W2043,7 = 1 Input active
	Display of activation of LI8	W2043,8 = 0 Input inactive W2043,8 = 1 Input active
	Display of activation of LO1	W2043,9 = 0 Input inactive W2043,9 = 1 Input active
	Display of activation of LO2	W2043,10 = 0 Input inactive W2043,10 = 1 Input active
	Display of activation of R1	W2043,11 = 0 Input inactive W2043,11 = 1 Input active
	Display of activation of R2	W2043,12 = 0 Input inactive W2043,12 = 1 Input active
	Display of activation of R3	W2043,13 = 0 Input inactive W2043,13 = 1 Input active
	Display of activation of R4	W2043,14 = 0 Input inactive W2043,14 = 1 Input active

# Altivar 66 variables

## SIGNALLING WORDS (read-only)

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W2044	0...100	1 %	Value of analog input AI1	0% for 0 V and 100 % for 10 V
W2063	0...100	1 %	Value of analog input AI2	0% for 0 mA and 100 % for 20 mA
W2064	0...100	1 %	Value of analog input AI3	0% for 0 V and 100 % for 10 V
W2065	0...100	1 %	Value of analog input AI4	0% for 0 mA and 100 % for 20 mA
W2100			Assignment of analog input AI1  (preset)	= 0 Not assigned = 1 Current limit = 2 Voltage reduction = 3 Frequency set point a = 4 Frequency set point b = 5 Frequency set point c = 8 PI Man set point = 9 Sensor feedback = 10 PI set point = 11 Torque limit
W2101			Assignment of analog input AI2  (preset)	= 0 Not assigned = 1 Current limit = 2 Voltage reduction = 3 Frequency set point a = 4 Frequency set point b = 5 Frequency set point c = 8 PI Man set point = 9 Sensor feedback = 10 PI set point = 11 Torque limit
W2102			Assignment of analog input AI3	= 0 Not assigned (preset without I/O) = 1 Current limit = 2 Voltage reduction = 3 Frequency set point a = 4 Frequency set point b = 5 Frequency set point c (preset with I/O) = 6 Tachogenerator speed feedback = 8 PI Man set point = 9 Sensor feedback = 10 PI set point = 11 Torque limit
W2103			Assignment of analog input AI4	= 0 Not assigned (preset) = 1 Current limit = 2 Voltage reduction = 3 Frequency set point a = 4 Frequency set point b = 5 Frequency set point c = 8 PI Man set point = 9 Sensor feedback = 10 PI set point = 11 Torque limit



# Altivar 66 variables

## SIGNALLING WORDS (read-only)

### *Display of assignment of logic outputs*

WORD	DESCRIPTION	POSSIBLE VALUES
W2107	Preset assignment of LO1 : set point reached	= 0 No assignment
W2108	Preset assignment of LO2 : current limit	= 1 Speed controller ready
W2111	Preset assignment of R1 : fault	= 2 Run
W2112	Preset assignment of R2 : run	= 3 Set point reached
W2113	Preset assignment of R3 : thermal state level 1	= 4 Forward operation
W2114	Preset assignment of R4 : speed controller ready	= 5 Reverse operation = 6 Graphic keypad command = 7 Auto / Man : automatic position = 8 Current limit = 9 Torque limit = 10 Fault = 11 Speed controller thermal alarm = 12 Loss of AI2 = 13 No ramp follow = 14 TACH feedback fault = 15 Overspeed (frequency) = 16 Frequency threshold 1 reached = 17 Frequency threshold 2 reached = 18 Current threshold 1 reached = 19 Current threshold 2 reached = 20 Thermal threshold 1 reached = 21 Thermal threshold 2 reached = 22 Reserved = 23 Braking command = 24 Shutdown completed = 25 Orient complete = 26 Cycle complete = 27 Cycle fault = 28 Run command signal (BYPASS) = 29 JOG in progress = 30 Reserved = 31 Reserved = 32 PI error exceeded = 33 PI max error exceeded = 34 PI min error exceeded

# Altivar 66 variables

## SIGNALLING WORDS (read-only)

### Display of assignment of logic inputs

WORD	DESCRIPTION	POSSIBLE VALUES
W2115	Assignment of LI1 : Stop (not reconfigurable)	Depends on the 2-wire / 3-wire configuration = 1 Stop (not reconfigurable) = 2 Run (not reconfigurable)
W2116	Assignment of LI2 : Forward operation (not reconfigurable)	= 3 Forward operation (not reconfigurable)
W2117	Assignment of LI3 : Reverse operation	= 0 Not assigned
W2118	Assignment of LI4 : JOG	= 4 Reverse operation
W2119	Assignment of LI5 : Preset speed a	= 5 Current limit
W2120	Assignment of LI6 : Preset speed b	= 6 Voltage reduction
W2121	Assignment of LI7 : Preset speed c	= 7 Ramp switching
W2122	Assignment of LI8 : Fault reset	= 8 JOG
		= 9 + speed = 10 - speed = 11 Controlled stop = 12 Start cycle with I/O card = 13 Reset cycle with I/O card = 14 Cycle blocked with I/O card = 15 Cycle next stop with I/O card = 16 Set point memory = 17 Preset speed a command = 18 Preset speed b command = 19 Preset speed c command with I/O card = 20 Indexing command with I/O card = 21 Indexing pulse with I/O card = 22 Local control = 23 Auto/man = 24 Terminal block/keypad = 25 Input assigned to process (Bypass) = 26 Input assigned to starting (Bypass) = 27 Parameter selection / motor a = 28 Parameter selection / motor b = 29 Customer fault = 30 Reset fault (RAZ fault) = 31 Run Auto = 32 Reserved = 33 Auto/Man (PI) = 34 Reverse direction (PI) = 35 Reserved = 36 Torque limit

# Altivar 66 variables

## CONFIGURATION WORDS (read and write)

### Access to variables management

#### *Semaphores and locking when stopped*

WORD	RANGE	DESCRIPTION	COMMENTS
W198		Configuration semaphore	0 = Free 1 = Reserved
W199		Speed controller locked when stopped	0 = Not locked 1 = Locked
W2235		Command semaphore	0 = Free 1 = Reserved

[See section "Communication principle"](#)

#### *Access to speed controller adjustments*

WORD	RANGE	UNIT	DESCRIPTION	COMMENTS
W748			Type of access to speed controller data via keypad	0 = Partial access 1 = Total access

# Altivar 66 variables

## CONFIGURATION WORDS (read and write)

### Basic configuration of speed controller and motor

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W211			Motor nominal frequency type	= 0 Frequency 50 Hz = 1 Frequency 60 Hz = 2 Special frequency

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W212	25...Fmax VAR	1Hz	Motor nominal frequency	

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W301	W212...Fmax VAR	0.1Hz	Motor maximum frequency	

#### High speed

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W302	W303...W301	0.1Hz	High speed	50 Hz if 50 Hz supply 60 Hz if 60 Hz supply

#### Low speed

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W303	0...W302	0.1Hz	Low speed	Preset at 0.0 Hz

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W213			Motor nominal voltage	= 0 Nominal voltage 208 V = 1 Nominal voltage 220 V = 2 Nominal voltage 230 V = 3 Nominal voltage 240 V = 4 Nominal voltage 380 V
			Preset supply voltage	= 5 Nominal voltage 400 V = 6 Nominal voltage 415 V = 7 Nominal voltage 440 V
			Preset 50Hz supply	= 8 Nominal voltage 460 V
			Preset 60 Hz supply	

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W214	45% Inom VAR 105% Inom VAR	0.1A	Motor nominal current	Preset at In 0.9 speed controller

VAR nominal current depends on the torque type, supply frequency, speed controller rating and motor rating  
F max VAR :

Constant torque : 400 Hz for Altivar 66 U41N4 to D79N4  
Altivar 66 U41M2 to D46M2  
200 Hz for Altivar 66 C10N4 to C31N4

Variable torque : 75/90 Hz (50 Hz/60Hz supply)

WORD	RANGE	UNIT	DESCRIPTION
W219	300...24000	rpm	Motor nominal speed configuration

\* When the multi-motor function is being used, nominal speed configuration by motor 2 is done via word W419 and for motor 3 via word W619.

# Altivar 66 variables

## CONFIGURATION WORDS (read and write)

### Basic configuration of speed controller and motor

WORD	DESCRIPTION	POSSIBLE VALUES
W200	2- or 3-wire control	= 0 2-wire control (preset) = 1 3-wire control
W201	Torque type	= 0 Constant torque (preset) = 1 Variable torque = 2 Low noise variable torque
W206	Control type	= 0 Normal control (preset) = 1 NOLD control = 2 High torque control = 3 Special motor control
W202	Motor power Only applicable to U41 rating (preset)	= 1 Motor 0.75 kW - 1 HP = 2 Motor 1.5 kW - 2 HP = 3 Motor 2.2 kW - 3 HP
W210	Direction of phase rotation	W210,1 = 0 Phase rotation ABC (preset) W210,1 = 1 Phase rotation ACB

### Configuration of torque limit

WORD	RANGE	UNIT	DESCRIPTION	COMMENTS
W320			Torque limit type	= 0 Torque limit by fault = 1 Torque limit by logic input = 2 Torque limit by analog input
W321			Torque limit assignment of activating logic input	= 0 No logic input assigned = 1 Reserved = 2 Reserved = 3 Logic input LI3 on basic product = 4 Logic input LI4 on basic product = 5 Logic input LI5 (I/O card) = 6 Logic input LI6 (I/O card) = 7 Logic input LI7 (I/O card) = 8 Logic input LI8 (I/O card)
W322			Torque limit assignment of activating analog input	= 0 No analog input assigned = 1 Analog input AI1 = 2 Analog input AI2 = 3 Analog input AI3 (I/O card) = 4 Analog input AI4 (I/O card)
W215 or W323	0...200	1%	Torque limit in generator phase	Only in constant torque HIGH TORQUE (preset at 200%)
W216 or W324	0...200	1%	Torque limit in motor phase	Only in constant torque HIGH TORQUE (preset at 200%)

# Altivar 66 variables

## CONFIGURATION WORDS (read and write)

### Configuration of slip compensation

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W225			Enabling of slip compensation	W225,0 = 0 Function not enabled W225,0 = 1 Function enabled
W226			Slip compensation type (preset)	= 0 No compensation = 1 Automatic compensation = 2 Manual compensation
W227	1..100	0.1Hz	Slip compensation value	Preset at 3.0 Hz

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W228	0...IR Comp max	1%	IR compensation value	Only for constant torque, preset at 100%

Max IR comp : Depends on control type :

- High torque...150 %
- Special...800 %
- Normal...100 %

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W229	0...100	1%	Profile	Only for variable torque and if NORMAL has been selected (preset at 20 %)

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W230	0...100	1%	Voltage boost	Only for constant torque HIGH TORQUE or SPECIAL (preset at 20%)

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W231	1...Stab max	1%	Damping	Preset at 20%

Max. damping : 800 % for Normal control variable torque and Special control constant torque  
100 % otherwise

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W232	0...100	1%	Bandwidth	Only for constant torque control HIGH TORQUE (preset at 20%)

# Altivar 66 variables

## CONFIGURATION WORDS (read and write)

### Configuration of braking sequence

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W245			Enabling of braking sequence	W245,0 = 0 Function not enabled (preset) W245,0 = 1 Function enabled
W246			Brake control logic output	= 0 No logic output assigned = 1 Logic output LO1 = 2 Logic output LO2 = 3 Reserved = 4 Logic output R2 = 5 Logic output R3 (I/O card) = 6 Logic output R4 (I/O card)
W247	0...W303	0.1Hz	Brake dwell frequency	From 0 to LS (low speed) Preset at 0 Hz
W248	0...W214	0.1 A	Brake dwell current level	From 0 to In (In = motor nominal current) Preset at 0 A
W249	0...50	0.1s	Brake dwell time	Preset at 0.0 s
W250	0...W303	0.1Hz	Brake release frequency	Preset at 0.0 Hz
W251	0...50	0.1s	Brake release time	Preset at 0.0 s
W252	50...150	1%	DC injection level	Preset at 70 %
W253	0...301	0.1s	DC injection time	Preset at 2 s

### Summary of analog inputs

WORD	RANGE	DESCRIPTION	POSSIBLE VALUES
W810		Limitation to 0 of the summing of analog inputs assigned to the frequency set point	W810,2 = 0 Function not enabled W810,2 = 1 Function enabled (preset)
W811		Analog input : frequency set point «a»	= 0 No analog input = 1 Analog input AI1 (preset) = 2 Analog input AI2 = 3 Analog input AI3 (I/O card) = 4 Analog input AI4 (I/O card)
W812		Analog input : frequency set point «b»	= 0 No analog input = 1 Analog input AI1 = 2 Analog input AI2 (preset) = 3 Analog input AI3 (I/O card) = 4 Analog input AI4 (I/O card)
W813		Analog input : frequency set point «c»	= 0 No analog input (preset) = 1 Analog input AI1 = 2 Analog input AI2 = 3 Analog input AI3 (I/O card) = 4 Analog input AI4 (I/O card) (preset)

# Altivar 66 variables

## CONFIGURATION WORDS (read and write)

### Configuration of current limit

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W260			Enabling of current limit	W260,0 = 0 Function not enabled (preset) W260,0 = 1 Function enabled
W261			Current limit type	= 0 No current limit (preset) = 1 Limit via frequency level = 2 Limit via logic input = 3 Limit via analog input
W262			Logic input to activate current limit	= 0 No logic input assigned = 1 Reserved = 2 Reserved = 3 Logic input LI3 on basic product = 4 Logic input LI4 on basic product = 5 Logic input LI5 (I/O card) = 6 Logic input LI6 (I/O card) = 7 Logic input LI7 (I/O card) = 8 Logic input LI8 (I/O card)
W263			Analog input for current limit	= 0 No analog input = 1 Analog input AI1 = 2 Analog input AI2 = 3 Analog input AI3 (I/O card) = 4 Analog input AI4 (I/O card)
W264	0... Fmax VAR	0.1Hz	Activation frequency level	Preset at 60 Hz if 60 Hz supply 50 Hz if 50 Hz supply
W265	40 % of I nom VAR ...I xx	0.1A	Limit current	I xx depends on torque type selected, supply frequency and speed controller rating Constant torque 60Hz ⇒ 150 %. I nom ATV Constant torque 50Hz ⇒ 136 %. I nom ATV Variable torque ⇒ 110 %. I nom ATV

# Altivar 66 variables

## CONFIGURATION WORDS (read and write)

### Configuration of acceleration and deceleration

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W270			Enabling of ramp switching (alternate ramp)	W270,0 = 0 Function not enabled (preset) W270,0 = 1 Function enabled
W271			Acceleration type	= 0 Linear ramp (preset) = 1 S ramp = 2 U ramp
W272	0...100	1%	Rounding coefficient for S acceleration ramps	Preset at 20 %
W273	0...100	1%	Rounding coefficient for U acceleration ramps	Preset at 50 %
W274			Deceleration type	= 0 Linear ramp (preset) = 1 S ramp = 2 U ramp
W275	0...100	1%	Rounding coefficient for S deceleration ramps	Preset at 20 %
W276	0...100	1%	Rounding coefficient for U deceleration ramps	Preset at 50 %
W277			Ramp switching type (alternate ramp)	= 0 Not assigned (preset) = 1 Switching by frequency level = 2 Switching by logic input
W278			Logic input for ramp switching	= 0 No logic input (preset) = 1 Reserved = 2 Reserved = 3 Logic input LI3 on basic product = 4 Logic input LI4 on basic product = 5 Logic input LI5 (I/O card) = 6 Logic input LI6 (I/O card) = 7 Logic input LI7 (I/O card) = 8 Logic input LI8 (I/O card)
W279	0...Fmax VAR	0.1Hz	Activation frequency level	Preset at 30.0 Hz
W280	1...9999	0.1s	Duration of first acceleration ramp	Preset at 3.0 s
W281	1...9999	0.1s	Duration of first deceleration ramp	Preset at 3.0 s
W282	1...9999	0.1s	Duration of second acceleration ramp	Preset at 5.0 s
W283	1...9999	0.1s	Duration of second deceleration ramp	Preset at 5.0 s

### Configuration of skip frequencies

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W290			Skip frequency range 1	W290,1 = 0 2 Hz (default) W290,1 = 1 5 Hz
			Skip frequency range 2	W290,2 = 0 2 Hz (default) W290,2 = 1 5 Hz
			Skip frequency range 3	W290,3 = 0 2 Hz (default) W290,3 = 1 5 Hz
W291	0...Fmax VAR	0.1Hz	Skip frequency value 1	Preset at 0.0 Hz
W292	0...Fmax VAR	0.1Hz	Skip frequency value 2	Preset at 0.0 Hz
W293	0...Fmax VAR	0.1Hz	Skip frequency value 3	Preset at 0.0 Hz

# Altivar 66 variables

## CONFIGURATION WORDS (read and write)

### Configuration of reverse operation function

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W880			Enabling of reverse function	W880,0 = 0 Function not enabled W880,0 = 1 Function enabled (preset)
W881			Logic input for enabling Run / Reverse  Preset	= 0 No logic input assigned = 1 Reserved = 2 Reserved = 3 Logic input LI3 on basic product = 4 Logic input LI4 on basic product = 5 Logic input LI5 (I/O card) = 6 Logic input LI6 (I/O card) = 7 Logic input LI7 (I/O card) = 8 Logic input LI8 (I/O card)

### Configuration of JOG function

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W890			Enabling of JOG function	W890,0 = 0 Function not enabled W890,0 = 1 Function enabled (preset)
W891			Logic input for JOG activation  Preset	= 0 No logic input assigned = 1 Reserved = 2 Reserved = 3 Logic input LI3 on basic product = 4 Logic input LI4 on basic product = 5 Logic input LI5 (I/O card) = 6 Logic input LI6 (I/O card) = 7 Logic input LI7 (I/O card) = 8 Logic input LI8 (I/O card)
W892			Logic output for signalling enabling of JOG	= 0 No logic output assigned (preset) = 1 Logic output LO1 = 2 Logic output LO2 = 3 Reserved = 4 Logic output R2 = 5 Logic output R3 (I/O card) = 6 Logic output R4 (I/O card)
W893	2...100	0.1Hz	JOG set point frequency	Preset at 5.0 Hz
W894	2...100	0.1s	Dead time between two JOG pulses	Preset at 0.5 s

# Altivar 66 variables

## CONFIGURATION WORDS (read and write)

### Configuration of + speed / - speed function

WORD	DESCRIPTION	POSSIBLE VALUES
W820	Enabling of + speed / - speed function	W820,0 = 0 Function not enabled (preset) W820,0 = 1 Function enabled
W821	Type of + / - speed	= 0 Function not enabled (preset) = 1 Enabling with memorization of speed reference = 2 Enabling without memorization of speed reference
W822	Logic input for - speed	= 0 No logic output assigned (preset) = 1 Reserved = 2 Reserved = 3 Logic input LI3 on basic product = 4 Logic input LI4 on basic product = 5 Logic input LI5 (I/O card) = 6 Logic input LI6 (I/O card) = 7 Logic input LI7 (I/O card) = 8 Logic input LI8 (I/O card)
W823	Logic input for + speed	= 0 No logic output assigned (preset) = 1 Reserved = 2 Reserved = 3 Logic input LI3 on basic product = 4 Logic input LI4 on basic product = 5 Logic input LI5 (I/O card) = 6 Logic input LI6 (I/O card) = 7 Logic input LI7 (I/O card) = 8 Logic input LI8 (I/O card)

# Altivar 66 variables

## CONFIGURATION WORDS (read and write)

### Configuration of preset speeds

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W830			Enabling of preset speeds	W830,0 = 0 Function not enabled (preset) W830,0 = 1 Function enabled (preset with I/O option)
W831			Choice of number of preset speeds	= 0 No preset speed (preset) = 1 One preset speed = 2 Three preset speeds = 3 Seven preset speeds (preset with I/O option)
W832			Select via logic input (a)	= 0 No logic input assigned (preset) = 1 Reserved = 2 Reserved = 3 Logic input LI3 on basic product = 4 Logic input LI4 on basic product (preset) = 5 Logic input LI5 (I/O card) preset : (a) with I/O card = 6 Logic input LI6 (I/O card) preset : (b) with I/O card = 7 Logic input LI7 (I/O card) preset : (c) with I/O card = 8 Logic input LI8 (I/O card)
W833			Select via logic input (b)	
W834			Select via logic input (c)	
W835	0...Fmax VAR	0.1Hz	Speed 1 value	Preset at 5.0 Hz
W836	W835...Fmax VAR	0.1Hz	Speed 2 value	Preset at 10.0 Hz
W837	W836...Fmax VAR	0.1Hz	Speed 3 value	Preset at 15.0 Hz
W838	W837...Fmax VAR	0.1Hz	Speed 4 value	Preset at 20.0 Hz
W839	W838...Fmax VAR	0.1Hz	Speed 5 value	Preset at 25.0 Hz
W840	W839...Fmax VAR	0.1Hz	Speed 6 value	Preset at 30.0 Hz
W841	W840...Fmax VAR	0.1Hz	Speed 7 value	Preset at 35.0 Hz

F max VAR :

Constant torque : 400 Hz for Altivar 66 U41N4 to D79N4  
Altivar 66 U41M2 to D46M2  
200 Hz for Altivar 66 C10N4 to C31N4

Variable torque : 75/90 Hz (50 Hz/60Hz supply)



The value of preset speed 1 must be less than the value of preset speed 2, which must be less than the value of preset speed 3, which must be less than the value of preset speed 4, which must be less than the value of preset speed 5, which must be less than the value of preset speed 6, which must be less than the value of preset speed 7, whatever the number of preset speeds.

# Altivar 66 variables

## CONFIGURATION WORDS (read and write)

### Configuration of Auto/Man function

WORD	DESCRIPTION	POSSIBLE VALUES
W860	Auto/Man	W860, 0 = 0 Not enabled (preset) W860, 0 = 1 Enabled via logic input
W861	Auto / manual switching logic input	= 0 No logic input assigned (preset) = 1 Reserved = 2 Reserved = 3 Logic input LI3 on basic product = 4 Logic input LI4 on basic product = 5 Logic input LI5 (I/O card) = 6 Logic input LI6 (I/O card) = 7 Logic input LI7 (I/O card) = 8 Logic input LI8 (I/O card)
W862	Automatic run logic input	= 0 No logic input assigned (preset) = 1 Reserved = 2 Reserved = 3 Logic input LI3 on basic product = 4 Logic input LI4 on basic product = 5 Logic input LI5 (I/O card) = 6 Logic input LI6 (I/O card) = 7 Logic input LI7 (I/O card) = 8 Logic input LI8 (I/O card)

### Configuration of local forcing

WORD	RANGE	UNIT	DESCRIPTION	COMMENTS
W910			Enabling of local forcing	W910, 0 = Function not enabled (preset) W910, 1 = Function enabled
W911			Local forcing via logic input	= 0 No logic input assigned = 1 Reserved = 2 Reserved = 3 Logic input LI3 on basic product = 4 Logic input LI4 on basic product = 5 Logic input LI5 (I/O card) = 6 Logic input LI6 (I/O card) = 7 Logic input LI7 (I/O card) = 8 Logic input LI8 (I/O card)

# Altivar 66 variables

## CONFIGURATION WORDS (read and write)

### Configuration of controlled stop

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W920			Enabling of controlled stop	W920,0 = 0 Function not enabled (preset) W920,0 = 1 Function enabled
			Activation input active level	W920,1 = 0 active at 0 (preset) W920,1 = 1 active at 1
W921			Controlled stop : type of input activation	= 0 No controlled stop (preset) = 1 Activation via logic input = 2 Activation on frequency level = 3 Activation via logic input or frequency level
W922			Stop command via logic input	= 0 No logic input assigned (preset) = 1 Reserved = 2 Reserved = 3 Logic input LI3 on basic product = 4 Logic input LI4 on basic product = 5 Logic input LI5 (I/O card) = 6 Logic input LI6 (I/O card) = 7 Logic input LI7 (I/O card) = 8 Logic input LI8 (I/O card)
W923			Type of controlled stop activated via logic input	= 0 Freewheel stop (preset) = 1 Fast stop = 2 DC injection stop
W924			Type of controlled stop activated via frequency level	= 0 Freewheel stop (preset) = 1 Fast stop = 2 DC injection stop
W925	0...Fmax VAR	0.1 Hz	Frequency level adjustment	Preset at 0 Hz
W926	50...150	1%	Percentage of DC current injected	Preset at 70% (same as W955)
W927	0...301	0.1 s	Adjustment of DC current injection time	Preset at 2 s (same as W956)

F max VAR : (W2204)

Constant torque : 400 Hz for Altivar 66 U41N4 to D79N4

Altivar 66 U41M2 to D46M2

200 Hz for Altivar 66 C10N4 to C31N4

Variable torque : 75/90 Hz (50 Hz/60Hz supply)

# Altivar 66 variables

## CONFIGURATION WORDS (read and write)

### Configuration of shutdown

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W940			Shutdown	W940,0 = 0 Function not enabled (preset) W940,0 = 1 Function enabled
W941			Logic output to signal shutdown completed	= 0 No logic output assigned (preset) = 1 Logic output LO1 = 2 Logic output LO2 = 3 Reserved = 4 Logic output R2 = 5 Logic output R3 (I/O card) = 6 Logic output R4 (I/O card)
W942	1...600	0.1s	Low speed dwell time	Preset at 1.0 s

### Configuration of Bypass

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W970			Bypass	W970,0 = 0 Function not enabled (preset) W970,0 = 1 Function enabled
W971			Start input OK	= 0 No logic input assigned (preset) = 1 Reserved = 2 Reserved
W972			Process input	= 3 Logic input LI3 on basic product = 4 Logic input LI4 on basic product = 5 Logic input LI5 (I/O card) = 6 Logic input LI6 (I/O card) = 7 Logic input LI7 (I/O card) = 8 Logic input LI8 (I/O card)
W973			Contacteur control logic output	= 0 No logic output assigned (preset) = 1 Logic output LO1 = 2 Logic output LO2 = 3 Reserved = 4 Logic output R2 = 5 Logic output R3 (I/O card) = 6 Logic output R4 (I/O card)
W974	2...100	0.1s	Decay time	Preset at 2.0 s
W975	2...3000	0.1s	Sequence time	Preset at 5.0 s
W976	2...3000	0.1s	Process time	Preset at 5.0 s

# Altivar 66 variables

## Configuration of PI function

WORD	RANGE	DESCRIPTION	POSSIBLE VALUES
W1040		Enabling of PI function	W1040,0 = 1 Function enabled W1040,0 = 0 Not enabled (preset)
W1041		Authorizing the direction of rotation Preset	W1041,0 = 1 Forward/reverse direction permissible W1041,0 = 0 Only forward direction permissible
		Increase in the PI error Preset	W1041,1 = 1 Increase in the PI error : decrease in the speed of the motor. W1041,1 = 0 Increase in the PI error : increase in the speed of the motor.
		PI set point via the keypad Preset	W1041,2 = 1 No PI set point via the graphic keypad W1041,2 = 0 PI set point via the graphic keypad
		Man. set point via the keypad Preset	W1041,3 = 1 No speed reference via graphic keypad W1041,3 = 0 Speed reference via the graphic keypad

## Management of PI alarm

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W1048	-9999... W1049		Minimum value for triggering the alarm	Preset at : 0
W1049	-9999... W1048		Maximum value for triggering the alarm	Preset at : 1000

## Configuration of PI function

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W1043	-9999...9999		Gain	Preset at : 9999
W1044	-9999...9999		Offset	Preset at : 0
W1046	-9999...9999		Min. feedback value for the sensor in user-defined units	Preset at : 0
W1047	-9999...9999		Max. feedback value for the sensor in user-defined units	Preset at : 1000
W1053	0..1000	0.1 %	PI error ratio	Preset at : 100 %
W1054	0..9999		PI set point value for the graphic keypad	Preset at : 0
W1055	0..4000	0.1 Hz	Speed reference value for the graphic keypad	Preset at 0 Hz
W1056	1..9999	%	Proportional gain	Preset at 100 %
W1057	0..9999		Integral gain	Preset at 0

# Altivar 66 variables

## Assignment of I/O for the PI function

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W1042	0...4		Assignment of analog input for the PI set point	W1042 = 0 Not assigned W1042 = 1 Analog input AI1 W1042 = 2 Analog input AI2 W1042 = 3 Analog input AI3 (I/O card) W1042 = 4 Analog input AI4 (I/O card)
W1045	0...4		Assignment of analog input for the sensor feedback	W1045 = 0 Not assigned W1045 = 1 Analog input AI1 W1045 = 2 Analog input AI2 W1045 = 3 Analog input AI3 (I/O card) W1045 = 4 Analog input AI4 (I/O card)
W1050	0...4		Assignment of analog input for the speed reference	W1050 = 0 Not assigned W1050 = 1 Analog input AI1 W1050 = 2 Analog input AI2 W1050 = 3 Analog input AI3 (I/O card) W1050 = 4 Analog input AI4 (I/O card)
W1051	0...8		Assignment of logic input switching between man/auto mode	W1051 = 0 Not assigned W1051 = 1 Reserved W1051 = 2 Reserved W1051 = 3 Logic input LI3 W1051 = 4 Logic input LI4 W1051 = 5 Logic input LI5 (I/O card) W1051 = 6 Logic input LI6 (I/O card) W1051 = 7 Logic input LI7 (I/O card) W1051 = 8 Logic input LI8 (I/O card)
W1052	0...8		Assignment of logic input for reversing the direction of rotation	W1052 = 0 Not assigned W1052 = 1 Reserved W1052 = 2 Reserved W1052 = 3 Logic input LI3 W1052 = 4 Logic input LI4 W1052 = 5 Logic input LI5 (I/O card) W1052 = 6 Logic input LI6 (I/O card) W1052 = 7 Logic input LI7 (I/O card) W1052 = 8 Logic input LI8 (I/O card)
W1058	0...3		Assignment of analog output for the PI set point	W1058 = 0 Not assigned W1058 = 1 Analog output AO1 W1058 = 2 Analog output AO2 W1058 = 3 Analog output AO3
W1059	0...3		Assignment of analog output for the PI feedback	W1059 = 0 Not assigned W1059 = 1 Analog output AO1 W1059 = 2 Analog output AO2 W1059 = 3 Analog output AO3
W1060	0...3		Assignment of analog output for the PI error	W1060 = 0 Not assigned W1060 = 1 Analog output AO1 W1060 = 2 Analog output AO2 W1060 = 3 Analog output AO3

# Altivar 66 variables

## Assignment of I/O for the PI function

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W1061	0...3		Assignment of analog output for the PI integrator	W1061 = 0 Not assigned W1061 = 1 Analog output AO1 W1061 = 2 Analog output AO2 W1061 = 3 Analog output AO3
W1062	0...8		Assignment of logic output indicating that the error has exceeded the set value	W1062 = 0 Not assigned W1062 = 1 Logic output LO1 W1062 = 2 Logic output LO2 W1062 = 3 Reserved W1062 = 4 Logic output R2 W1062 = 5 Logic output R3 (I/O card) W1062 = 6 Logic output R4 (I/O card)
W1063	0...8		Assignment of logic output indicating that the process feedback is greater than the maximum set value	W1063 = 0 Not assigned W1063 = 1 Logic output LO1 W1063 = 2 Logic output LO2 W1063 = 3 Reserved W1063 = 4 Logic output R2 W1063 = 5 Logic output R3 (I/O card) W1063 = 6 Logic output R4 (I/O card)
W1064	0...8		Assignment of logic output indicating that the process feedback is greater than the minimum set value	W1064 = 0 Not assigned W1064 = 1 Logic output LO1 W1064 = 2 Logic output LO2 W1064 = 3 Reserved W1064 = 4 Logic output R2 W1064 = 5 Logic output R3 (I/O card) W1064 = 6 Logic output R4 (I/O card)

## Multimotor and multiparameter functions

The use of multimotor and multiparameter functions can be dangerous (especially when switching motors); it is therefore advisable to read the instructions in the ATV66 user manual thoroughly.

To simplify this document, a list of multimotor and multiparameter functions and parameters is provided at the end of the manual (indicated by the letters M and P).

The multimotor function is used to configure up to three motors. These motors can be configured using the same data or independently. However, even though the functions or parameters are multimotor, the inputs and outputs of the speed controller are not. In fact, if the user decides to configure different I/O for each motor, then only the last assignment will actually be taken into account.

## Data structure

- The configuration of motor 1 is between words W206 and W324.
- The configuration of motor 2 is between words W406 and W524 (same as motor 1 + 200).
- The configuration of motor 3 is between words W606 and W724 (same as motor 1 + 400).

Example : W214, nominal current for motor 1.  
W414, nominal current for motor 2.  
W614, nominal current for motor 3.

The display variables monitor the motor which is currently running (word W2074 gives the parameter set or the number of the current motor).

Similarly, for the multiparameter function, the functions and parameters which can be accessed using this function are indicated at the end of this manual (by the letter P).

# Altivar 66 variables

## Configuration of multimotor and multiparameter functions

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W901	0...5		Configuration of multimotor and multiparameter functions	= 0 1 motor = 2 2 motors = 3 2 parameter sets = 4 3 motors = 5 3 parameter sets

## Assignment of logic inputs for multimotor and multiparameter functions

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W902	0...8		Assignment of LIa (selecting the set of parameters or motor)	W902 = 0 Not assigned (preset) W902 = 1 Reserved W902 = 2 Reserved W902 = 3 Logic input LI3 W902 = 4 Logic input LI4 W902 = 5 Logic input LI5 (I/O card) W902 = 6 Logic input LI6 (I/O card) W902 = 7 Logic input LI7 (I/O card) W902 = 8 Logic input LI8 (I/O card)
W903	0...8		Assignment of LIb (selecting the set of parameters or motor)	W903 = 0 Not assigned (preset) W903 = 2 Reserved W903 = 3 Logic input LI3 W903 = 4 Logic input LI4 W903 = 5 Logic input LI5 (I/O card) W903 = 6 Logic input LI6 (I/O card) W903 = 7 Logic input LI7 (I/O card) W903 = 8 Logic input LI8 (I/O card)

# Altivar 66 variables

## PCMCIA memory card / ATV66 transfer - via line

A configuration that is saved on a PCMCIA memory card is called a page. A card consists of up to 16 different configurations or pages.

To transfer from the memory card to the ATV66 :

- Initialize the transfer status register W2190 (optional). This places the transfer data in one of the following states : no card, card incompatible or ready to transfer.
- Request a transfer from the memory card to the ATV66, or a transfer from the ATV66 to the memory card W1700. The transfer is performed immediately. Consult the status register W2190 to confirm the transfer has been successful.
- Process the response obtained : if the response is NO, this means that there are insufficient access rights (motor running or semaphore configuration already reserved).

### Transfer

WORD	DESCRIPTION	POSSIBLE VALUES
W1700	Selection of range to transfer	W1700,0 to W1700,7 = = 1 Page no. 1 = 2 Page no. 2 = 3 Page no. 3 = 4 Page no. 4 = 5 Page no. 5 = 6 Page no. 6 = 7 Page no. 7 = 8 Page no. 8 = 9 Page no. 9 = 10 Page no. 10 = 11 Page no. 11 = 12 Page no. 12 = 13 Page no. 13 = 14 Page no. 14 = 15 Page no. 15 = 16 Page no. 16
	Command to be used for the transfer	W1700,8 to W1700,15 = = 0 Word W2191 update : page identification = 1 Reinitialization of the transfer status register : W2190 = 2 Request a transfer from the memory card to the speed controller = 3 Request a transfer from the speed controller to the memory card

# Altivar 66 variables

## PCMCIA memory card / ATV66 transfer - via line

### Transfer status register

WORD	DESCRIPTION	POSSIBLE VALUES
W2190	Status of memory card/ ATV66 transfer	W2190,0 to W2190,7 = = 0 Ready to transfer = 1 Transfert correct = 2 No PCMCIA card present = 3 PCMCIA card incompatible = 4 Transfert incorrect (eg : page no. or transfer order incorrect) = 5 Transfer error (eg : write-protection by PCMCIA card switch) = 6 Page incompatible = 7 Blank page
	PCMCIA memory card removed	W2190.8 = 1 card removed or changed W2190.8 = 0 no card change

### Page identification

WORD	DESCRIPTION	POSSIBLE VALUES
W2191	No. of selected page	W2191,0 to W2191,7 = = 1 Page no. 1 = 2 Page no. 2 = 3 Page no. 3 = 4 Page no. 4 = 5 Page no. 5 = 6 Page no. 6 = 7 Page no. 7 = 8 Page no. 8 = 9 Page no. 9 = 10 Page no. 10 = 11 Page no. 11 = 12 Page no.12 = 13 Page no. 13 = 14 Page no. 14 = 15 Page no. 15 = 16 Page no. 16
	Blank page	W2191,8, 8 = 1 blank page W2191,8, 8 = 0 page not blank

# Altivar 66 variables

## CONFIGURATION WORDS (read and write)

### Configuration of the intermediate parameters with I/O card

#### Configuration of voltage reduction

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W310			Voltage reduction	W310,0 = 0 Function not enabled (preset) W310,0 = 1 Function enabled
W311			Choice of reduction type	= 0 No reduction (preset) = 1 Activation on frequency threshold = 2 Activation via logic input = 3 Level of analog input
W312			Voltage reduction via logic input	= 0 No logic output assigned (preset) = 1 Reserved = 2 Reserved = 3 Logic input LI3 on basic product = 4 Logic input LI4 on basic product = 5 Logic input LI5 (I/O card) = 6 Logic input LI6 (I/O card) = 7 Logic input LI7 (I/O card) = 8 Logic input LI8 (I/O card)
W313			Voltage reduction via analog input	= 0 No logic output assigned (preset) = 1 Analog input AI1 = 2 Analog input AI2 = 3 Analog input AI3 (I/O card) = 4 Analog input AI4 (I/O card)
W314*	0...Fmax VAR	0.1Hz	Voltage reduction via frequency threshold	Preset at 60 Hz if 60 Hz supply Preset at 50 Hz if 50 Hz supply
W315	20...100	1%	Voltage reduction coefficient	Preset at 100%

\* F max VAR : (W2204)

Constant torque : 400 Hz for Altivar 66 U41N4 to D79N4

Altivar 66 U41M2 to D46M2

200 Hz for Altivar 66 C10N4 to C31N4

Variable torque : 75/90 Hz (50 Hz/60Hz supply)

# Altivar 66 variables

## CONFIGURATION WORDS (read and write)

### Configuration of the intermediate parameters with I/O card

#### Configuration of tachogenerator feedback

WORD	RANGE	DESCRIPTION	POSSIBLE VALUES
W870		Enabling of tachogenerator feedback	W870,0 = 0 Function not enabled (preset) W870,0 = 1 Function enabled
W871		Assignment of speed feedback input	= 0 No analog input (preset) = 3 Analog input AI3 (I/O card)

#### Configuration of orient

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W950			Enabling of orient	W950,0 = 0 Function not enabled (preset) W950,0 = 1 Function enabled
W951			Assignment of logic input for command	= 0 No logic input assigned (preset) = 1 Reserved
W952			Assignment of synchronization logic input	= 2 Reserved = 3 Logic input LI3 on basic product = 4 Logic input LI4 on basic product = 5 Logic input LI5 (I/O card) = 6 Logic input LI6 (I/O card) = 7 Logic input LI7 (I/O card) = 8 Logic input LI8 (I/O card)
W953			Orient : signalling logic output to signal orient completed	= 0 No logic output assigned (preset) = 1 Logic output LO1 = 2 Logic output LO2 = 3 Reserved = 4 Logic output R2 = 5 Logic output R3 (I/O card) = 6 Logic output R4 (I/O card)
W954	0...100	0.1s	Shutdown	Preset at 1.0 s
W955	50...150	1%	Percentage of DC injection	Preset at 70 %
W956	0...301	0.1s	DC injection time	Preset at 2.0 s

#### Memorization of speed reference

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W850			Memorization of speed reference	W850,0 = 0 Function not enabled (preset) W850,0 = 1 Function enabled
W851			Memorization of speed reference via logic input	= 0 No logic input assigned (preset) = 1 Reserved = 2 Reserved = 3 Logic input LI3 on basic product = 4 Logic input LI4 on basic product = 5 Logic input LI5 (I/O card) = 6 Logic input LI6 (I/O card) = 7 Logic input LI7 (I/O card) = 8 Logic input LI8 (I/O card)

# Altivar 66 variables

## CONFIGURATION WORDS (read and write)

### Configuration of the intermediate parameters with I/O card

#### Configuration of cycle function

WORD	RANGE	DESCRIPTION	POSSIBLE VALUES
W1000		Enabling of cycle function	W1000,0 = 0 Function not enabled (preset) W1000,0 = 1 Function enabled
		Step 1 frequency sign	W1000,8 = 0 Positive sign (preset) W1000,8 = 1 Negative sign
		Step 2 frequency sign	W1000,9 = 0 Positive sign (preset) W1000,9 = 1 Negative sign
		Step 3 frequency sign	W1000,10 = 0 Positive sign (preset) W1000,10 = 1 Negative sign
		Step 4 frequency sign	W1000,11 = 0 Positive sign (preset) W1000,11 = 1 Negative sign
		Step 5 frequency sign	W1000,12 = 0 Positive sign (preset) W1000,12 = 1 Negative sign
		Step 6 frequency sign	W1000,13 = 0 Positive sign (preset) W1000,13 = 1 Negative sign
		Step 7 frequency sign	W1000,14 = 0 Positive sign (preset) W1000,14 = 1 Negative sign
		Step 8 frequency sign	W1000,15 = 0 Positive sign (preset) W1000,15 = 1 Negative sign
W1001		Logic input for cycle start	= 0 No logic input assigned = 1 Reserved = 2 Reserved = 3 Logic input LI3 on basic product = 4 Logic input LI4 on basic product = 5 Logic input LI5 (I/O card) = 6 Logic input LI6 (I/O card) = 7 Logic input LI7 (I/O card) = 8 Logic input LI8 (I/O card)
W1002		Logic input for cycle reset	
W1003		Logic input for cycle pause	
W1004		Logic input for change to next step	
W1005		Logic output for cycle over	= 0 No logic input assigned = 1 Logic output LO1 = 2 Logic output LO2 = 3 Reserved = 4 Logic output R2 = 5 Logic output R3 (I/O card) = 6 Logic output R4 (I/O card)
W1006		Logic output for cycle fault	

# Altivar 66 variables

## CONFIGURATION WORDS (read and write)

### Configuration of the intermediate parameters with I/O card

#### Configuration of cycle function (continued)

WORD	RANGE	UNIT	DESCRIPTION	PRESET
W1007	0...250		Step 1 number of sub-cycles	0
W1008	0...250		Step 2 number of sub-cycles	0
W1009	0...250		Step 3 number of sub-cycles	0
W1010	0...250		Step 4 number of sub-cycles	0
W1011	0...250		Step 5 number of sub-cycles	0
W1012	0...250		Step 6 number of sub-cycles	0
W1013	0...250		Step 7 number of sub-cycles	0
W1014	0...250		Step 8 number of sub-cycles	0
W1015	0...Fmax VAR	0.1Hz	Step 1 Frequency	30.0 Hz
W1016	1...9999	0.1s	Step 1 Ramp time	3.0 s
W1017	0...6000	1s	Step 1 Step duration	30 s
W1018	0...Fmax VAR	0.1Hz	Step 2 Frequency	30.0 Hz
W1019	1...9999	0.1s	Step 2 Ramp time	3.0 s
W1020	0...6000	1s	Step 2 Step duration	0 s
W1021	0...Fmax VAR	0.1Hz	Step 3 Frequency	30.0 Hz
W1022	1...9999	0.1s	Step 3 Ramp time	3.0 s
W1023	0...6000	1s	Step 3 Step duration	0 s
W1024	0...Fmax VAR	0.1Hz	Step 4 Frequency	30.0 Hz
W1025	1...999	0.1s	Step 4 Ramp time	3.0 s
W1026	0...6000	1s	Step 4 Step duration	0 s
W1027	0...Fmax VAR	0.1Hz	Step 5 Frequency	30.0 Hz
W1028	1...999	0.1s	Step 5 Ramp time	3.0 s
W1029	0...6000	1s	Step 5 Step duration	0 s
W1030	0...Fmax VAR	0.1Hz	Step 6 Frequency	30.0 Hz
W1031	1...999	0.1s	Step 6 Ramp time	3.0 s
W1032	0...6000	1s	Step 6 Step duration	0 s
W1033	0...Fmax VAR	0.1Hz	Step 7 Frequency	30.0 Hz
W1034	1...999	0.1s	Step 7 Ramp time	.0 s
W1035	0...6000	1s	Step 7 Step duration	0 s
W1036	0...Fmax VAR	0.1Hz	Step 8 Frequency	30.0 Hz
W1037	1...999	0.1s	Step 8 Ramp time	3.0 s
W1038	0...6000	1s	Step 8 Step duration	0 s

F max VAR :

Constant torque : 400 Hz for Altivar 66 U41N4 to D79N4

Altivar 66 U41M2 to D46M2

200 Hz for Altivar 66 C10N4 to C31N4

Variable torque : 75/90 Hz (50 Hz/60Hz supply)

# Altivar 66 variables

## CONFIGURATION WORDS (read and write) I/O configuration

### Assignment of negative signs to analog inputs AI2, AI3 and AI4

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W775			Assignment of negative sign to AI2	W775,2 = 0 Negative sign not enabled (preset) W775,2 = 1 Negative sign enabled
			Assignment of negative sign to AI4	W775,3 = 0 Negative sign not enabled (preset) W775,3 = 1 Negative sign enabled
			Assignment of negative sign to AI4	W775,4 = 0 Negative sign not enabled (preset) W775,4 = 1 Negative sign enabled

### Analog input AI2 AI3 AI4 current input type

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W776			Current type of input AI 2	W776 = 0 Input 0 - 20 mA W776 = 1 Input 4 - 20 mA (preset) W776 = 2 Input 20 - 4 mA W776 = 3 Input X - 20 mA (see W779)
W777			Voltage type of input AI 3	W777 = 4 Input +/- 10 V (preset) W777 = 5 Input 0 / +10 V W777 = 6 Input 0 / -10V
W778			Current type of input AI 4	W778 = 0 Input 0 - 20 mA W778 = 1 Input 4 - 20 mA (preset) W778 = 2 Input 20 - 4 mA

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W779	0...200	0.1mA	Entry of a value for AI2	Preset at 4.0 mA for X - 20 mA

# Altivar 66 variables

## CONFIGURATION WORDS (read and write)

### I/O configuration

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W780			Type of signal of analog output AO1	= 0 Output 0 - 20 mA (preset) = 1 Output 4 - 20 mA
W781			Type of signal of analog output AO2	= 0 Output 0 - 20 mA (preset) = 1 Output 4 - 20 mA
W782			Type of signal of analog output AO3	= 0 Output 0 - 20 mA (preset) = 1 Output 4 - 20 mA

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W783			Assignment of analog output AO1	= 0 Not assigned = 1 Motor current = 2 Motor frequency(preset) = 3 Motor power = 4 Motor torque = 5 Motor voltage = 6 Motor thermal state = 7 Ramp output = 8 PI set point = 9 Sensor feedback = 10 PI error = 11 PI error integrator
W784			Assignment of analog output AO2	= 0 Not assigned = 1 Motor current (preset) = 2 Motor frequency = 3 Motor power = 4 Motor torque = 5 Motor voltage = 6 Motor thermal state = 7 Ramp output = 8 PI set point = 9 Sensor feedback = 10 PI error = 11 PI error integrator
W785			Assignment of analog output AO3	= 0 Not assigned (preset) = 1 Motor current = 2 Motor frequency = 3 Motor power (preset with I/O card) = 4 Motor torque = 5 Motor voltage = 6 Motor thermal state = 7 Ramp output = 8 PI set point = 9 Sensor feedback = 10 PI error = 11 PI error integrator
W786	0...Fmax VAR	0.1Hz	Logic output activation frequency level 1	Preset at 25.0 Hz
W787	0...Fmax VAR	0.1Hz	Logic output activation frequency level 2	Preset at 0.0 Hz
W788	10...150	1%	Logic output activation current level 1	Preset at 100%
W789	10...150	1%	Logic output activation current level 2	Preset at 50%
W790	0...200	1%	Logic output activation thermal state 1	Preset at 100%
W791	0...200	1%	Logic output activation thermal state 2	Preset at 10%
W792	0...100	1%	Logic output activation torque level	Preset at 100%

F max VAR :

Constant torque : 400 Hz for Altivar 66 U41N4 to D79N4  
Altivar 66 U41M2 to D46M2

200 Hz for Altivar 66 C10N4 to C31N4

Variable torque : 75/90 Hz (50 Hz/60Hz supply)

# Altivar 66 variables

## CONFIGURATION WORDS (read and write)

### I/O configuration

WORD	DESCRIPTION	POSSIBLE VALUES
W793	Assignment of logic output LO1	= 0 Not assigned
W794	Assignment of logic output LO2	= 1 Speed controller ready
W798	Assignment of logic output R2	= 2 Speed controller running
W799	Assignment of logic output R3	= 3 Set point reached
W800	Assignment of logic output R4	= 4 Forward operation = 5 Reverse operation = 6 Keypad control = 7 Auto/Man automatic position = 8 Current limit = 9 Torque limit = 10 Fault = 11 Speed controller thermal alarm = 12 Loss of AI2 = 13 No ramp follow (with I/O card) = 14 Tachogenerator feedback fault (with I/O card) = 15 Overspeed (with I/O card) = 16 Frequency threshold 1 reached = 17 Frequency threshold 2 reached (with I/O card) = 18 Current threshold 1 reached = 19 Current threshold 2 reached (with I/O card) = 20 Thermal state threshold 1 reached = 21 Thermal state threshold 2 reached (with I/O card) = 22 Reserved = 23 Brake release = 24 Shutdown = 25 Orient complete = 26 Cycle complete = 27 Cycle fault = 28 Bypass command = 29 JOG = 30 Reserved = 31 Reserved = 32 PI error exceeded = 33 (PI) max error exceeded = 34 (PI) min error exceeded



# Altivar 66 variables

## CONFIGURATION WORDS (read and write)

### Configuration of the keypad

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W743			Terminal block / keypad control	= 0 Control via terminal block (preset) = 1 Control via keypad = 2 Switching via logic input = 3 Switching via F2 key
W744			Logic input for Terminal block/ Graphic keypad switching	= 0 No logic input assigned (preset) = 1 Reserved = 2 Reserved = 3 Logic input LI3 on basic product = 4 Logic input LI4 on basic product = 5 Logic input LI5 (I/O card) = 6 Logic input LI6 (I/O card) = 7 Logic input LI7 (I/O card) = 8 Logic input LI8 (I/O card)
W745	0...Fmax VAR	0.1Hz	Keypad preset speed 1	Preset at 0.0 Hz
W746	0...Fmax VAR	0.1Hz	Keypad preset speed 2	Preset at 0.0 Hz
W747	2...100	0.1Hz	JOG frequency	Preset at 5.0 Hz

W747 and W893 = same word

# Altivar 66 variables

## CONFIGURATION WORDS (read and write)

### Configuration of faults

#### *Fault configuration register*

WORD	DESCRIPTION	POSSIBLE VALUES
W755	Automatic restart	W755,1 = 0 Not enabled (preset) W755,1 = 1 Enabled
	Enabling of power loss function	W755,2 = 0 Not enabled (preset) W755,2 = 1 Enabled
	Enabling of input phase failure function	W755,3 = 0 Not enabled W755,3 = 1 Enabled (preset)
	Enabling of motor phase fault function	W755,4 = 0 Not enabled W755,4 = 1 Enabled (preset)
	Enabling of DB resistor protection	W755,5 = 0 Not enabled (preset) W755,5 = 1 Enabled
	Check presence of braking resistor	W755,6 = 0 Not enabled (preset) W755,6 = 1 Enabled
	Enabling of speed controller reset	W755,7 = 0 Not enabled (preset) W755,7 = 1 Enabled
	External fault	W755,8 = 0 Not enabled (preset) W755,8 = 1 Enabled
	Logic input active state (0 or 1)	W755,9 = 0 Active at low state W755,9 = 1 Active at high state
	Current adaptation (variable torque)	W755,10 = 0 Not enabled (preset) W755,10 = 1 Enabled
	Enabling of flying restart function	W755,11 = 0 Not enabled W755,11 = 1 Enabled (preset)
	Enabling of loss follower	W755,12 = 0 Not enabled (preset) W755,12 = 1 Enabled
	Enabling of thermal protection	W755,13 = 0 Not enabled W755,13 = 1 Enabled (preset)

# Altivar 66 variables

## CONFIGURATION WORDS (read and write)

### Configuration of faults

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W756			Stopping methods on a fault	= 0 Normal stop = 1 Fast stop = 2 Freewheel stop (preset)

### Configuration of automatic restart

WORD	RANGE	UNIT	DESCRIPTION	COMMENT
W757	1...5		Number of possible restarts	Preset at 5
W758	1...600	1s	Locking time	Preset at 30 s

### Type of motor overload

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W759	0...3		Type of motor overload	= 0 No protection = 1 Motor self-cooled = 2 Motor force-cooled = 3 Manual tuning of motor minimum speed at full load (preset at 50%) W761
W760	45%..115% of W214	0.1A	Thermal tripping current	Factory preset at 0.9 times speed controller nominal current
W761	0...100	1%	Minimum speed at full load	Preset at 50%
W762	0...100	1%	Maximum current at zero frequency	Preset at 50%
W763		0.1Ω	Value of braking resistor	
W764		1W	Power of braking resistor	

WORD	RANGE	UNIT	DESCRIPTION	COMMENT
W765			Reset speed controller via logic input	= 0 No logic input assigned = 1 Reserved
W766			External fault : activation logic input	= 2 Reserved = 3 Logic input LI3 = 4 Logic input LI4 = 5 Logic input LI5 (I/O card) = 6 Logic input LI6 (I/O card) = 7 Logic input LI7 (I/O card) = 8 Logic input LI8 (I/O card)

# Altivar 66 variables

## CONFIGURATION WORDS (read and write)

### Configuration of faults

#### *Loss follower*

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W767	0...Fmax VAR	0.1 Hz	Frequency set point if loss follower occurs	Programming of a reference speed (preset at 0 Hz)
W768			Type of action in the event of loss of current input :	= 0 No detection (preset) = 1 Skip to frequency = 2 Change to fault mode

#### *Type of flying restart*

WORD	RANGE	UNIT	DESCRIPTION	POSSIBLE VALUES
W769			Type of flying restart	= 0 On ramp (preset) = 1 Current limit = 2 No restart

F max VAR :

Constant torque : 400 Hz for Altivar 66 U41N4 to D79N4

Altivar 66 U41M2 to D46M2

200 Hz for Altivar 66 C10N4 to C31N4

Variable torque : 75/90 Hz (50 Hz/60Hz supply)

# Altivar 66 variables

## CONFIGURATION WORDS (read and write)

### Configuration of the keypad display

WORD	DESCRIPTION	POSSIBLE VALUES
W730	Configuration of graphics	= 0 One bargraph (preset) = 1 Two bargraphs = 2 Four parameters
W731	Configuration of bargraph 1	= 0 Set point frequency (preset)
W732	Configuration of bargraph 2	= 1 Output frequency = 2 Output current = 3 Motor torque = 4 Output power = 5 Output voltage = 6 Supply voltage = 7 Bus voltage = 8 Motor thermal state = 9 Speed controller thermal state = 10 Motor speed = 11 Machine set point (user unit) = 12 Machine speed (user unit) = 15 PI feedback = 16 PI set point

WORD	RANGE	UNIT	DESCRIPTION
W734	1...100		Scale factor of machine units

\*The machine units of the set point and machine speed variables are entered via the graphic keypad

(see ["display configuration" in the programming manual](#))

WORD	DESCRIPTION	POSSIBLE VALUES
W749	Language	= 1 German = 2 English = 3 Spanish = 4 French = 5 Italian = 6 Reserved = 7 Swedish

# Altivar 66 variables

## ADDRESS ZONE COMMON TO ALTIVAR 66 AND ALTIVAR 45 2

### Command bits (read and write) of words W0 and W1

BIT	NAME	DESCRIPTION	NOTES
B0	TST	De-energization of speed controller safety relay	Always read at 0 (active on transition from 0 to 1)
B1	RST	Speed controller reset	
B2	CLO	Assignment of commands in LOCAL mode	
B3	CLI	Assignment of commands in LINE mode	
B4	NTO	Inhibition of communication check	
B5	RUN	Start/stop command	
B6	REV	Reverse direction of rotation = change frequency set point sign	
B7	DCB	Braking control	
B8	CAL	Selection of freewheel stop	
B9	CAR	Selection of fast stop	
B10	RTM	Motor voltage reduction	

### Adjustment words (read and write)

WD	NAME	RANGE ATV45.2	RANGE ATV66	UNITS	DESCRIPTION	COMMENTS
W2	CGL	0..5	0..100	0.1 Hz	Slip compensation	
W4	RLI	5..150%	50...1360	0.10%	Reduction of current limit	
W6	IBR	0.2..1.5 In	50...150 (%)	0.1 A	Braking current amplitude	
W7	IAR	0.2..1.5 In	50...150 (%)	0.1 A	DC amplitude when stopping	
W8	TAR	0.5..4 s	0...301	0.1 s	DC injection time when stopping	
W9	UFR	0..100	0..100	1	Voltage/frequency ratio adjustment coefficient	Adjustment word : Voltage Boost
W10	ITH	0.45..1.05 In	50...115	0.1 A	Motor thermal protection	
W11	GBF	0..100	0..100	0.1	Frequency loop gain	
W12	FR1	0.. HSP	0.. HSP	0.1 Hz	Skip frequency 1	
W13	FR2	0.. HSP	0.. HSP	0.1 Hz	Skip frequency 2	
W14	LSP	0.. HSP	0.. HSP	0.1 Hz	Minimum frequency	
W15	HSP	LSP..f max	LSP..f max	0.1 Hz	Maximum frequency	
W16	ACC	0.2.. 990 s	1...9999	0.1 s	Acceleration time	
W17	DEC	0.2.. 990 s	1...9999	0.1 s	Deceleration time	

# Altivar 66 variables

## ADDRESS ZONE COMMON TO ALTIVAR 66 AND ALTIVAR 45 2

### Command register

WORDS	NAME	RANGE ATV66	RANGE ATV 45.2	UNITS	DESCRIPTION
W18	COM	–		–	Command register
	–				W18,0 Speed controller reset
	DLI				W18,1 Assignment of logic commands in LINE mode
	FLI				W18,2 Assignment of set points in LINE mode
					W18,3 Reserved
	NTO				W18,4 Inhibit communication check
	RUN				W18,5 Stop/Start command
	DCB				W18,6 DC injection braking control
	–				W18,7 Reserved
	CAL				W18,8 Selection of freewheel stop
	CAR				W18,9 Selection of fast stop
	RTM				W18,10 Motor voltage reduction control
	–				W18,11 Reserved
	–				W18,12 Reserved
	–				W18,13 Reserved
–				W18,14 Reserved	
–				W18,15 Storage in EEPROM	
W19	FRH	LSP .. HSP		0.1 Hz	Frequency set point

# Altivar 66 variables

---

## ADDRESS ZONE COMMON TO ALTIVAR 66 AND ALTIVAR 45 2

### Configuration words (read and write)

WORDS	NAME	RANGE	RANGE ATV45.2	UNITS ATV66	DESCRIPTION
W53		0.2.. 990 s	1...9999	0.1 s	Acceleration time 2
W54		0.2.. 990 s	1...9999	0.1 s	Deceleration time 2
W61		W62.. 10Hz	0...LSP	0.1 Hz	Brake application level
W62		0 Hz .. W61	0...LSP	0.1 Hz	Brake release level
W63		0.. 4 s	0...50	0.1 s	Brake application time

## REGISTER OF PAST FAULTS (read only)

### Configuration words (read only)

WORDS	NAME	RANGE	RANGE ATV45.2	UNITS ATV66	DESCRIPTION
W120					Register of 1st past fault
W121					Register of 2nd past fault
W121					Register of 3rd past fault
W121					Register of 4th past fault
W121					Register of 5th past fault
W121					Register of 6th past fault
W121					Register of 7th past fault
W127					Register of 8th past fault

# Altivar 66 variables

## ADDRESS ZONE COMMON TO ALTIVAR 66 AND ALTIVAR 45 2 (read only)

### Status register

WORDS	NAME	RANGE ATV45.2		DESCRIPTION (corresponding to state 1)
W20	STR			Status register
	LOC		1	W20,0 All commands assigned in LOCAL mode
	RDY		2	W20,1 Speed controller ready
	FAI		4	W20,2 Faulty
	REN		8	W20,3 Reset authorized
	BOR		16	W20,4 Brake release relay energized
	FLO		32	W20,5 Speed controller forced in LOCAL mode
	NTO		64	W20,6 Communication check inhibited
	CFA		128	W20,7 Resettable fault
	RNG		256	W20,8 Motor running
	RVE		512	W20,9 Actual direction of rotation
	BRE		1024	W20,10 DC injection braking
	SST		2048	W20,11 Steady state
	OVL		4096	W20,12 Motor thermal overload alarm
	OBR		8292	W20,13 Overbraking alarm
LIM		16384	W20,14 Current limit	
PWD		32768	W20,15 Power not present	

### Fault register

BIT	NAME	RANGE ATV45.2		DESCRIPTION
W21	FLT			Fault register
	INF		1	W21,0 Internal fault
	SLP		2	W21,1 Serial link break
			4	W21,2 Reserved
	SRF		8	W21,3 Reserved
	USF		16	W21,4 DC bus undervoltage
	OSF		32	W21,5 AC line overvoltage
	PHF		64	W21,6 Phase break
	OHF		128	W21,7 Speed controller overtemperature
	SPF		256	W21,8 Speed feedback not present, overspeed
	OCF		512	W21,9 Phase short-circuit or ground short-circuit
	OBF		1024	W21,10 DC bus overvoltage
	OBF		2048	W21,11 DC bus overvoltage
	OLF		4096	W21,12 Motor overload
	OLF		8192	W21,13 Output phase loss
		16384	W21,14 Reserved	
CRF		32768	W21,15 Precharge failure	

# Altivar 66 variables

---

## ADDRESS ZONE COMMON TO ALTIVAR 66 AND ALTIVAR 45 2

*Signalling words (read only)*

WORDS	NAME	RANGE		UNIT	DESCRIPTION
		ATV45.2	ATV66		
W22	LCR			0.1 A	Motor current
W23	RFR			0.1 Hz	Rotation frequency
W24	THR			0.10%	Motor thermal state
W25	ULN			0.1 V	AC supply voltage
W26	CHM			0.10%	Motor load
W27	–			–	Reserved
W28	–			–	Reserved
W30	DAI	0.. 1000	0...100		Value of speed controller analog input
W31	–	–			Reserved
W32	–	–			Reserved

# INDEX

Start address	End address	Description	Page
W198		Configuration semaphore	61
W199		Speed controller locked when stopped	61
W200		2- or 3- wire control	63
W201		Torque type	63
W202		Motor power	63
W206		Control type	M * 63
W210		Direction of phase rotation	M 63
W211		Motor nominal frequency type	M 62
W212		Motor nominal frequency	M 62
W213		Motor nominal voltage	M 62
W214		Motor nominal current	M 62
W215		Torque limit in generator phase	M 63
W216		Torque limit in motor phase	M 63
W219		Motor nominal speed configuration	M 62
W225	W227	Slip compensation value	M 64
W226		Slip compensation type	M 64
W227		Slip compensation value	M 64
W228		IR compensation value	M 64
W229		Profile	M 64
W230		Voltage boost	M 64
W231		Damping	M 64
W232		Bandwidth	64
W245	W253	Enabling of braking sequence	M 65
W246		Brake control logic output	65
W247		Brake release frequency	M 65
W248		Brake dwell current threshold	M 65
W249		Brake dwell time	M 65
W250		Brake release frequency	M 65
W251		Brake release time	M 65
W252		DC injection threshold	M 65
W253		DC injection time	M 65
W260	W265	Enabling of current limit	M 66
W261		Current limit type	M 66
W262		Logic input to activate current limit	66
W263		Analog input for current limit	66
W264		Activation frequency level	M 66
W265		Limit current	M 66
W270	W283	Enabling of ramp switching	M,P 67

\* High torque available on motor 1 only - M = Multimotor - P = Multiparameter

# INDEX

Start address	End address	Description		Page
W271		Acceleration type	M,P	67
W272		Rounding coefficient for S acceleration ramps	M,P	67
W273		Rounding coefficient for U acceleration ramps	M,P	67
W274		Deceleration type	M,P	67
W275		Rounding coefficient for S deceleration ramps	M,P	67
W276		Rounding coefficient for U deceleration ramps	M,P	67
W277		Ramp switching type	M,P	67
W278		Logic input for ramp switching		67
W279		Activation frequency level	M,P	67
W280		Duration of first acceleration ramp	M,P	67
W281		Duration of first deceleration ramp	M,P	67
W282		Duration of second acceleration ramp	M,P	67
W283		Duration of second deceleration ramp	M,P	67
W290		Skip frequency range 1	M,P	67
		Skip frequency range 2		67
		Skip frequency range 3		67
W291		Skip frequency value 1	M,P	67
W292		Skip frequency value 2	M,P	67
W293		Skip frequency value 3	M,P	67
W301		Motor maximum frequency	M,P	62
W302		High speed	M,P	62
W303		Low speed	M,P	62
W310	W315	Voltage reduction	M,P	81
W311		Choice of reduction type	M,P	81
W312		Voltage reduction via logic input		81
W313		Voltage reduction via analog input		81
W314		Voltage reduction via frequency level	M,P	81
W315		Voltage reduction coefficient	M,P	81
W320		Torque limit type	M	63
W321		Assignment of torque limit activating logic input		63
W322		Assignment of torque limit activating analog input		63
W323		Torque limit in generator phase	M	63
W324		Torque limit in motor phase	M	63
W730		Configuration of graphics		93
W731		Configuration of bargraph 1		93
W732		Configuration of bargraph 2		93
W734		Scale factor of machine units		93
W740		Assignment of F1 key		88

M = Multimotor - P = Multiparameter

# INDEX

Start address	End address	Description	Page
W741		Assignment of a logic input to F2 key	88
W742		Assignment of a logic input to F3 key	88
W743		Terminal block / keypad control	89
W744		Logic input for Terminal block / keypad switching	89
W745		Keypad preset speed 1	89
W746		Keypad preset speed 2	89
W747		JOG	89
W748		Type of access to speed controller data via keypad	61
W749		Language	93
W755		Automatic restart	90
		Enabling of power loss function	90
		Enabling of input phase failure function	90
		Enabling of motor phase fault fuction	90
		Enabling of DB resistor protection	90
		Check presence of braking resistor	90
		Enabling of speed controller reset	90
		External fault	90
		Logic input active state (0 or 1)	90
		Current adaptation (Variable torque)	90
		Enabling of flying restart function	90
		Enabling of loss follower	90
		Enabling of thermal protection	90
W756		Stopping methods on a fault	91
W757		Number of possible restarts	91
W758		Locking time	91
W759		Type of motor overload	91
W760		Thermal tripping current	91
W761		Minimum speed at full load	91
W762		Maximum speed at zero frequency	91
W763		Value of braking resistor	91
W764		Power of braking resistor	91
W765		Reset speed controller via logic input	91
W766		External fault : activation logic input	91
W767		Frequency set point if loss follower occurs	92
W768		Type of action in the event of loss of current input	92
W769		Type of flying restart	92
W775		Assignment of negative sign to AI2	85
		Assignment of negative sign to AI3	85

# INDEX

Start address	End address	Description	Page
		Assignment of negative sign to AI4	85
W776		Current type of input AI2	85
W777		Voltage type of input AI3	85
W778		Current type of input AI4	85
W779		Entry of a value for AI2	85
W780		Type of signal of analog output AO1	86
W781		Type of signal of analog output AO2	86
W782		Type of signal of analog output AO3	86
W783		Assignment of analog output AO1	86
W784		Assignment of analog output AO2	86
W785		Assignment of analog output AO3	86
W786		Logic output activation frequency level 1	86
W787		Logic output activation frequency level 2	86
W788		Logic output activation current level 1	86
W789		Logic output activation current level 2	86
W790		Logic output activation thermal state 1	86
W791		Logic output activation thermal state 1	86
W792		Logic output activation torque level	86
W793		Assignment of logic output LO1	87
W794		Assignment of logic output LO2	87
W798		Assignment of logic output R2	87
W799		Assignment of logic output R3	87
W800		Assignment of logic output R4	87
W810	W813	Limitation to 0 of the summing of analog inputs assigned to the frequency set point	65
W811		Analog input : frequency set point «a»	65
W812		Analog input : frequency set point «b»	65
W813		Analog input : frequency set point «c»	65
W820	W823	Enabling of + speed / - speed function	69
W821		Type of +/- speed	69
W822		Logic input for - speed	69
W823		Logic input for + speed	69
W830	W841	Enabling of preset speeds	70
W831		Choice of number of preset speeds	70
W832		Select via logic input (a)	70
W833		Select via logic input (b)	70
W834		Select via logic input (c)	70
W835		Speed 1 value	70

# INDEX

Start address	End address	Description	Page
W836		Speed 2 value	70
W837		Speed 3 value	70
W838		Speed 4 value	70
W839		Speed 5 value	70
W840		Speed 6 value	70
W841		Speed 7 value	70
W850	W851	Memorization of speed reference	82
W851		Memorization of speed reference via logic input	82
W860	W862	Auto/Man	71
W861		Switching auto / manual logic input	71
W862		Auto / Run logic input	71
W870		Enabling of tachogenerator feedback	82
W871		Assignment of speed feedback input	82
W880	W881	Enabling of reverse function	68
W881	W894	Logic input for enabling Run / Reverse	68
W890		Enabling of JOG function	68
W891		Logic input for JOG activation	68
W892		Logic output for signalling enabling of JOG	68
W893		JOG reference frequency	68
W894		Dead time between two JOG pulses	68
W901		Configuration of multimotor and multiparameter functions	78
W902		Assignment of LIa (selecting the set of parameters or motors)	78
W903		Assignment of LIb (selecting the set of parameters or motors)	78
W910	W911	Enabling of local forcing	71
W911		Local forcing via logic input	71
W920	W927	Enabling of controlled stop	72
		Activation input active level	72
W921		Controlled stop : type of input activation	72
W922		Stop command via logic input	72
W923		Type of controlled stop activated via logic input	72
W924		Type of controlled stop activated via frequency level	72
W925		Frequency level adjustment	72
W926		Percentage of DC current injected	72
W927		Adjustment of DC current injection time	72
W940	W942	Shutdown	73
W941		Logic output signalling shutdown completed	73
W942		Low speed dwell time	73
W950	W956	Enabling of orient	82

# INDEX

Start address	End address	Description	Page
W951		Assignment of logic input for command	82
W952		Assignment of synchronization logic input	82
W953		Orient : signalling logic output to signal orient completed	82
W954		Shutdown	82
W955		Percentage of DC injection	82
W956		DC injection time	82
W970	W976	Bypass	73
W971		Start input OK	73
W972		Process input	73
W973		Contactora control logic output	73
W974		Decay time	73
W975		Sequence time	73
W976		Process time	73
W1000	W1038	Enabling of cycle function	83
		Step 1 frequency sign	83
		Step 2 frequency sign	83
		Step 3 frequency sign	83
		Step 4 frequency sign	83
		Step 5 frequency sign	83
		Step 6 frequency sign	83
		Step 7 frequency sign	83
		Step 8 frequency sign	83
W1001		Logic input for cycle start	83
W1002		Logic input for cycle reset	83
W1003		Logic input for cycle pause	83
W1004		Logic input for change to next step	83
W1005		Logic output for cycle end	83
W1006		Logic output for cycle fault	83
W1007		Step 1 number of sub-cycles	84
W1008		Step 2 number of sub-cycles	84
W1009		Step 3 number of sub-cycles	84
W1010		Step 4 number of sub-cycles	84
W1011		Step 5 number of sub-cycles	84
W1012		Step 6 number of sub-cycles	84
W1013		Step 7 number of sub-cycles	84
W1014		Step 8 number of sub-cycles	84
W1015		Step 1 Frequency	84
W1016		Step 1 Ramp time	84

# INDEX

Start address	End address	Description	Page
W1017		Step 1 Step duration	84
W1018		Step 2 Frequency	84
W1019		Step 2 Ramp time	84
W1020		Step 2 Step duration	84
W1021		Step 3 Frequency	84
W1022		Step 3 Ramp time	84
W1023		Step 3 Step duration	84
W1024		Step 4 Frequency	84
W1025		Step 4 Ramp time	84
W1026		Step 4 Step duration	84
W1027		Step 5 Frequency	84
W1028		Step 5 Ramp time	84
W1029		Step 5 Step duration	84
W1030		Step 6 Frequency	84
W1031		Step 6 Ramp time	84
W1032		Step 6 Step duration	84
W1033		Step 7 Frequency	84
W1034		Step 7 Ramp time	84
W1035		Step 7 Step duration	84
W1036		Step 8 Frequency	84
W1037		Step 8 Ramp time	84
W1038		Step 8 Step duration	84
W1040		Enabling of PI function	74
W1041		Authorizing the direction of rotation	74
		Increase in the PI error	74
		PI set point value by the terminal	74
		Man. set point by the terminal	74
W1042		Assignment of analog input for the PI set point	75
W1043		Gain	74
W1044		Offset	74
W1045		Assignment of analog input for the sensor feedback	75
W1046		Min. feedback value for the sensor in user-defined units	74
W1047		Max. feedback value for the sensor in user-defined units	74
W1048		Minimum value for triggering the alarm	74
W1049		Maximum value for triggering the alarm	74
W1050		Assignment of analog input for the speed reference	75
W1051		Assignment of logic input for switching between man/auto mode	75
W1052		Assignment of logic input for reversing the direction of rotation	75
W1053		PI error ratio	74
W1054		PI set point value for the graphic keypad	74
W1055		Speed reference value for the graphic keypad	74

# INDEX

Start address	End address	Description	Page
W1056		Proportional gain	74
W1057		Integral gain	74
W1058		Assignment of analog output for the PI set point	75
W1059		Assignment of analog output for the PI feedback	75
W1060		Assignment of analog output for the PI error	75
W1061		Assignment of analog output for the PI integrator	76
W1062		Assignment of logic output indicating that the error has exceeded the set value	76
W1063		Assignment of logic output indicating that the process feedback is greater than the maximum set value	76
W1064		Assignment of logic output indicating that the process feedback is greater than the minimum set value	76
W1700		Selection of range to transfer	79
		Command to be used for the transfer	79
W1993		Proportional gain	44
W1994		Integral gain	44
W1995		Gain	44
W1996		Offset	44
W1997		Fault ratio	44
W1998		Terminal PI set point value	44
W1999		Terminal speed reference value	44
W2000		High speed	44
W2001		Low speed	44
W2002		1st acceleration ramp time	44
W2003		1st deceleration ramp time	44
W2004		2nd acceleration ramp time	44
W2005		2nd deceleration ramp time	44
W2006		Slip compensation : motor value	44
W2007		IR compensation	44
W2008		Profile	44
W2009		BOOST voltage	44
W2010		Damping	44
W2011		Bandwidth	44
W2012		Thermal protection	44
W2020		Speed controller reset	45
		Assignment of logic commands on line (DLI)	45
		Assignment of references on line (FLI)	45
		Ramp 2 command	45
		Communication check inhibited (NTO)	45
		Start/Stop command (RUN)	45
		DC injection braking command (DCB)	45
		Select orient stop	45

# INDEX

Start address	End address	Description	Page
		Select freewheel stop	45
		Select fast stop	45
		Voltage reduction command	45
		Select motor a	45
		Select motor b	45
		External fault command (EFL)	45
W2021		Frequency set point on line	46
W2022		State of logic output LO1	47
		State of logic output LO2	47
		State of output relay RO2	47
		State of output relay RO3	47
		State of output relay RO4	47
W2023		Value of output AO1	47
W2024		Current limit value	46
W2025		Motor torque limit value	46
W2026		Generator torque limit value	46
W2028		Motor voltage reduction value	46
W2029		Value of output AO2	47
W2030		Value of output AO3	47
W2031		Current limit command	46
		Operating direction	46
		Auto / man command	46
		Motor and generator torque limit command	46
		Preset speeds selection a	46
		Preset speeds selection b	46
		Preset speeds selection c	46
W2040		All commands assigned in LOCAL mode	48
		Speed controller ready (RDY or SLC)	48
		Faulty (FLT)	48
		Reset authorized	48
		Brake release relay energized	48
		Speed controller forced in LOCAL mode	48
		Communication check inhibited (NTO)	48
		Resettable fault	48
		Motor running	48
		Actual direction of rotation	48
		DC injection braking	48
		Steady state	48

# INDEX

Start address	End address	Description	Page
		Motor thermal overload alarm	48
		Overbraking alarm	48
		Current limit	48
		No power present	48
W2043		Display of activation of LO1	56
		Display of activation of LO2	56
		Display of activation of R1	56
		Display of activation of R2	56
		Display of activation of R3	56
		Display of activation of R4	56
W2044		Value of analog input AI1	57
W2047		Local control mode terminal block/keypad	49
		On line logic commands	49
		On line reference commands	49
		Dynamic braking (BRK)	49
		Fast stop in progress	49
		Controlled stop on loss of AC supply	49
		Output voltage deactivated freewheel stop	49
		Orient complete	49
		Decelerating (DEC)	49
		Accelerating (ACC)	49
		Motor selection	49
		Motor selection	49
		Speed controller thermal alarm	49
		Stopped via the keypad	49
W2048		JOG in progress	50
		Shutdown completed	50
		Cycle completed	50
		Ramp 2 in progress	50
		Auto/Man state	50
		Frequency threshold 1 reached	50
		Frequency threshold 2 reached	50
		Current threshold 1 reached	50
		Current threshold 2 reached	50
		Thermal threshold 1 reached	50
		Thermal threshold 2 reached	50
		No ramp follow	50
		External contactor in active state	50

# INDEX

Start address	End address	Description	Page
		Direction of rotation requested	50
W2049		Speed controller locked when stopped	50
		Invalid configuration	50
		OEM access protection indicator	50
		State of configuration semaphore	50
		State of command semaphore	50
W2050		Register of faults	51
W2051		Register of faults present	51
W2052		Output power	53
W2053		Output voltage	53
W2054		Supply voltage	53
W2055		Bus voltage	53
W2056		Motor thermal state value	53
W2057		Speed controller thermal state value	53
W2058		Motor running time elapsed (hours)	53
W2059		Motor running time elapsed (minutes)	53
W2060		Output speed	53
W2061		Machine speed reference (customer unit)	53
W2062		Machine frequency (customer unit)	53
W2063		Value of analog input AI2	57
W2064		Value of analog input AI3	57
W2065		Value of analog input AI4	57
W2071		Motor nominal voltage	55
W2074		No. of motor running or no. of set parameter	54
W2075		Current cycle step	54
W2076		Current preset speed number	54
W2100		Assignment of analog input AI1	57
W2101		Assignment of analog input AI2	57
W2102		Assignment of analog input AI3	57
W2103		Assignment of analog input AI4	57
W2104		Assignment of analog output AO1	58
W2105		Assignment of analog output AO2	58
W2106		Assignment of analog output AO3	58
W2107		Preset assignment of LO1 : set point reached	59
W2108		Preset assignment of LO2 :current limit	59
W2111		Preset assignment of R1 : fault	59
W2112		Preset assignment of R2 : run	59
W2113		Preset assignment of R3 : thermal state level 1	59

# INDEX

Start address	End address	Description	Page
W2114		Preset assignment of R4 : speed controller ready	59
W2115		Assignment of LI1 : Stop (not reconfigurable)	60
W2116		Assignment of LI2 : Forward operation (not reconfigurable)	60
W2117		Assignment of LI3 : Reverse operation	60
W2118		Assignment of LI4 : JOG	60
W2119		Assignment of LI5 : Preset speed a	60
W2120		Assignment of LI6 : Preset speed b	60
W2121		Assignment of LI7 : Preset speed c	60
W2122		Assignment of LI8 : Fault reset	60
W2140		Indicates position of marker on 1 of the 8 past faults	52
W2141		Past fault 1 : speed controller status	52
W2142		Past fault 1 : fault name	52
W2143		Past fault 2 : speed controller status	52
W2144		Past fault 2 : fault name	52
W2145		Past fault 3 : speed controller status	52
W2146		Past fault 3 : fault name	52
W2147		Past fault 4 : speed controller status	52
W2148		Past fault 4 : fault name	52
W2149		Past fault 5 : speed controller status	52
W2150		Past fault 5 : fault name	52
W2151		Past fault 6 : speed controller status	52
W2152		Past fault 6 : fault name	52
W2153		Past fault 7 : speed controller status	52
W2154		Past fault 7 : fault name	52
W2155		Past fault 8 : speed controller status	52
W2156		Past fault 8 : fault name	52
W2190		Status of memory card / ATV66 transfer	80
W2191		No. of selected page	80
		Blank page	80
W2200		Commercial rating for speed controller in constant torque	54
W2201		Configured speed controller rating	55
W2202		Speed controller voltage range	55
W2203		AC frequency recognized or not	55
W2205		Altivar nominal current	55
W2206		Speed controller maximum current	55
W2211		Memory card present	55
W2212		Communication Interface Option	55
W2213		Graphic keypad present	55





