



# S10 AC Drive



## INSTRUCTION MANUAL

Saftronics, Inc. retains the right to change specifications and illustrations in the text, without prior notification. The contents of this document may not be copied without the explicit permission of Saftronics, Inc.

# TABLE OF CONTENTS

<b>Foreword</b> .....	3
1. Safety Precaution .....	3
2. Examination before installation .....	4
<b>1. Safety Precautions</b>	
1.1 Precautions for operation .....	5
1.2 Precautions of operation environment .....	8
<b>2. Hardware Instruction and Installation</b>	
2.1 Operational Environment .....	9
2.2 Sample Model No. identification .....	10
2.3 Specifications .....	11
2.4 Wiring diagram .....	17
2.5 Dimensions & location of terminal block .....	20
2.6 Mounting instructions .....	33
<b>3. Software Index</b>	
3.1 Keypad operating instructions .....	35
3.2 Parameters list .....	36
3.3 Parameter function description .....	37
3.4 Malfunction indication and countermeasure .....	49
3.5 General malfunction examination method .....	52
<b>4. Trouble Shooting Procedure</b>	
4.1 Flow chart .....	53
4.2 Routine examination and periodical examination .....	60
4.3 Maintenance examination .....	61
4.4 Voltage current measurement .....	62
4.5 EMI filter (Class B) specification .....	63
4.6 DIN Rail specification .....	63
4.7 Specification of braking resistor and input reactor .....	63
4.8 Specification of braking resistor .....	64
4.9 Parameters table .....	65

## FOREWORD

To fully employ all functions of this AC Drive, and to ensure the safety for its users, please read through this operations manual in detail. Should you have any further questions, please feel free to contact your local distributor or regional representative.

### 1. SAFETY PRECAUTION

The AC Drive is a power electronic device. For safety reasons, please read carefully those paragraphs with "WARNING" or "CAUTION" symbols. They are important safety precautions to be aware of while transporting, installation, operating or examining the AC drive. Please follow these precautions to ensure your safety.

**⚠ WARNING** Personnel injury may be resulted by improper operation.

**⚠ CAUTION** The AC Drive or mechanical system may be damaged by improper operation.

#### **WARNING**

- Do not touch the PCB or components on the PCB right after turning off the power before the charging indicator went off.
- Do not attempt to wire circuitry while power is on. Do not attempt to examine the components and signals on the PCB while the inverter operating.
- Do not attempt to disassemble or modify internal circuitry, wiring, or components of the inverter.
- The grounding terminal of the inverter must be grounded properly with 200V class type III standard.
- This is a product of the restricted sales distribution class according to EN61800-3.

In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

#### **CAUTION**

- Do not attempt to perform dielectric strength test to internal components of the inverter. There are sensitive semiconductor-devices vulnerable to highvoltage in the inverter.
- Do not connect the output terminals: T1 (U), T2 (V), and T3 (W) to AC power input
- The CMOS IC on the primary PCB of the inverter is vulnerable to static electrical charges. Do not contact the primary PCB of the inverter.

## **2. EXAMINATION BEFORE INSTALLATION**

Every inverter has been fully tested and examined before shipment. Please carry out the following examination procedures after unpacking your AC inverter.

- Check to see if the model number of the AC inverter matches the model number of the AC inverter that you ordered.
- Check to see whether any damage occurred to the AC inverter during shipment. Do not connect the AC inverter to the power supply if there is any sign of damage.

Report this to a regional sale representative if you find any abnormal condition as mentioned above.

# 1. SAFETY PRECAUTIONS

## 1.1 PRECAUTIONS FOR OPERATION

### *Before turning ON power*

#### CAUTION

Choose the appropriate power source with correct voltage settings for the input voltage specification of the AC inverter.

#### WARNING

Special care must be taken while wiring the primary circuitry panel. The L1 and L2 terminal must be connected to the input power source and must not be mistakenly connected to T1, T2 or T3 output terminals. This may damage the inverter when the power is turned on.

#### CAUTION

- Do not attempt to transport the inverter by the front of the cover. Securely hold the inverter by the heat-sink mounting chassis to prevent the inverter from falling, this may cause personnel injury or damage to the inverter itself.
- Install the inverter onto a firm metal base plate or another non-flammable type material. Do not install the inverter onto or nearby any flammable material.
- An additional cooling fan may need to be installed if several inverters are installed into one control panel. The inside temperature inside an enclosed panel should be below 40 degrees to avoid overheating.
- Turn off the power supply before proceeding to remove or perform any work on any panel. Carry out installation procedures according to instructions given in order to avoid a situation resulting in an operational malfunction.
- Suitable for use on a circuit capable of delivering not more than 5000 RMS symmetrical amperes. 240 Volts maximum.
- This product is not provided with over speed protection.
- Only intended for use in a pollution degree 2 macro environment or equivalent.

## **When power is applied**

### **⚠ WARNING**

- Do not attempt to install or remove input or output connectors of inverter when the power supply is turned on. Otherwise, the inverter may be damaged due to the surge peak caused by the insertion or removal of power.
- When momentary power loss is longer than 2 seconds (the larger the horsepower, the the longer the time), the inverter does not have enough storage power to control the circuit; Therefore, when power is regenerated, the operation of the inverter is based on the setup of F\_10 and the condition of external switch, this is considered to be a restart in the following paragraphs.
- When the momentary power loss is short, the inverter still has enough storage power to control the circuit; therefore, when power is regenerated, the inverter will automatically start operation again depends on the setup of F\_23.

When restart the inverter, the operation of the inverter is based on the setup of F\_10 and the condition of external switch (FWD/REV button). Attention: the restart operation is irrelevant with F\_23/F\_24.

(1) When F\_10=0, the inverter will not start after restart.

(2) When F\_10=1 and the external switch (FWD/REV button) is OFF, the inverter will not start after restart.

(3) When F\_10=1 and the external switch (FWD/REV button) is ON, the inverter will start automatically after restart. Attention: Base on safety reason, please turn off the external switch (FWD/REV button) after power loss to avoid possible damage to the machine and the human body after sudden regeneration of power.

## **Under Operation**

### **⚠ WARNING**

Do not use a separate device to switch ON or OFF motor during operation. Otherwise, the inverter may experience an over-current breakdown.

### **⚠ WARNING**

- Do not remove the front cover of the inverter when the power is ON to avoid personnel injury caused by electrical shock.
- When the automatic restart function is enabled, the motor and machinery will be restarted automatically.

**▲ CAUTION**

- Do not touch the heat-sink base during operation.
- The inverter can be easily operated from a low-speed to high-speed range. Please reconfirm the operating range of motor and the machinery you are controlling.
- Do not examine the signals on the PCB of the inverter when it is under operation.
- All inverters are properly adjusted and set before delivery.

**▲ CAUTION**

Do not proceed with disassemble or examination procedure before ensuring that the power is off and the Power LED extinguished.

***When performing an examination or maintenance*****▲ CAUTION**

Inverter environment should be within temp:  $-10^{\circ}\text{C} \sim +40^{\circ}\text{C}$ , humidity under 95% RH without condensing.


**▲ CAUTION**

After the removal of shield sticker, the environment temperature should be within  $-10^{\circ}\text{C} \sim +50^{\circ}\text{C}$  and humidity under 95% RH without condensing. Besides, the inverter should be free from water dripping or metal dust.

## 1.2 PRECAUTIONS OF OPERATION ENVIRONMENT




Avoid any direct sunlight



Keep away from corrosive gas or liquid



Keep away from oil grease and gas




Keep away from salty environments



Keep away from rain or where dripping water may get into the inverter




Avoid metal dust and dusty environments



Avoid massive vibration




Avoid excessive direct heat



Avoid where environmental temperatures are too high



Keep away from high electrical-magnetic



Keep away from radioactive matter



Keep away from flammable material


## 2. HARDWARE INSTRUCTIONS AND INSTALLATION

### 2.1 OPERATIONAL ENVIRONMENT


The installation site of the inverter is very important. It relates directly to the functionality and the life span of your inverter. Please carefully choose the installation site to meet the following requirements:

- Mount the unit vertically
- Environment temperature:  $-10^{\circ}\text{C} \sim +40^{\circ}\text{C}$  (without shield sticker:  $-10^{\circ}\text{C} \sim +50^{\circ}\text{C}$ )
- Avoid placing close to any heating equipment
- Avoid water dripping or humid environment
- Avoid direct sunlight
- Avoid oil or salty corrosive gas
- Avoid contacting corrosive liquid or gas
- Prevent foreign dusts, flocks, or metal scraps from entering interior
- Avoid electric-magnetic interference (soldering or power machinery)
- Avoid vibration, if vibration cannot be avoided, an anti-rattle mounting device should be installed to reduce vibration.
- If the inverter is installed in an enclosed control panel, please remove the shield sticker located at the top of the inverter. This will allow additional airflow and cooling.

*External Fan Placement needs to be over the top of the inverter*




- For proper Installation of the inverter you must place the front side of the inverter facing front and the top of the inverter in the up direction for better heat dissipation.
- Installation must be compliant to the following requirements.



Note: Maximum temperature in the enclosure  $50^{\circ}\text{C}$

## 2.2 SAMPLE MODEL NO. IDENTIFICATION

Inverter Model	⇒	MODEL: S102001-XX
Input Power Rating	⇒	I/P: AC 1PH 200 ~ 240V 50/60 Hz
Output Rating	⇒	O/P: AC 3PH 0 ~ 240V 1 Hp 4.2 Amps



## 2.3 SPECIFICATIONS

### 2.3.1 Basic Specifications

Model : S10-		1F25-XX1X	1F50-XX1X	001-XX1X
Suitable Motor Power Rating (KW)		0.2	0.4	0.75
Rated	Motor (HP)	1/4	1/2	1
	Input Current (A)	6	10	16
	Output Current (A)	1.4	2.3	4.2
	Capacity (KVA)	0.53	0.88	1.6
	Weight (lb)	1.54	1.58	1.76
Input Voltage Max.		Single phase 100-120V (+10%, -15%), 50 / 60Hz (+/-5%)		
Output Voltage Max.		Three phase 200-240V (Proportional to input voltage)		
Dimension W*H*D (inches)		2.83 x 5.20 x 4.65		
EMC Specification		Without Filter		

Model: S10		2F25-X1XX*	2F50-X1XX*	2001-X1XX*	2002-XXXX	2003-XXXX
Suitable Motor Power Rating (KW)		0.2	0.4	0.75	1.5	2.2
Rated	Motor (HP)	0.25	0.5	1	2	3
	Input Current (A)	3	5.2	9.4	15	20
	Output Current (A)	1.4	2.3	4.2	7.5	10.5
	Capacity (KVA)	0.53	0.88	1.6	2.9	4.0
	Weight (lb)	1.68	1.10	1.76	3.66	3.88
Input Voltage Max.		Single/Three phase 200-240V (+10%, -15%), 50 / 60Hz (+/-5%)				
Output Voltage Max.		Three phase 200-240V (Proportional to input voltage)				
Dimension W*H*D (inches)		2.83 x 5.20 x 4.65			4.65 x 5.63 x 6.77	
EMC Specification		Class A (Single Phase Filter built in)				

Model : S10		4001-XXXX	4002-XXXX	4003-XXXX
Suitable Motor Power Rating (KW)		0.75	1.5	2.2
Rated	Motor (HP)	1	2	3
	Input Current (A)	2.6	4.6	6.5
	Output Current (A)	2.3	3.8	5.2
	Capacity (KVA)	1.7	2.9	4.0
	Weight (lb)	3.53	3.57	3.70
Input Voltage Max.		Three phase 380-480V (+10%, -15%), 50 / 60Hz (+/-5%)		
Output Voltage Max.		Three phase 380-480V (Proportional to input voltage)		
Dimension W*H*D (inches)		4.65 x 5.63 x 6.77		
EMC Specification		Class A (Three Phases Filter built in)		

\*Models are single phase only

## 2.3.2 Functional Specifications

Item		Specification
Input Signal Type		PNP type (SOURCE) input (External 24VDC Input is allowed)
Control Method		Sinusoidal wave PWM control
Freq. Control	Freq. Range	1~200 Hz*1
	Resolution Setting	Digital: 0.1 Hz (1 ~ 99.9 Hz); 1 Hz (100 ~ 200 Hz) Analog: 1Hz/ 60 Hz
	Keyboard Setting	Directly setup by ▲ ▼ buttons.
	External Signal Setting	0~10V, 4 ~ 20mA, 0 ~ 20mA
	Other function	Frequency upper and lower limit
General Control	Carrier frequency	4~16KHz*2
	Accelerate/Decelerate time	0.1~ 999 Sec
	V/F Pattern	6 Patterns
	Torque control	Torque boost level adjustable (manual torque boost)
	Multi-Functional input	2 point, to be used as multi-speed 1(Sp.1) / multi-speed 2(Sp.2) *1/ Jog / External emergency stop / External bb / Reset
	Multi-Functional output	1a Relay terminal, to be setup as Fault / Running / Frequency.
	Braking Torque	1P2~101/2P2~201>About 20% 202/203/401/402/403: 20%~100%, built-in braking transistor
Other function	Decelerate or free run stop, Auto reset, DC braking frequency / Voltage / Time can be setup by constants.	
Display		Three digital LED display frequency / inverter parameter / fault record / program version.
Operating temperature		-10 ~ +40°C (without shield sticker: -10°C ~ +50°C)
Humidity		0~95% RH non-condensing.
Vibration		Under 1 G (9.8 m/s <sup>2</sup> )
EMC specification		EN50081-1, EN50081-2, EN50178, EN61800-3 + All
UL		UL508C
Protection Function	Overload protection	150% for 1 min.
	Over-voltage	DC voltage > 410V(100/200 series); DC voltage > 800V(400 series)
	Under voltage	DC voltage < 200V(100/200 series); DC voltage < 400V(400 series)
	Momentary Power-loss	0 ~ 2 sec: The inverter can be restarted using speed search feature.
	Stall Prevention	During Acceleration / Deceleration/ Constant speed
	Output Short-circuit	Electronic circuitry protection
	Grounding fault	Electronic circuitry protection
	Other function	Heat sink overheat protection, Current limit
Installation		Mounting screw or DIN rail (Option).

Note: \*1: New function for CPU version v1.9 and above.

\*2: Carrier frequency range: CPU version v1.6 is 4~8kHz.

CPU version v1.9 and above are 4~16kHz.

### 2.3.3 Suitable optional and Wiring Specifications

#### Molded-Case Circuit Breaker / Magnetic Contact

● Warrantee does not apply to damage caused by the following situations:

(1) Damage to the inverter caused by the lack of appropriate molded-case circuit breaker or when a circuit breaker with too large of capacity is installed between the power supply and the inverter.

(2) Damage to the inverter caused by the magnetic contact, phase advancing capacitor, or surge-protector installed between the inverter and the motor.

Model Type	1F25/1F50/2F25/2F50	1001/2001/2002	2003	4001/4002/4003
Molded-case circuit breaker	15A	20A	30A	15A
Primary Circuit Terminal (TM1) 	Wire dimension (#14AWG) 2.0mm <sup>2</sup> Terminal screw M3	Wire dimension (#14AWG) 2.0mm <sup>2</sup> Terminal screw M3/M4	Wire dimension 3.5mm <sup>2</sup> Terminal screw M4	Wire dimension 3.5mm <sup>2</sup> Terminal screw M4
Signal Terminal (TM2) 1~11	Wire dimension 0.75mm <sup>2</sup> (#18 AWG), Terminal screw M3			

Use copper conductors only size field wiring based on 80 degrees C wire only.

- Please utilize three-phase squirrel-cage induction motor with appropriate capacity.
- If the inverter is used to drive more than one motor, the total capacity must be smaller than the capacity of the inverter. Additional thermal overload relays must be installed in front of each motor. Use the  $F_n_{18}$  at 1.0 times of the rated value specified on the motor nameplate at 50Hz, 1.1 times of the rated value specified on the motor nameplate at 60Hz.
- Do not install phase advancing capacitors, LC, or RC component between the inverter and the motor.

---

### **2.3.4 Application and precautions of peripherals**

#### **From the Power Source:**

- Apply the power source at the correct rated voltage to prevent from damaging the inverter.
- A Power Disconnect or Circuit breaker must be installed between the AC power supply and the inverter.

#### **Molded-case circuit breaker:**

- Utilize an appropriate circuit breaker that's suitable for the rated voltage and current ratings of the inverter to switch ON/OFF the power supply to the inverter and as additional protection for the inverter.
- Do not operate the circuit breaker to switch ON or OFF the inverter. The circuit breaker should be used only to supply input power and should not be used for operational sequence.

#### **Leakage circuit breaker:**

- An earth leakage circuit breaker should be added to prevent false operation cause by leakage current and to ensure personnel safety.

#### **Magnetic Contact:**

- The Magnetic Contact can be omitted at ordinary operation. To utilize external control, automatic restart, or breaking controller the magnetic contact must be added at the primary side.
- Do not operate the magnetic contact to switch ON or OFF the inverter.

#### **Power improvement AC Reactor:**

- If large capacity power source is applied (over 600KVA), additional AC reactor may be added to improve power factor.

#### **Inverter:**

- Power supply input terminals L1 and L2 are not differentiated on phase sequence. They can be arbitrarily connected. Their connection may be interchanged.
- Output terminal T1, T2, and T3 should be connected to the U, V, and W terminals of the motor respectively. If motor turns in opposite direction of the inverter command, simply exchanging two of the three wire connections will correct this problem.
- Output terminal T1, T2, and T3 must not be connected to power source to prevent from damaging the inverter.
- Grounding terminal Properly ground the grounding terminal in compliance to 200V class type three grounding. (The 400V class type is special grounding.)


External wiring should be carried out in accordance with following requirement. Check and reassure the wiring is correct after the wiring is complete.

(Do not utilize the control circuitry buzzer to check the wiring.)


#### EMI connections:

It is very important that the connections between the inverter, the shielded motor cable, and the EMI filters are tested as follows.


- Use a metal grounding plate and place the frequency inverter and the EMI filter on the plate.
- Use a shielded motor cable with 4 connectors (U, V, W, & Earth), don't use the shielding as safety earth (shield is high frequency earth)
- Remove any paint around the two metal coupling nut holes. So that the metal coupling nuts (and the shielding) make contact with the frequency inverter and the motor.
- Don't solder a conductor to the shielding.
- Use a metal clamp to connect the shielding from the motor cable with the metal grounding plate. Now there is a perfect high frequency earth connection between frequency inverter, grounding plate and EMI filter.
- Keep the distance between the frequency inverter and EMI filter as short as possible (< 11.8") if longer use a shielded cable with a metal coupling nut and a metal clamp to connect the shielded cable to the frequency inverter and metal grounding plate.
- The only earth connection between the LISN and the test plate should be via the EMI filter.
- Use a motor which equals the power rating or below of the inverter rating.
- Install a noise filter for inverter onto the output side of the primary circuitry can suppress conducting noise.



## Class A




- When the distance between the inverter and motor is longer than 330 ft (100 m) cable wire should be carefully chosen to reduce the wiring resistance below 3% and the voltage drop  $(V) = \sqrt{3} \times \text{Wire resistance (}\Omega/\text{km)} \times \text{wire length (m)} \times \text{current} \times 10^{-3}$
- Control circuitry wiring must be separated terminated and away from the primary power circuitry and other high-voltage or large-current power lines to avoid noise interference.
- To reduce the noise interference and avoid possible operational problems, shielded twisted pair cable should be used to wire the control circuitry. Please refer to following diagram. Connect the shielding wire onto the grounding terminal. Only connect one end of the shield.




Connect to system grounding terminal

### Wiring distance must be under 164 ft (50 m).


- The grounding terminal of the inverter must be correctly grounded in compliance with 200V class type three grounding.
- Grounding wire should be wired in accordance to electrical equipment (AWG) with the length of the grounding wire as short as possible.
- The grounding wire of the inverter must not be grounded together with other large current loads (such as soldering machines or large current motors). They should be grounded separately.



(a) good



(b) good




(c) not good

- Grounding circuitry must not be formed when grounding several inverters together.


(D) Wire specification, apply appropriate wire with correct diameter for primary power circuitry and control circuitry in accordance with electricity regulations.

## 2.4 WIRING DIAGRAM



Wire Terminations to the Inverter must be made with either UL listed field wiring lugs or UL listed crimp type ring terminals.

Note: Only for 2002/2003/4001/4002/4003.

**External 24V supply**

**Inverter terminal descriptions****Primary Circuitry Terminal Block (TM1) description**

Terminal Symbol	Function Description
L1/L (R)	Primary power source input to Drive Single phase: L1/L2 or L/N Three phase: L1/L2/L3
L2 (S)	
L3/N (T)	
P	External braking resistor terminal (Only for S10-2002/2003/4001/4002/4003)
R	
T1 (U)	Inverter output to Motor
T2 (V)	
T3 (W)	

Tightening torque for TM1 is 1 LBS-FT or 12 LBS-IN (1F25/1F50/2F25/2F50/2001).

Tightening torque for TM1 is 1.3 LBS-FT or 16 LBS-IN (2002/2003/4001/4002/4003)

\* Wire voltage rating must be a minimum of 300V(200V series)/600V(400V series)

**Control Circuitry Terminal Block (TM2) description**

Terminal Symbol	Function Description
1 TRIP	Fault relay output terminal Multi function output terminal (refer to F_21)
2 RELAY	Connection point rated capacity 250VAC/1A (30VDC / 1A)
3 FWD (FW)	Operation control terminals (refer to F_03)
4 REV (RE)	
5 + 12V(12)	Common point of terminal 3 / 4 / 6 / 7
6 SP1(SP)	Multifunction input terminals (refer to F_19)
7 RESET(RS)	
8 	+10V Power terminal for potentiometer ( Pin 3 )
9	Analog input wire Wiper Analog frequency signal input terminal ( Pin 2 of potentiometer or positive terminal of 0~10V / 4~20mA / 0~20mA)
10 0V(FM -)	Analog common point Analog signal common point ( Pin 1 of potentiometer or negative terminal of 0~10V / 4~20mA / 0~20mA )
11 FM+	Analog output positive connection point Analog frequency signal output terminal Output terminal signal is 0 ~ 10VDC/Fn6

Tightening torque for TM2 is 0.42 LBS-FT or 5.03 LBS-IN.

\* Wire voltage rating must be a minimum of 300V

\* Control wiring should not run in the same conduit or raceway with power or motor wiring


\* Single Input and Output Terminals (TM2) Ratings are ALL Class 2



## SW1 function description

SWITCH 1	External signal type
	0~20mA analog signal (When F_11 is set to 1) 4~20mA analog signal (When F_11 is set to 2)
	0~10 VDC analog signal (When F_11 is set to 1)

## 2.5 DIMENSIONS & LOCATION OF TERMINAL BLOCK


S10-1F20/1F50/1001/2F20/2F50/2001:






**S10-2002/2003/4001/4002/4003:**


Unit: inches

MODEL	LENGTH	A	B	C	D
S10-2002/2003/4001/4002/4003		5.63	5.02	5.51	0.32
MODEL	LENGTH	E	F	G	
S10-2002/2003/4001/4002/4003		6.76	4.25	4.65	

**Dimensions & Installation of class B Filter**


**DIMENSIONS****S10 NEMA4X (IP65 Indoor Duty) with operators (1F25/1F50/1001/2F25/2F50/2001)**


**INSTALLATION****S10 NEMA4X (IP65 Indoor Duty) with operators (1F25/1F50/1001/2F25/2F50/2001)****NOTE :**

1. Power switch, REV-0-FWD switch and potentiometer are only for NEMA4X units with operator devices
2. Power supply cable: #14 AWG (2.0mm<sup>2</sup>)
3. Motor cable: #16 AWG (1.25mm<sup>2</sup>)
4. Torque value of screw:
  - (1). Power/Motor cable (plug-in) terminal: 4.34in-lb (5kg-cm)
  - (2). Remote control wire: 3.47in-lb (4kg-cm)

## CONNECTION

### Circuit Diagram

S10 NEMA4X (IP65 Indoor Duty) with operators (1F25/1F50/1001/2F25/2F50/2001)



#### NOTE :



- Power switch, REV-0-FWD switch and potentiometer are only for NEMA4X units with operator devices
- Power supply cable: #14 AWG (2.0mm<sup>2</sup>)
- Motor cable: #16 AWG (1.25mm<sup>2</sup>)
- Torque value of screw:
  - (1). Power/Motor cable (plug-in) terminal: 4.34in-lb (5kg-cm)
  - (2). Remote control wire: 3.47in-lb (4kg-cm)
  - (3). Outer cover (M4): 5.20in-lb (6kg-cm)
- Input source: single-phase (L1, L2, ⚡), ensuring that it is connected to the appropriate power supply.
- Output motor: three-phase (⚡, T1, T2, T3)

#### Caution:

- Do not start or stop the inverter using the main circuit power.
- NEMA4X with operators: Always maintain REV-0-FWD switch at 0 position. This will ensure that the inverter has no running signal before power-on again after power supply has been interrupted. Otherwise, injury may result to personnel.


**CONNECTION**

S10 NEMA4X (IP65 Indoor Duty) (1F25/1F50/1001/2F25/2F50/2001)


**EMC MOUNTING**

## CONNECTION

S10 NEMA4X (IP65 Indoor Duty) with operators (1F25/1F50/1001/2F25/2F50/2001)




## EMC MOUNTING




**DIMENSIONS**

S10 NEMA4X (IP65 Indoor Duty) with operators (2002/2003/4001/4002/4003)



## INSTALLATION

S10 NEMA4X (IP65 Indoor Duty) with operators (2002/2003/4001/4002/4003)




### NOTE :

1. Power switch, REV-0-FWD switch and potentiometer are only for NEMA4X units with operator devices
2. Power supply cable: **230V** #12 AWG (3.5mm<sup>2</sup>); **460V** #16 AWG (1.25mm<sup>2</sup>)
3. Motor cable: **230V** #14 AWG (2.0mm<sup>2</sup>); **460V** #16 AWG (1.25mm<sup>2</sup>)
4. Torque value of screw :
  - (1). Power/Motor cable (TM1, TM3)  
Terminal: 6.94in-lb (8kg-cm)
  - (2). Remote control wire: 3.47in-lb (4kg-cm)
  - (3). Outer cover (M4): 6.94in-lb (8kg-cm)

\*Models 2003 & 2003 with operator devices are single phase input only.

**CONNECTION****Circuit Diagram**

S10 NEMA4X (IP65 Indoor Duty) with operators (2002/2003/4001/4002/4003)

**NOTE :**


1. Power switch, REV-0-FWD switch and potentiometer are only for NEMA4X units with operator devices
2. Power supply cable: #12 AWG (3.5mm<sup>2</sup>)
3. Motor cable: #16 AWG (1.25mm<sup>2</sup>)
4. Torque value of screw:
  - (1). Power/Motor cable (plug-in) terminal: 4.34in-lb (5kg-cm)
  - (2). Remote control wire: 3.47in-lb (4kg-cm)
  - (3). Outer cover (M4): 5.20in-lb (6kg-cm)
5. Input source: single-phase or three-phase (L1, L2, L3,  $\varnothing$ ) ensuring that it is connected to a 200/240V or a 460/480V supply. (Models 2002 & 2003 with operator devices are single phase input only.)
6. Output motor: three-phase ( $\varnothing$ , T1, T2, T3)

**Caution:**


- Do not start or stop the inverter using the main circuit power.
- NEMA4X with operators: Always maintain REV-0-FWD switch at 0 position. This will ensure that the inverter has no running signal before power-on again after power supply has been interrupted. Otherwise, injury may result to personnel.

## CONNECTION

S10 NEMA4X (IP65 Indoor Duty) (2002/2003/4001/4002/4003)





## EMC MOUNTING



**NOTE:** For ALL MODELS WITH FILTERS additional items will be found inside the box including: [1]pc of EMC conformed waterproof (IP65) ferrite core; [1]pc of metal fastener; [1]pc of MF Zin 5-C screw.


**CAUTION:** If application use requires you to meet EMC regulation, you **MUST** first constrain the motor cables, close the ferrite core onto the motor cable outside the plastic enclosure as indicated in the above diagram.

**Please Note:** The length of the motor cable **CANNOT** exceed 5M under EMC regulation.


**CONNECTION****S10 NEMA4X (IP65 Indoor Duty) with operators (2002/2003/4001/4002/4003)**

**EMC MOUNTING**


S10 NEMA4X (IP65 Indoor Duty) with operators (2002/2003/4001/4002/4003)




## 2.6 MOUNTING INSTRUCTIONS



Inverter with class B filter mounted




Inverter with class B filter & Din rail mounted kit.





## Din Rail Mounting Diagram

Step 1 -  
Aim and insert  
the 4 retention  
ribs of the DIN  
Rail at the 4  
holes in rear  
panel of inverter



Step 2 -  
Push the DIN  
Rail forward until  
the middle rib  
grips firmly with  
back panel




Step1-  
Use a small  
screwdriver  
inserting it into  
the middle rib  
of DIN Rail  
and press the  
screwdriver in  
order to  
remove the  
DIN Rail from  
inverter


## DIN Rail Installation

A mounting clamp and a 1.38" width rail must be used to install the drive on the rail.

Install Drive



Dismounting Drive




First place the groove on the back of module on the upper edge of din rail, and then push the module down to lock up position. Finally press the mounting plate upward into module.

1. Pull the mounting plate downward.
2. Rotate the inverter module to dismount it.

## 3. SOFTWARE INDEX

### 3.1 KEYPAD OPERATING INSTRUCTIONS


#### Keypad Description



#### **⚠ Caution**

Do not operate keypad by screwdriver or other sharp-ended tool to avoid damaging keypad.

#### Brief keypad operation flowchart



Note 1: Displayed setting of frequency when stopped. Display output frequency when running.

Note 2: The setting of the frequency can be modified either when stopped or when running.

## 3.2 PARAMETER LIST

Function	F_	Function Description	Unit	Range	Factory setting	Page	Note	
	0	Factory Adjustment			0	26		
Accel. Time	1	Accel. time	0.1Sec	0.1 ~ 999 S	5.0	26	*1 *3	
Decel. Time	2	Decel. time	0.1Sec	0.1 ~ 999 S	5.0	26	*1 *3	
Operation mode	3	0: Forward / Stop, Reverse / Stop 1: Run/Stop, Forward / Reverse	1	0 1	~ 0	27		
Motor rotation direction	4	0: Forward 1: Reverse	1	0 1	~ 0	27	*1	
V/F Pattern	5	V/F pattern setting	1	1 ~ 6	1/4	28	*2	
Frequency upper/lower limit	6	Frequency upper limit	0.1Hz	1 ~ 200	50/60Hz	29	*2 *3	
	7	Frequency lower limit	0.1Hz	1 ~ 200	0.0Hz	29	*3	
SPI frequency	8	SP1 frequency	0.1Hz	1 ~ 200	10Hz	29	*3	
JOG frequency	9	JOG frequency	0.1Hz	1 ~ 200	6Hz	29		
Start / Stop Control	10	0: Keypad 1: Terminal (TM2)	1	0 1	~ 0	30		
Frequency Control	11	0: Keypad 1: Terminal (0~10v / 0~20mA) 2: Terminal (4~20mA)	1	0 2	~ 0	30		
Carrier frequency control	12	Carrier Frequency Setting	1	1 ~ 5 (1~10)*4	5	31		
Torque compensation	13	Torque compensation gain	0.1%	0.0 ~ 10.0%	0.0%	31	*1	
Stop method	14	0: controlled deceleration stop 1: free run to stop	1	0 1	~ 0	32		
DC braking setting	15	DC braking time	0.1S	0.0 ~ 25.5S	0.5S	32		
	16	DC braking injection frequency	0.1Hz	1 ~ 10Hz	1.5Hz	32		
	17	DC braking level	0.1%	0.0 ~ 20.0%	8.0%	32		
Electronic thermal Overload protection	18	Protection base on motor rated current	1%	50 ~ 100% (0~200)*4	100%	32		
Multifunction input connection point	19	Multifunction input terminal 1 (SP1) function	1: Jog 2: Sp1 3: Emergency stop			2	33	
	20	Multifunction input terminal 2 (RESET) function	4: External Base Block 5: Reset 6: SP2*4			5	33	
Multi-function output	21	Multifunction output terminal	1: Operating 2: Frequency reached 3: Fault			3	34	

Function	F_	Function Description	Unit	Range	Factory setting	Page	Note	
Reverse Lock-Out	22	0: REV run 1: REV run Lock-Out	1	0 1	~ 0	35		
Momentary power loss	23	0: enabled 1: disabled	1	0 1	~ 0	35		
Auto restart	24	Number of Auto-restart times	1	0 ~ 5	0	36		
Factory setting	25	010: Constants initialization to 50Hz system 020: Constants initialization to 60Hz system					36	*2
SP2 frequency	26	SP2 frequency	0.1Hz	1.0~200Hz	20	37		
SP3 frequency	27	SP3 frequency	0.1Hz	1.0~200Hz	30	37		
Direct start	28	0:enable 1:disable	1	0 1	~ 1	37	*4	
Software version	29	CPU program version					37	
Fault Log	30	Fault log for three faults.					37	

**NOTE:**

\*1: Indicate this parameter can be adjusted during running mode.

\*2: Please refer to F\_25.

\*3: If the setting range is above 100, the setting unit becomes 1.

\*4: New function for CPU version V2.1 and above

### 3.3 PARAMETER FUNCTION DESCRIPTION

**F\_00** Factory adjustment parameter. Do not change.


**F\_01** : Acceleration time = 0.1 ~ 999 sec

**F\_02** : Deceleration time = 0.1 ~ 999 sec

#### 1. Acceleration / Deceleration time calculation formula:



Accelerate time = F\_01 x  $\frac{\text{Setting Frequency}}{60 \text{ Hz}}$

Decelerate time = F\_02 x  $\frac{\text{Setting Frequency}}{60\text{Hz}}$



**F\_03: Operation mode selection = 0: Forward / Stop, Reverse / Stop  
1: Run / Stop, Forward / Reverse**

NOTE 1: F\_03 takes effect only when F\_10 = 1 (external operation control)



Note: Reverse command is ignored when F\_22 = 1

**F\_04: Motor rotation direction setting = 0: Forward  
1: Reverse**

Although there is no Forward / Reverse push button on the digital control panel, it is possible to adjust forward / reverse function by changing the F\_04 setting.

NOTE: When F\_22 = 1: Reverse is disabled, the F\_04 cannot be set to 1.

The keypad indication would display "LOC".

**F\_05: V/F pattern setting = 1 ~ 6**

Selecting F\_05 = 1-6 to select one of the six preset V/F patterns. (Refer to the following tables)


Specification	50 Hz System		
Application	General Application	High starting torque	Decreasing torque
F_5	1	2	3
V/F pattern			
Specification	60Hz System		
Application	General Application	High starting torque	Decreasing torque
F_5	4	5	6
V/F pattern			

F_5	B	C
1/4	10%	8%
2/5	15%	10.5%
3/6	25%	7.7%

**F\_06: frequency upper limit range = 1~120Hz**

**F\_07: frequency lower limit range = 1~120Hz**

F\_06: Factory setting refers to F\_25.



**NOTE:**

**If F\_07 = 0 Hz,**

The frequency instruction is equal to 0Hz, the inverter will stop at 0 speed.

**If F\_07 > 0 Hz,**

The frequency instruction F\_07, the inverter will output a minimum speed according to the setting in F\_07


**F\_08: SP1 frequency = 1 ~ 200 Hz**

**F\_09: JOG frequency = 1 ~ 200 Hz**

1. When F\_19 or F\_20 = 2 and the multifunction input terminal is ON, the inverter operates at sp1 frequency (F\_08)
2. When F\_19 or F\_20 = 1 and the multifunction input terminal is ON, the inverter operate at jog frequency (F\_09)
3. The priority of reading frequency setting is: Jog? Sp1?Keypad setting or external frequency signal using a speed pot.

**F\_10: Start / Stop Control** = 0: Keypad  
= 1: Terminal (TM2)

**NOTE: When F\_10=1 (Terminal Control), emergency stop on the Keypad is enabled.**  
When F\_10=1, please refer to the descriptions of F\_23/24, in order to avoid the damage to the human and the machine.




**F\_11: Speed Control** = 0: Keypad  
= 1: Analog Speed Pot Terminal (TM2) (0 ~ 10V / 0-20mA)  
= 2: Analog Speed Pot Terminal (TM2) (4-20mA)

**NOTE 1:**

When jog frequency or Sp1 frequency is switched on, the frequency is setup by Sp1 speed, the ▲▼ buttons on the keypad is disabled. Original setting will be restored after the Sp1 connection is removed.

**NOTE 2:**

During the contact closure of the jog function, the keypad control remains in a sleep state until the jog contact connection is re-opened.



**F\_12: Carrier Frequency = 1 ~ 10**

F_12	Carrier frequency	F_12	Carrier frequency	F_12	Carrier frequency
1	4 kHz	5	8 kHz	9	15 kHz*1
2	5 kHz	6	10 kHz*1	10	16 kHz*1
3	6 kHz	7	12 kHz*1		
4	7.2 kHz	8	14.4 kHz*1		

**NOTE:**


\*1: Available for CPU version V1.9 and above.

2: If F\_12=7~10, the inverter must operator with low load.

Although an IGBT TYPE inverter can provide a low audible noise level during its operation, it is possible that the switching of the high carrier frequency may interfere with external electronic components (or other controllers) or even cause vibration in the motor. Adjusting the carrier frequency can usually correct this problem.

**F\_13: Torque compensation gain = 0 ~ 10 %**

To enhance Inverter output torque patterns according to the B, C voltage points on the V/F pattern (refer to F\_05 description) and the (F\_13) for this feature.



**NOTE:** When F\_13 = 0, the torque boost function is disabled.

**F\_14 Stopping method = 0 : Controlled deceleration stop**

**= 1 : free run to stop**


**F\_15 DC braking time = 0 ~ 25.5 sec**

**F\_16 DC braking starting frequency = 1 ~ 10 Hz**

**F\_17 DC braking level = 0 ~ 20 %**

**If F\_14 = 0**

When the inverter receives the stop command, it decelerate to the pre-set frequency setup by F\_16 after this the output voltage level that is set in the F\_17; will determine the amount of DC voltage that's injected into the motor. The time duration to perform this stopping function is setup in F\_15.



**If F\_14 = 1**

The inverter stops output immediately after receiving the stop command. The motor will enter into a free running state until it comes to a complete stop.

**F\_18: Motor rated current = 50 ~ 200 %**

**1. The electronic thermal overload protection for motor:**

(1) Motor rated current = Inverter rated current x F\_18

$F_{18} = \text{Motor rated current} / \text{inverter rated current}$

(2) When the load is within 100% of the motors rated current, the operation continues. When the load reaches 150% of the motors rated current the operation is allowed to continue for 1 minute. (Refer to curve (1) in Figure 3)


(3) After protecting the motor with the electronic thermal switch activated, the inverter is cut off immediately. The OLI light will flash. To resume operation, push the RESET button or activate an external reset connection wired to terminal 2.

(4) When the motor is operating at low speeds, the heat dissipation efficiency is lower. The electronic thermal activation level is also reduced. (to change from curve (1) to curve (2) in Figure 3. Choose the appropriate F\_05 setting according to the applied motor to reach the desired performance.

## 2. The electronic thermal protecting for inverter:

(1) When the load is within 103% of the inverters rated current, the operation continues. When the load reaches 150% of rated current of the inverter, the operation will continue for 1 minute. (Refer to curve (1) of figure 3)

(2) After the activation of the electronic thermal switch, the inverter is shut off immediately. The OL2 light will flash. To resume the operation, push RESET button or activate an external reset contact on terminal 2.



**F\_19: Multifunctional input terminal 1 function = 1- 5 (1-6:CPU version v1.9 and above)**

**F\_20: Multifunctional input terminal 2 function = 1- 5 (1-6:CPU version v1.9 and above)**

1. F\_19=1 or F\_20 =1: JOG control (refer to F\_09)
2. F\_19, F\_20 =2 or 6 Multi-speed control:  
F\_19=2 & F\_20=6:

TM2 SP1 Terminal	TM2 RESET Terminal	Output frequency
ON	OFF	F_08
OFF	ON	F_26
ON	ON	F_27

**F\_19=6 & F\_20=2:**



TM2 SP1 Terminal	TM2 RESET Terminal	Output frequency
ON	OFF	F_26
OFF	ON	F_08
ON	ON	F_27

### 3. F\_19, F\_20 =3: External emergency stop

When the external emergency stop signal is activated, the inverter proceeds to decelerate and stop, (ignoring the setting of F\_14). The inverter's E.S. light will flash after stopping. After the emergency stop signal is deactivated, turn the RUN switch OFF and then ON again to cycle it. (F\_10 = 1) Or, push the RUN key (F\_10 = 0). The inverter will then resume operation and restart. If the emergency stop signal is removed before the inverter stops, the inverter will still execute the emergency stop.

### 4. F\_19, F\_20 =4: External Base Block (Immediate Shut Down)

When the external base block signal is activated, the inverter output will be immediately shut off (ignoring the setting of F\_14) and flash b.b. Light. After the base block signal is deactivated, turn the RUN switch OFF and then ON again (F\_10 = 1) or push the RUN key (F\_10 = 0), the inverter will restart from the original starting frequency.




5. F\_19, F\_20 = 5: Auto Reset when inverter faults.

### F\_21: Multi-function output terminal control = 1 ~ 3

1. F\_21 = 1: Run mode signal
2. F\_22 = 2: At Frequency Speed Signal
3. F\_21 = 3: Fault signal

Terminal1 and2 of TM2 are activated at CPF, OL1, OL2, OCS, OCA, OCC, Ocd , Ocb , OVC , LVC , OHC.



**F\_22: Reverse Lock-Out** = 0: REV command  
= 1: REV command Lock-out

**NOTE:**

When F\_04 is set to 1 (reverse), F\_22 cannot be set to 1, in order to properly lockout a motors direction, F\_04 must be set at 0 before setting F\_22 to 1.

**F\_23: Auto-restart after momentary power loss** = 0: auto-restart enabled  
= 1: auto-restart disabled

- When the AC power supply is temporary below low voltage protection levels because of power company issues or encountering large current loading in the same power supply system, the inverter will stop its output immediately. If the power source resumes within 2 seconds, the inverter can restart by using its speed search program.
- When F\_23=0:
  - If the momentary power loss is less than 2 seconds, the inverter resume operation automatically via speed search at 0.5 seconds after power up. The number of auto-restart times is not limited by F\_24.
  - If the momentary power loss is long, the operation of the inverter is based on the setup of F\_10 and the condition of external switch.
  - If the time of momentary loss is between the above two, whether the inverter will auto-restart depends on F\_24:  
F\_24=0: auto-restart disabled.  
F\_24=1-5: auto-restart enabled 1-5 times.

3. When F\_23=1,
  - (1) Power up after momentary power loss, the inverter will not start. Even under F\_24>0.
  - (2) If the momentary power loss is long, the inverter must be restart manually. The operation of the inverter is based on the setup of F\_10 and the condition of external switch.
4. When restart the inverter, the operation of the inverter is based on the setup of F\_10 and the condition of external switches (FWD/REV button).
  - (1) When F\_10=0, the inverter will not start after restart.
  - (2) When F\_10=1 and the external switch (FWD/REV button) is OFF, the inverter will not start after restart.
  - (3) When F\_10=1 and the external switch (FWD/REV button) is ON, the inverter will start automatically after restart. Attention: Base on safety reason, please turn off the external switch (FWD/REV button) after power loss to avoid possible damage to the machine and the human body after sudden regeneration of power.

**F\_24: Number of Auto-restart times = 0~5**

1. When F\_24=0, the inverter will not auto-restart after a malfunction break away from operation. (Except for momentary power loss, please refer to F\_23 for details)
2. When F\_24=1~5: the inverter will resume operation via speed search at 0.5 second under auto-restart after malfunction break away. (Except for momentary power loss, please refer to F\_23 for details).
3. When the inverter is set to deceleration or DC breaking, the transient restart procedure is not performed.
4. If either of following situations should develop, the auto restart times will be reset:
  - (1) No additional malfunction (in operation or stop) occurs within 10 minutes.
  - (2) Press RESET button.

**F\_25: Return to Factory Pre-Settings = 010: Constants initialization to 50Hz system  
= 020: Constants initialization to 60Hz system**

1. When F\_25 is set to 010, all parameters are restored to factory settings. The settings of F\_05 =1 and F\_06 = 50. F\_25 is restored back to 000 after the reset process is complete. (50Hz operation)
2. When F\_25 is set to 020, all parameters are restored to factory settings. The settings of F\_05 =4 and F\_06 = 60. F\_25 is restored back to 000 after the reset process is complete. (60Hz operation)

**F\_26: SP2 (1~200Hz) , Multi-speed 2 (Reference to F\_19 / F\_20)**

**F\_27: SP3 (1~200Hz) , Multi-speed 3 (Reference to F\_19 / F\_20)**

**F\_28: Direct start = 0 : Direct start enable when remote Run command on  
= 1 : Direct start disable when remote Run command on**

(CPU version V2.1 and above)

When F\_28 = 1 and control mode is remote control (F\_10 = 1), Inverter can not start if RUN switch is ON when power is engaged, Must be turned the RUN switch OFF and turned ON again, Then Inverter can start.

**F\_29: CPU program version**

**F\_30: Last three faults**

1. Last three faults: indicate the sequence of the occurrence of malfunctions by the location of decimal point. **x.xx** indicates a recently happened malfunction. **xx.x** indicates the last malfunction that happened. **xxx.** Indicates the earliest malfunction in the record.
2. After entering the F\_30 function, the **x.xx** trip record will be displayed first. After that, press **▲** button and you can read activity in a chronological order. **xx.x → xxx. → x.xx →,,,** consecutively.
3. After entering F\_30 function, if the RESET button is pressed, the trip record will be cleared. Indication display **-.-, --.-, and ---.**
4. When the content of trip indicates O.CC, it will indicate the latest trip code is OC-C and so on.

### 3.4 MALFUNCTION INDICATIONS AND COUNTERMEASURES

#### 1. Manual reset inoperative malfunctions

INDICATION	CONTENT	POSSIBLE CAUSE	COUNTERMEASURE
CPF	Program error	Outside noise interference	Place a RC surge absorber in parallel with the noise generating magnetic contact
EPR	EEPROM error	EEPROM defective	Replace EEPROM
OV	Voltage too high while not operating	1.Power source voltage too high. 2.Detection circuitry defective	1. Examine the power supply 2.Return the inverter for repair
LV	Voltage too low while not operating	1.Power source voltage too low. 2.Detection circuitry defective.	1.Examining the power supply 2.Return the inverter for repair
OH	Inverter over heat while not operating	1.Detection circuit defective. 2.Environment over-heat or poor ventilation	1.Return the inverter for repair 2. Improve ventilation

#### 2. Manual reset operative malfunctions (Auto-Reset inoperative)

INDICATION	CONTENT	POSSIBLE CAUSE	COUNTERMEASURE
OC	Over-current at stop condition	Detection circuit malfunction	Return the inverter for repair
OL1	Motor over-load	1. Loading too large 2. Improper V/F model setting 3. Improper F_18 setting	1. Increase capacity of motor 2. Adjust to use a proper V/F curve setting 3. Adjust F_18 according to instruction
OL2	Inverter over-load	1. Loading too large 2. Improper V/F model setting	1. Increase capacity of inverter 2. Adjust to use a proper V/F curve setting

### 3.Manual Reset and Auto-Reset Operative Malfunction

INDICATION	CONTENT	POSSIBLE CAUSE	COUNTERMEASURE
<b>OCS</b>	Transient over-current starting machine	<ol style="list-style-type: none"> <li>1.Motor coil short-circuit with external casing</li> <li>2.Motor connection wire short-circuit with grounding</li> <li>3.Transistor module damaged</li> </ol>	<ol style="list-style-type: none"> <li>1.Examining motor</li> <li>2.Examining wiring</li> <li>3.Replace transistor module</li> </ol>
<b>OCA</b>	Over-current at acceleration	<ol style="list-style-type: none"> <li>1.Acceleration time setting too short</li> <li>2.Improper V/F feature selection</li> <li>3.Applied motor capacity exceeds inverter capacity</li> </ol>	<ol style="list-style-type: none"> <li>1.Adjust acceleration time to longer setting</li> <li>2.Adjust to a proper V/F curve</li> <li>3.Replace and install another inverter with appropriate capacity</li> </ol>
<b>OCC</b>	Over-current at steady speed	<ol style="list-style-type: none"> <li>1.Transient alteration of the loading</li> <li>2.Transient alteration of the power supply</li> </ol>	<ol style="list-style-type: none"> <li>1.Examining the loading configuration</li> <li>2.Install inductor on the power supply input side</li> </ol>
<b>Ocd</b>	Over-current at deceleration	Deceleration setting too short	Adjust to use a longer acceleration time
<b>OCb</b>	Over-current at breaking	DC Breaking frequency, breaking voltage, or breaking time setting too long	Adjust to reduce settings of F_15, F_16, or F_17
<b>OVC</b>	Over-voltage at operation/deceleration	<ol style="list-style-type: none"> <li>1.Deceleration time setting too short or inertial loading too large</li> <li>2.Power supply voltage variation too large</li> </ol>	<ol style="list-style-type: none"> <li>1.Adjust to use a longer deceleration time</li> <li>2.Install an inductor on the power supply input side</li> <li>3.Increase the capacity of inverter</li> </ol>
<b>LVC</b>	Insufficient voltage level at operation	<ol style="list-style-type: none"> <li>1.Power supply voltage too low</li> <li>2.Power supply voltage variation too large</li> </ol>	<ol style="list-style-type: none"> <li>1.Improve power source quality</li> <li>2.Adjust to use a longer acceleration time</li> <li>3.Increase capacity of inverter</li> <li>4.Install a reactor on the power supply input side</li> </ol>
<b>OHC</b>	Heat-sink over heated at operation	<ol style="list-style-type: none"> <li>1.Loading too heavy</li> <li>2.Ambient temperature too high or poor ventilation</li> </ol>	<ol style="list-style-type: none"> <li>1.Examining the loading</li> <li>2.Increase capacity of inverter</li> <li>3.Improve ventilation</li> </ol>

## Special Condition Description

INDICATION	CONTENT	DESCRIPTION
<b>SP0</b>	Zero Speed Stopping	When F_11 = 0, F_7= 0 and frequency setting < 1 Hz When F_11 = 1, F_7<(F_6/100), and frequency setting <(F_6/100)
<b>SP1</b>	Fail to start directly	<ol style="list-style-type: none"> <li>If the inverter is set to external operation (F_10 = 1) and direct start is disabled (F_28 = 1), the inverter cannot be started and will flash SP1 when operation switch turned to ON after applying power (see descriptions of F_28).</li> <li>Direct start is possible when F_28 = 0.</li> </ol>
<b>SP2</b>	Keypad emergency stop	The inverter setup to external operation (F_10=1). If the STOP key in the keypad is pressed at the middle of operation, the inverter stops according the setting in F_14 and flash SP2 after stop. The RUN switch must be turned OFF than ON to restart the machine.
<b>E.S.</b>	External emergency stop	When the external emergency stop signal is activated through the multi-function input terminal, the inverter decelerates and stops. Inverter flashes E.S. after stops. (Refer to instruction for F_19 for detail).
<b>b.b.</b>	External BASE BLOCK	When the external BASE BLOCK signal is activated through the multifunction terminal, the inverter stop output immediately and flash b.b. for indication. (Refer to instruction for F_19 for detail)

## Keypad Operation Error Instruction


INDICATION	CONTENT	POSSIBLE CAUSE	COUNTERMEASURE
<b>LOC</b>	Motor direction locked	<ol style="list-style-type: none"> <li>Attempt to reverse direction when F_22 = 1</li> <li>Attempt to set F_22 to 1 when F_04 = 1</li> </ol>	<ol style="list-style-type: none"> <li>Adjust F_22 to 0</li> <li>Adjust F_04 to 0</li> </ol>
<b>Er1</b>	Keypad operation error	<ol style="list-style-type: none"> <li>Press ▲ or ▼ keys when F_11=1 or under sp1 operation</li> <li>Attempt to modify F_29</li> <li>Attempt to modify parameter that is not allowed to be modified during operation (refer to parameter list)</li> </ol>	<ol style="list-style-type: none"> <li>Use ▲ or ▼ keys to adjust frequency setting only after F_11=0</li> <li>Do not modify F_29</li> <li>Modify in stop mode</li> </ol>
<b>Er2</b>	Parameter setting error	<ol style="list-style-type: none"> <li>F_6 ≤ F_7</li> </ol>	<ol style="list-style-type: none"> <li>F_6 &gt; F_7</li> </ol>

### 3.5 GENERAL MALFUNCTION EXAMINATION METHOD


ABNORMALITY	CHECK POINT	COUNTERMEASURE
<b>Motor Inoperative</b>	Is the power source voltage delivered to L1, L2 terminal (is the charging indicator illuminated)?	<ul style="list-style-type: none"> <li>● Check if the power source on.</li> <li>● Turn power source OFF and then ON again.</li> <li>● Reconfirm the power voltage level.</li> </ul>
	Is there voltage output from output terminal T1, T2 and T3?	<ul style="list-style-type: none"> <li>● Turn power source OFF and then ON again.</li> </ul>
	Is the motor wired correctly?	<ul style="list-style-type: none"> <li>● Check motor wiring.</li> </ul>
	Is there any abnormal condition of the inverter?	<ul style="list-style-type: none"> <li>● Refer to malfunction handling instructions to examine and correct wiring.</li> </ul>
	Is the forward or reverse instruction loaded?	
<b>Motor Inoperative</b>	Is the analog frequency setting loaded?	<ul style="list-style-type: none"> <li>● Check to see if wiring for analog frequency input signal is correct?</li> </ul>
	If the operation mode setting correct?	<ul style="list-style-type: none"> <li>● Check if the frequency input setting voltage is correct?</li> </ul>
<b>Motor operate in opposite direction</b>	Is wiring on the output terminals T1, T2 and T3 correct?	<ul style="list-style-type: none"> <li>● Operate by digital?</li> </ul>
	Is the wiring for the forward and reverse signals correct?	<ul style="list-style-type: none"> <li>● Wiring should be in accordance with the U, V, W terminals of motor.</li> </ul>
<b>Motor operation speed fixed</b>	Is the wiring for analog frequency input correct?	<ul style="list-style-type: none"> <li>● Examining the wiring and correct it.</li> </ul>
	Is the operation mode setting correct?	<ul style="list-style-type: none"> <li>● Examining the wiring and correct it.</li> </ul>
	Is the loading too heavy?	<ul style="list-style-type: none"> <li>● Check the Operation panel</li> </ul>
<b>Motor operation at speed too high or too low</b>	Is the specification of motor (poles, voltage) correct?	<ul style="list-style-type: none"> <li>● Reduce loading</li> </ul>
	Is the gear ratio correct?	<ul style="list-style-type: none"> <li>● Reconfirm motor specification.</li> </ul>
	Is the highest output frequency setting correct?	<ul style="list-style-type: none"> <li>● Reconfirm gear ratio</li> </ul>
	Is the voltage on motor side reduced extremely?	<ul style="list-style-type: none"> <li>● Reconfirm highest output frequency</li> </ul>
<b>Abnormal speed variation at operation</b>	Is the loading too heavy?	<ul style="list-style-type: none"> <li>● Reduce loading variation</li> </ul>
	Is the loading variation too large?	<ul style="list-style-type: none"> <li>● Increase inverter and motor capacity</li> </ul>
	Is the input power source steady and stable?	<ul style="list-style-type: none"> <li>● Install AC reactor on the power supply input side</li> </ul>

## 4. TROUBLESHOOTING PROCEDURES


### 4.1 FLOW CHART




## (Continued)




## Error handling of malfunction indication of OC.O.L





## Error handling of malfunction indication of OV.LV



## (1). Motor inoperative



**(2). Motor over-heat**

**(3). Disturbing motor operation**

## 4.2 ROUTINE EXAMINATION AND PERIODICAL EXAMINATION

Inverter requires routine and periodical examination and maintenance

Carry out the examination only after the " Power LED " indicator goes off for at least 5 minutes


Maintenance item	Maintenance description	Examination period		Examination method	Criterion	Countermeasure
		Routine	1 Year			
Installation site environment	Reconfirm environment temperature and humidity	<input type="radio"/>		Refer to installation instructions and measure with thermometer and hygrometer	Temperature: -10~40 OC Humidity: under 95% without condensing	Improve installation site environment
	Check and remove any flammable material nearby	<input type="radio"/>		Visual inspection	No foreign object	
Inverter Installation and Grounding	Is there any abnormal vibration on the installation site?	<input type="radio"/>		Visual and audio Inspection	No foreign object	Tighten loose screw
	Is the grounding resistance within acceptable range?		<input type="radio"/>	Measure resistance by multi-meter	200V class under 100 ohm	Improve grounding
Input power source voltage	Is the voltage of the primary circuitry normal?	<input type="radio"/>		Measure voltage by multi-meter	Voltage level conforming specification	Improve input power source
Inverter external terminal mounting screw	Is the tighten parts secured?		<input type="radio"/>	Visual inspection. Use screwdriver to verify screw tightness	No abnormality	Tighten loose screw or return for repair
	Is there any sign of breakage on the terminal panel?		<input type="radio"/>			
	Is there any obvious rusty condition?		<input type="radio"/>			
Internal wiring of inverter	Is it deformed or skewed?		<input type="radio"/>	Visual inspection	No abnormality	Replace or return for repair
	Is the insulation of wire broken?		<input type="radio"/>			
Heat-sink	Is it accumulating dust or dirt?	<input type="radio"/>		Visual inspection	No abnormality	Clean up dust or dirt
PCB	Is it accumulating conductive metal or oil stain?		<input type="radio"/>	Visual inspection	No abnormality	Clean up or replace PCB
	Is there any over-heated or burnt component?		<input type="radio"/>			
Cooling fan	Is there any abnormal vibration or noise?		<input type="radio"/>	Visual and audio inspection	No abnormality	Replace cooling fan
	Is it accumulating dust or dirt?	<input type="radio"/>		Visual inspection		Clean up
Power component	Is it accumulating dust or dirt?		<input type="radio"/>	Visual inspection	No abnormality	Clean up
Capacitor	Is there any sign of strange order or leakage?	<input type="radio"/>		Visual inspection	No abnormality	Replace capacitor or inverter
	Is there any sign of swelling or bulging?	<input type="radio"/>				

### 4.3 MAINTENANCE AND EXAMINATION

Frequent examination and maintenance is not required for the inverter. To maintain appropriate reliability, please proceed with following periodical examination. Remember to turn off power supply and wait till the Power LED goes off before proceed. (Due to the large amount of remaining charges in the internal capacitors.)

- (1) Clean out internal dust and dirt.
- (2) Check out mounting screws on every terminal and parts. Tighten loose screws.
- (3) Dielectric strength test
  - (a) Remove all conducting wires between Drive and outside world. Power must be turned OFF.
  - (b) The dielectric strength test inside Drive should be carried out only for S10 major circuitry. Use DC 500V: high resistance meter. Measured resistance should be higher than 100M ohm.


**CAUTION: Do not perform dielectric strength test to the control circuit.**



*Connection for dielectric strength test*

## 4.4 VOLTAGE CURRENT MEASUREMENT

The voltage and current measurement on the primary and secondary side of the inverter may be different due to instrumentation variations. Refer to following diagram for measurement:



Different kinds  
of instruments



Measurement	Measuring point	Instrument	NOTE (Measurement criterion)
Input voltage $V_i$	(V1)	Moving-iron	
Input current $I_i$	(A1)	Moving-iron	
Input power $P_i$	(W1)	Power-meter	$P=W1$
Input power factor $PF_i$	Calculate power factor by the input voltage, input current and input power $PF_i = \frac{P_i}{\sqrt{3}V_i \cdot I_i} \times 100\%$		
Output voltage $V_o$	(V4) (V5) (V6)	Rectifier (Moving-iron not allowed)	Maximum voltage difference between wires under 3%
Output Current $I_o$	(A4) (A5) (A6)	Moving-iron	Under the inverter rated current
Output power $P_o$	(W3) (W4)	Power-meter	$P_o=W3+W4$
Output power factor	$PF_o = \frac{P_o}{\sqrt{3}V_o \cdot I_o} \times 100\%$		

## 4.5 EMI FILTER (CLASS B) SPECIFICATION

Model	Dimension (in)	Current (A)	Inverter model
S10F-2102	6.14 x 3.0 x 0.99	10A	S101F25-1 S101F50-1 S101001-1
S10F-2202	6.77 x 4.73 x 0.43	20A	S102002-1 S102003-1
S10F-4103	6.77 x 4.73 x 0.43	10A	S104001-1 S104002-1 S104003-1

## 4.6 DIN RAIL SPECIFICATION

Model	Dimension (in)	Inverter model
DIN S10-201	5.12 x 2.83 x 0.30	S10-1F25/1F50/1001/2F25/2F50/2001 S10-2002/2003/4001/4002/4003

## 4.7 SPECIFICATION OF BRAKING RESISTOR AND INPUT REACTOR

MODEL	Braking transistor build-in	Braking resistor build-in	Torque of braking	Model of braking resistor	Input AC Reactor	
					Current (A)	Inductance (mH)
S102F25-XX	X	X	20%	Note 1	3	7.0
S102F50-XX	X	X	20%	Note 1	5.2	4.2
S102001-XX	X	X	20%	Note 1	9.4	2.1
S102002-XX	○	X	20%	BRN2-202	19	1.1
S102003-XX	○	X	20%	BRN2-203	25	0.71
S104001-XX	○	X	20%	BRN2-401	2.5	8.4
S104002-XX	○	X	20%	BRN2-402	5.0	4.2
S104003-XX	○	X	20%	BRN2-403	7.5	3.6

○ : Built-in      X: Without built-in


Note 1: Without transistor and resistor built-in.

## 4.8 SPECIFICATION OF BRAKING RESISTOR

Model of Inverter	Model of Braking resistor	Motor (HP)	Specification of Braking Resistor		Braking Resistor ED(%)	Torque of braking (%)
			(W)	( $\Omega$ )		
S102002-XX	BRN2-202	2	150	100	10	119
S102003-XX	BRN2-203	3	200	70	9	116
S104001-XX	BRN2-401	1	60	750	8	125
S104002-XX	BRN2-401	2	150	400	10	119
S104002-XX	BRN2-403	3	200	250	8	128

### Note:

1. Braking level: 385/770Vdc for S10-200/400 series
2. Braking resistor mounting is below:



**4.9 PARAMETERS TABLE**

CUSTOMER				MODEL	
APPLICATION				TELEPHONE	
ADDRESS					
F_ ##	Value Setting	F_ ##	Value Setting	F_ ##	Value Setting
F_00		F_11		F_22	
F_01		F_12		F_23	
F_02		F_13		F_24	
F_03		F_14		F_25	
F_04		F_15		F_26	
F_05		F_16		F_27	
F_06		F_17		F_28	
F_07		F_18		F_29	
F_08		F_19		F_30	
F_09		F_20			
F_10		F_21			

P/N: 027-2162  
REV 3 October 2003  
© Copyright Safronics, Inc. 2003

5580 Enterprise Parkway  
Fort Myers, FL 33905  
(239) 693-7200  
Fax: (239) 693-2431